

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1242-6758	EC450 USB CABLE	70	EC450/1m microUSB cable/Bulk	6			eski modeller
1000-0274	W950 DIODE	50	DIODE/ESD Protector 5.6V	0,015			eski modeller
1000-0293	G502 TRANSISTOR	20	Transistor, Mosfet, N-Channel	0,075	G502	2009	Xperia öncesi yeniler
1000-0412	K660 BAT. CONN.	20	battery Connector	0,12			eski modeller
1000-0421	K790 SIM READER	24	Card Conn SIM Wilma/SIM reader	0,15			eski modeller
1000-7567	E10 LIGHT SENSOR	5	Light Sensor	0,15	E10I		Xperia
1000-7670	ST15 SIDE PUSH SWITCH	4	Side push switch	0,18	ST15I		Xperia
1000-7708	K550 MEMORY CARD READER	41	Cyndi Alps Memory Card Reader	0,435			eski modeller
1001-0060	E10 SIDE SWITCH	10	Side Switch(volume key, power key)	0,09	E10I		Xperia
1001-0324	W595 LOUDSPEAKER(YENİ)	73	Speaker	0,705	W595	2009	Xperia öncesi yeniler
1001-0931	1 GB MEMORY STICK M2	7	1GB Memory Stick Micro(M2)	7,44			eski modeller
1001-1167	K530 MİKROFON (YENİ)	5	Microphone	0,3			eski modeller
1001-2138	K550 CON X MICROSIM CARD READE	23	Con X Microsim Card Reader	0,195			eski modeller
1001-2234	2 GB MEMORY STICK M2	5	Memory Stick 2GB M2	8,94			eski modeller
1001-2269	MT27 SCREW	50	Screw JCIS#0 3.0 x 1.4	0,03	MT27I		Xperia
1001-2725	K660 MİKROFON	51	Mic 0, Electret	0,27			eski modeller
1002-8847	Z520 SİSTEM KONN.	139	Receptacle for PCB range 0.8-1.0 mm	0,165			eski modeller
1200-0073	K660 MODULE PA	5	Module PA WLAN 4040	0,99			eski modeller
1200-0085	K660 SHIELD CAN FENCE WITH LI	5	Shield Can Fence with lid	0,06			eski modeller
1200-0107	K850 IC VREG	5	IC Vreg	0,93			eski modeller
1200-0109	K530 COMBO BT FM MODULE	6	Combo BT/FM module	3,105			eski modeller
1200-0110	K850 IC VREG	5	IC Vreg	0,795			eski modeller
1200-0112	T650 CAMERA 3 MP	3	Camera 3 MPixel	10,62			eski modeller
1200-0117	K530 CAMERA VGA	2	Camera QCIF MPixel	2,265			eski modeller
1200-0119	K660 IND WW 4,7 UH +-20%3,6	5	Ind WW 4.7 uH +-20% 3X2.8X1	0,09			eski modeller
1200-0169	W890 MODULE GSM FEM SWITCH	3	Module GSM FEM/Switch/SAW/5.4x4.7x1.2mm	2,025			eski modeller
1200-0188	K850 SHIELD CAN CLOSED	3	Shield Can Closed assembly	0,06			eski modeller
1200-0293	T650 CONN BTB	4	Conn BtB 26 pin	0,165			eski modeller
1200-0296	T650 EAR SPEAKER	17	Ear Speaker	0,405			eski modeller
1200-0299	T650 VİBRATOR	5	Vibrator	0,705			eski modeller
1200-0311	C510 CAPACİTOR	5	Capacitor 220, uF +/-20% 4, V NK2003A_1	0,135	C510	2010	Xperia öncesi yeniler
1200-0320	C510 TRANS ARRAY	5	Trans Array	0,03	C510	2010	Xperia öncesi yeniler
1200-0331	T650 CONNECTOR	4	Conn Pogopin Plug 5p	0,465			eski modeller
1200-0374	K530 CAMERA VGA SOCKET	5	Conn Camera Socket Receptacle 0p Socket	0,315			eski modeller
1200-0417	T650 SOCKET VGA	3	Conn Camera Socket Main Cam.Socket 3.2M	0,54			eski modeller
1200-0425	K850 IC SINGLE BUS BUFFER GATE	5	IC Single bus buffer gate	0,135			eski modeller
1200-0484	T303 SİSTEM KONN.	9	System Connector BT Antenna	0,36			eski modeller
1200-0700	IC	3	A-GPS	2,94			eski modeller
1200-0703	T650 CONN POGO PIN	5	Conn Pogopin	0,12			eski modeller
1200-1223	K850 ASIC 3-AXIS ACCELEROMETER	3	ASIC 3-axis accelerometer	1,455			eski modeller
1200-1425	K850 CAMERA 5MP CMOS	2	Camera 5 MPixel CMOS	48,345			eski modeller
1200-1426	K850 XENON FASH	3	Xenon Fash Assy	9,24			eski modeller
1200-1644	W380 IC VREG	3	IC Vreg	0,15			eski modeller
1200-1657	INDUCTOR 10,	10	Inductor 10, uH 20%	0,105			eski modeller
1200-1694	K850 IC IF ISP1508 ES3 USB TRA	3	IC IF ISP1508 ES3 (3.5*3.5*0.8)	1,065			eski modeller
1200-1733	K850 CON BTB 30 PIN	5	Conn BtB 30 pin	0,15			eski modeller
1200-1735	K850 CON BTB 40 PIN	5	Conn BtB 40 pin	0,165			eski modeller
1200-1780	K850 TRANS P-CH FET WDFN6	5	Trans P-ch FET WDFN6	0,15			eski modeller
1200-1922	K850 IC DRI MAX8830 ES3 4*4 UC	5	IC Dri MAX8830 ES3 4x4 UCSP	0,96			eski modeller
1200-1951	K850 IC IF 3.5*3.5*0.8THIN ADE	5	IC IF 3.5x3.5x0.8 thin QFN	0,495			eski modeller
1200-2065	T650 DIODE SCHOTTKY 0,28 V	10	Diode Schottky 0,28 V	0,03			eski modeller
1200-2104	J110 LCD MODULE	1	Display CSTN 1	4,29			eski modeller
1200-2112	K850 MICROPHONE CONN	5	Microphone connector	0,12			eski modeller
1200-2144	T650 CONN LEAF SPRING ANTENNA	5	Conn Leaf Spring Receptacle 1p	0,03			eski modeller
1200-2180	W910 SHIELD CAN CAMERA	5	Shield Can Lid Camera	0,105	W910	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1200-2184	P1 CAMERA MODULE	4	Camera Module QCIF	2,775			eski modeller
1200-2190	W595 INDUCTOR	5	Inductor Wirewound 4.7 uH	0,075	W595	2009	Xperia öncesi yeniler
1200-2263	T707 CONN BTB	5	Conn BtB	0,51	T707	2009	Xperia öncesi yeniler
1200-2293	T707 CONN BTB	4	Conn BtB	0,18	T707	2009	Xperia öncesi yeniler
1200-2296	T650 IC	3	IC	1,23			eski modeller
1200-2375	K850 LOUDSPEAKER	3	Loudspeaker	0,885			eski modeller
1200-2376	K850 MICROPHONE	8	Mic 4.0 Electret	0,24			eski modeller
1200-2377	K850 EAR SPEAKER	6	Ear Speaker	0,465			eski modeller
1200-2390	T700 MİKROFON	5	Microphone	0,855	T700	2009	Xperia öncesi yeniler
1200-2407	IC AMP P-TSLP-1-1	5	IC Amp P-TSLP-1-1	0,315			eski modeller
1200-2447	K850 REAR COVER BLACK GREEN	8	Rear cover assembly Black/Green	5,91			eski modeller
1200-2451	K850 BATTERY COVER BLACK GREEN	14	Cover Battery door assy Black/Green	0,735			eski modeller
1200-2454	K850 SCREWSLOT L:0 D:0	5	Screw Slot Len:0, Diam:0,	0,015			eski modeller
1200-2455	K850 SCREW TORX LEN 5.0	36	Screw Torx Len:5.0 Diam:1.7	0,015			eski modeller
1200-2461	W910 SLIDER SUB ASS COMPLETE	13	Slider Sub Assembly (complete)	10,11	W910	2009	Xperia öncesi yeniler
1200-2467	W910 ANTENNA COVER	28	Antenna Cover	0,465	W910	2009	Xperia öncesi yeniler
1200-2485	W910 COVER MS BLACK	29	Cap Memory stick	0,075	W910	2009	Xperia öncesi yeniler
1200-2486	W910 ON-OFF KEY	19	Key(On/Off), HeartyRed/NobleBlack/IceWhi	0,135	W910	2009	Xperia öncesi yeniler
1200-2487	W910 VOLUME KEY	22	Key(Volume), HeartyRed/NobleBlack/IceWhi	0,135	W910	2009	Xperia öncesi yeniler
1200-2488	W910 CAMERA KEY	18	Key(Camera), HeartyRed/NobleBlack/IceWhi	0,3	W910	2009	Xperia öncesi yeniler
1200-2489	W910 MUSIC KEY	14	Key(Music), HeartyRed/NobleBlack/Icewhit	0,3	W910	2009	Xperia öncesi yeniler
1200-2491	W910 SHIELD CAN B	5	Shield Can Lid B	0,06	W910	2009	Xperia öncesi yeniler
1200-2493	W910 SCREW OTHER DIAM 1.4M	55	Screw Other Len:5.0 Diam:1.4 M	0,015	W910	2009	Xperia öncesi yeniler
1200-2506	W910 NAVIGATE ICE WHITE	1	Key, Navi, IceWhite	2,025	W910	2009	Xperia öncesi yeniler
1200-2509	W910 LOWER REAR COVER ICE WHIT	1	Cover Lower Rear Sub Assembly, IceWhite	3,09	W910	2009	Xperia öncesi yeniler
1200-2516	W910 KEYBOARD MAIN ICE WHITE	2	Keyboard Main, White Latin	2,1	W910	2009	Xperia öncesi yeniler
1200-2518	W910 SCREW TORX LEN 2.0	84	Screw Torx Len:2.0 Diam:1.4 M	0,015	W910	2009	Xperia öncesi yeniler
1200-2519	W910 CAP RF ICE WHITE	3	Cap (RF) Ice White	0,09	W910	2009	Xperia öncesi yeniler
1200-2520	W910 CO-BRAND ICE WHITE	6	Lable Co-brand Inlay, White, Generic	0,12	W910	2009	Xperia öncesi yeniler
1200-2522	W910 COVER SCREW UPPER	39	Cap Screw Upper	0,015	W910	2009	Xperia öncesi yeniler
1200-2523	W910 CAP SCREW ICE WHITE	10	Cap(Screw Lower), IceWhite	0,06	W910	2009	Xperia öncesi yeniler
1200-2525	W910 MCOMP SHEET PROTECTION	5	Mcomp Sheet Protection LCD	0,075	W910	2009	Xperia öncesi yeniler
1200-2552	K850 ICVREG 8 PIN LLP	5	IC Vreg 8-pin LLP	0,315			eski modeller
1200-2565	W910 ANTENNA	14	Antenna	0,465	W910	2009	Xperia öncesi yeniler
1200-2645	W910 LCD	59	Display A-SI TFT 2.36	18,975	W910	2009	Xperia öncesi yeniler
1200-2656	K850 KEYFOIL	18	Key FPC (Complete)	6,75			eski modeller
1200-2697	K850 ANTENNA PIFA	5	Antenna PIFA	0,54			eski modeller
1200-2700	K850 ANTENNA GASKET	5	Antenna Gasket	0,105			eski modeller
1200-2701	K850 TREAD INSERT	5	Thread Insert	0,105			eski modeller
1200-2711	W910 KEYFOIL WITH LUMI SHEEL	3	Key foil assy with Lumi Sheet	7,62	W910	2009	Xperia öncesi yeniler
1200-2713	W910 SPEAKER FLEX MODULE	48	Speaker Flex Module	3,165	W910	2009	Xperia öncesi yeniler
1200-2714	W910 CAMERA FLEX	43	Camera Flex Assy	2,985	W910	2009	Xperia öncesi yeniler
1200-2807	K850 BLUETOOTH ANTENNA	10	Bluetooth Antenna	0,06			eski modeller
1200-2824	K850 HOLDER METAL FRAME	2	Holder Metal frame assy	2,085			eski modeller
1200-2828	K850 SIM/COMBO CARD FPC	10	Card FPC Complete (SIM/COMBO)	2,52			eski modeller
1200-2831	K850 HOLDER PLASTIC LABEL TRAY	5	Holder Plastic Label tray	0,06			eski modeller
1200-2834	KRH LABEL K850	5	Label Core Unit	0,03			eski modeller
1200-2900	K850 SHIELD CAN LID	4	Shield Can Lid	0,045			eski modeller
1200-2901	K850 SHIELD CAN LID	5	Shield Can Lid	0,06			eski modeller
1200-2903	K850 SHIELD CAN LID	5	Shield Can Lid	0,075			eski modeller
1200-2904	K850 SHIELD CAN LID	5	Shield Can Lid	0,045			eski modeller
1200-2950	W995 MAGNET	5	Magnet	0,105	W995	2010	Xperia öncesi yeniler
1200-3042	W910 FOIL ADHESIVE DOUBLE SIDE	4	Foil Adhesive Double Side 0.0 mmAntenna	0,015	W910	2009	Xperia öncesi yeniler
1200-3047	W910 SCREW OTHER LEN 2.0	41	Screw Other Len:2.0 Diam:1.4 M	0,015	W910	2009	Xperia öncesi yeniler
1200-3078	K850 ON-OFF KEY BLACK	12	Key On/off Black	0,195			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1200-3079	K850 VOLUME KEY BLACK	8	Key Volume Black	0,255			eski modeller
1200-3231	OSC XO 32.768 kHz LC	5	Osc XO 32.768 kHz LC	1,11			eski modeller
1200-3418	K850 GASKET CIF CAMERA	5	Gasket, CIF camera	0,015			eski modeller
1200-3525	W910 LGHT GUIDE NAVI KEY SHEET	73	Light Guide Navi Key with Sheetkey	0,435	W910	2009	Xperia öncesi yeniler
1200-3683	K850 FOIL ADHESIVE SIDE(SIM/CO	4	Foil Adhesive Double Side 0.0 mm (SIM/CO	0,015			eski modeller
1200-3876	W910 SHEET FPC SLIDE	53	Sheet FPC Slide	0,03	W910	2009	Xperia öncesi yeniler
1200-3903	W910 BATTERY COVER ICE WHITE	2	Battery Cover, IceWhite	0,84	W910	2009	Xperia öncesi yeniler
1200-3924	KRH LABEL W910	100	Label KRH	0,105	W910	2009	Xperia öncesi yeniler
1200-3994	IC VREG CS-5	5	IC Vreg CS-5	0,225			eski modeller
1200-4100	W760 IC FLIF CHIP 9-PIN	3	IC FLIP CHIP 9-PIN	0,18			eski modeller
1200-4674	K850 RUBBER CONN	5	Rubber connector	0,06			eski modeller
1200-4735	X10 BTB CONN. 16P	5	BtB Connector 16p	0,12	X10I		Xperia
1200-4814	K850 BATTERY COVER SILVER BLUE	1	Cover Battery door assy Silver/Blue	0,825			eski modeller
1200-4903	K850 ON-OFF KEY SILVER	7	Key On/off Silver	0,33			eski modeller
1200-4904	K850 VOLUME KEY SILVER	1	Key Volume Silver	0,255			eski modeller
1200-5075	W910 HOLDER ANTENNA SUB	4	Holder Antenna Sub Assy	0,12	W910	2009	Xperia öncesi yeniler
1200-5094	K850 GASKET SYSTEM CONN	5	Dust gasket system connector	0,045			eski modeller
1200-5130	R300 TVS DIODE	5	TVS Diode 12V 38pF	0,03			eski modeller
1200-5197	E10 CONN.BTB 10 PIN	10	Conn BtB 10 pin	0,15	E10I		Xperia
1200-5244	K850 MICROPHONE CONN GROMMET	5	Microphone connector grommet	0,06			eski modeller
1200-5473	W910 SLIDER SUB GOLD	1	Slider Sub Assembly Gold	10,11	W910	2009	Xperia öncesi yeniler
1200-5483	W910 COVER MS HAVANA BRONZE	10	Cap (Memory stick) HavanaBronze	0,075	W910	2009	Xperia öncesi yeniler
1200-5487	W910 ON-OFF KEY HAVANA BRONZE	7	Key (On/Off) HavanaBronze	0,135	W910	2009	Xperia öncesi yeniler
1200-5489	W910 VOLUME KEY HAVANA BRONZE	6	Key (volume) HavanaBronze	0,135	W910	2009	Xperia öncesi yeniler
1200-5577	W910 GAME KEY NOBLE BALCK	20	Key, Game, NobleBlack	0,135	W910	2009	Xperia öncesi yeniler
1200-5579	W910 NAVIGATE KEY NOBLE BLACK	22	Key, Navi, NobleBlack	2,025	W910	2009	Xperia öncesi yeniler
1200-5581	W910 LOVER REAR COVER BLACK	26	Cover Lower Rear Sub Assembly, NobleBlac	2,775	W910	2009	Xperia öncesi yeniler
1200-5593	W910 KEYBOARD MAIN NOBLEBLACK	31	Keyboard Main, NobleBlack, Latin	1,845	W910	2009	Xperia öncesi yeniler
1200-5599	W910 CAP RF BLACK	24	Cap (RF) Black	0,075	W910	2009	Xperia öncesi yeniler
1200-5626	W910 CAP SCREW LOWER NOBLEBLAC	61	Cap(Screw Lower), NobleBlack	0,06	W910	2009	Xperia öncesi yeniler
1200-6182	K850 BLUETOOTH MODULE FM STC	4	Module Bluetooth + FM STLC2592	2,655			eski modeller
1200-6309	T650 IC ESD PROT UDFN 6 2*2mm	8	IC ESD Prot UDFN 6 2x2 mm	0,27			eski modeller
1200-6420	K850 IC VREG MAX8640, 1.8V	5	IC Vreg MAX8640, 1.8V	0,465			eski modeller
1200-6457	T650 CONN BTB	8	Conn BtB	0,21			eski modeller
1200-6744	W910 CO-BRAND INLAY NOBELBLACK	24	Lable Co-brand Inlay, NobleBlack, Generi	0,12	W910	2009	Xperia öncesi yeniler
1200-6761	W380 HINGE FPC	16	PBA W380 Hinge PBA FPC Lena	3,03			eski modeller
1200-6773	W380 SIM M2 FLEX	12	SIM/M2 Flex	2,49			eski modeller
1200-6777	W380 UPPER PBA	18	Upper PBA	10,56			eski modeller
1200-6812	K850 CAMERA COVER PAD	16	Camera Cover Pad	0,015			eski modeller
1200-7033	Z320 IC LED DRIVER	3	IC LED Driver	0,735			eski modeller
1200-7390	W595 CONNECTOR FPC	5	Connector FPC 25p	0,36	W595	2009	Xperia öncesi yeniler
1200-7550	W380 SUB DISPLAY	3	Outer Display	2,55			eski modeller
1200-7601	G502 BT SHIELDING CAN	5	BT shielding can	0,03	G502	2009	Xperia öncesi yeniler
1200-7643	K660 SHIELD CAN LID	5	Shield Can Lid	0,045			eski modeller
1200-7756	W380 FOIL 0,0 MAIN WINDOW	5	Foil 0.0 mmTape, Main window	0,18			eski modeller
1200-7757	W380 WINDOW MAIN DISPLAY MAIN	1	Window Main Display Main window Assy	1,395			eski modeller
1200-7763	W380 LOWER FRONT COVER PURPLE	1	Lower Front Cover Assy - Purple	2,01			eski modeller
1200-7772	W380 SHIELD CAN LID BT	5	Shield Can Lid Shield can lid BT	0,03			eski modeller
1200-7787	W380 VOLUME KEY PINK	8	Volume Key - Pink	0,15			eski modeller
1200-7790	W380 MAIN WINDOW LABEL SILVER	10	Main window Label - Silver	0,645			eski modeller
1200-7792	KRH LABEL W380	20	KRH Label	0,015			eski modeller
1200-7793	W380 BATTERY COVER PURPLE	16	Battery Cover - Purple	0,435			eski modeller
1200-7827	J110 LED BACKLIGHT DRIVER	4	LED backlight driver	0,345			eski modeller
1200-7831	J110 LED BLUE	5	LED Blue	0,015			eski modeller
1200-7847	W760 OSC TCXO 27,456 MHZ	3	Osc TCXO 27,456 MHz	1,155			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1200-8192	W380 CAMERA 1.3 MPIXEL	1	Camera module 1.3 Mpixel	4,32			eski modeller
1200-8239	W890 CAMERA FLEX	6	Camera Flex Module	5,985			eski modeller
1200-8240	W890 KEY FLEX MODULE	13	Key Flex Module	6,09			eski modeller
1200-8241	W890 SIM-M2 FLEX MODULE	12	SIM/M2 Flex Module	2,79			eski modeller
1200-8268	W380 CONN BTB RECEPTACLE 24P	33	Conn BtB Receptacle 24p	0,195			eski modeller
1200-8295	K850 REAR COVER SILVER BLUE	5	Rear cover assembly Silver/Blue	5,415			eski modeller
1200-8708	W350 MOD PA EDGE	2	Mod PA EDGE	2,085			eski modeller
1200-8745	W380 CONN POGOPIN PLUG 5P	7	Conn Pogopin Plug 5p	0,78			eski modeller
1200-8787	K660 GASKET TAPE SIM READER	5	Gasket Tape near sim reader	0,06			eski modeller
1200-8846	W910 GAME KEY HEARTYPED	27	Key, Game, HeartyRed	0,135	W910	2009	Xperia öncesi yeniler
1200-8850	W910 NAVIGATE HEARTYRED	25	Key, Navi, HeartyRed	2,025	W910	2009	Xperia öncesi yeniler
1200-8956	W910 FOIL ADHESIVE DOUBLE SIDE	9	Foil Adhesive Double Side 0.0 mm(Panel A	0,03	W910	2009	Xperia öncesi yeniler
1200-8971	W890 LCD	36	Display 2,02 A-SI TFT	14,565			eski modeller
1200-9042	W910 STOPPER OPEN RIGHT	10	Stopper Open(Right)	0,06	W910	2009	Xperia öncesi yeniler
1200-9044	W910 SCREW OTHER LEN 6.5	100	Screw Other Len:6 Diam:1	0,015	W910	2009	Xperia öncesi yeniler
1200-9176	R300 SHOTTKY DIODE	5	Shottky Diode 2pin	0,045			eski modeller
1200-9179	W910 PANEL ANTENNA BLACK	17	Panel Antenna Sub Assy Black	0,315	W910	2009	Xperia öncesi yeniler
1200-9186	W910 PANEL ANTENNA RED	27	Panel Antenna Sub Assy Red	0,33	W910	2009	Xperia öncesi yeniler
1200-9189	W910 CAP RF RED	9	Cap (RF) Red	0,075	W910	2009	Xperia öncesi yeniler
1200-9206	W910 BATTERY COVER RED	27	Cover(Battery) Red	0,795	W910	2009	Xperia öncesi yeniler
1200-9223	W910 CAP SCREW LOVER RED	29	Cap Screw Lower Red	0,045	W910	2009	Xperia öncesi yeniler
1200-9228	W910 LOVER REAR COVER RED	21	Cover Lower Rear Sub Assembly Red	3,075	W910	2009	Xperia öncesi yeniler
1200-9232	W910 KEYBOARD MAIN HEARTYRED	32	Keyboard Main, HeartyRed, Latin	1,89	W910	2009	Xperia öncesi yeniler
1200-9239	W910 CO-BRANDING RED	43	Label Co-Branding Red/Generic	0,12	W910	2009	Xperia öncesi yeniler
1200-9356	W595 IC	1	IC Amplifier	2,055	W595	2009	Xperia öncesi yeniler
1200-9563	W380 LOUDSPEAKER	9	Loudspeaker	0,75			eski modeller
1200-9596	ST15 SIM CARD CONN.	5	Conn SIM Card	0,165	ST15I		Xperia
1200-9599	W890 ANT MAIN PIFA	18	Ant Main PIFA	0,555			eski modeller
1200-9670	W910 MUSIC KEY HAVANA BRONZE	2	Key(Music), HavanaBronze	0,3	W910	2009	Xperia öncesi yeniler
1200-9840	C510 BT AND RADIO TUNER	3	Bluetooth and RDS FM radio tuner.	2,655	C510	2010	Xperia öncesi yeniler
1200-9861	MT15 INPUT SWITCH	2	Input Switch Side Push	0,105	MT15I		Xperia
1200-9864	W705 BTB CON.	5	Conn BtB	0,135	W705 / W715	2010	Xperia öncesi yeniler
1200-9865	W380 HINGE	8	Hinge	0,21			eski modeller
1200-9961	W380 SCREW 5IP 1.6*4	5	Screw - 5IP - 1.6X4	0,015			eski modeller
1200-9964	W380 ADHESIVE SUB DISPLAY	10	Sub Display Adhesive	0,9			eski modeller
1200-9978	W350 IC CS 9	5	IC CS-9	0,18			eski modeller
1201-0039	W380 KEYBOARD FPC	12	PBA W380 Keyboard PBA FPC Assy	3,15			eski modeller
1201-0304	DIODE PROTECTION 5.0V SOD-523	5	Diode Protection 5.0 V SOD-523	0,03			eski modeller
1201-0489	W890 FRAME ASS PWB	1	Frame Sub Assembly PWB	1,17			eski modeller
1201-0502	W890 CAP GROMMET CAMR	4	Cap Grommet CamR	0,105			eski modeller
1201-0508	W890 GASKET BB	5	Gasket BB	0,015			eski modeller
1201-0510	W890 GASKET RF	5	Gasket RF	0,015			eski modeller
1201-0538	W890 CAMERA KEY	15	Key Camera	0,39			eski modeller
1201-0541	W890 MUSIC KEY	20	Key Music	0,36			eski modeller
1201-0637	KRH LABEL W890	20	Core Unit Label	0,135			eski modeller
1201-0639	W890 KEYBOARD	7	Keyboard, Latin Sparkling Silver	2,61			eski modeller
1201-0706	C510 IND CHIP	5	Ferrite B 330.0 Ohm 600.0 mA 0603	0,015	C510	2010	Xperia öncesi yeniler
1201-0746	W380 DIODE PROTECTION 15.0V	9	Diode Protection 15, V SOD882	0,045			eski modeller
1201-0785	W380 CO-BRAND INLAY	6	Cobrand Inlay Assy	0,33			eski modeller
1201-0898	W380 CAPACITOR 33 MF 3,3V	10	Capacitor 33, mF 3,3 V	0,3			eski modeller
1201-0985	K850 COVER REAR PLAST LATINCAM	5	Cover Rear Plastic Latin Camera Cover As	7,59			eski modeller
1201-1051	W760 GASKET CAMERA	5	Gasket Camera	0,03			eski modeller
1201-1117	W760 COVER M2 LIGHT SILVER	2	Cover M2 Light Silver	0,09			eski modeller
1201-1127	W760 KEYBOARD NUMERIC SILVER	3	Keyboard Numeric Light Silver	2,79			eski modeller
1201-1196	W760 FRONT FRAME COMP SILVER	1	Front Frame Complete	4,635			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1201-1200	W760 RECEIVER GROMMET BLACK	5	Receiver Grommet black	0,06			eski modeller
1201-1210	W760 LCD CUSHION PAD	5	LCD Cushion Pad	0,015			eski modeller
1201-1220	W760 SPEAKER BOX SILVER	1	Speaker Box - Light Silver	1,755			eski modeller
1201-1221	W760 SCREW LEN 3, DIAM 1,6	11	Screw-Len:3, Diam:1,6	0,03			eski modeller
1201-1243	W910 SHEET RADIATION	10	Sheet radiation	0,015	W910	2009	Xperia öncesi yeniler
1201-1281	W760 FLEX MAIN KEYPAD COMPLETE	4	PBA W760 Main Keypad Flex Complete	4,11			eski modeller
1201-1290	W760 REAR FRAME SILVER	2	Rear Frame Light Silver	1,2			eski modeller
1201-1294	W760 SHIELD CAN CLOSED GPS	5	Shield Can Closed GPS	0,03			eski modeller
1201-1302	W760 MICROPHONE GROMMET	5	Microphone Grommet	0,12			eski modeller
1201-1306	W760 FLEX ILLUMINATION	4	PBA W760 Flex Assembly, Side Key	3,84			eski modeller
1201-1309	W760 CONN BTB PLUG 16P	5	Conn BtB Plug 16p	0,195			eski modeller
1201-1381	W760 VOLUME KEY SILVER	4	Key Volume - Light Silver	0,18			eski modeller
1201-1382	W760 ANTENNA ASS	3	Antenna Assembly	3,33			eski modeller
1201-1484	W380 GASKET COAX CABLE	10	Coax Cable Gasket	0,045			eski modeller
1201-1916	W380 PANEL LIGHT SILVER	7	Cover Light panel Assy - Silver	0,135			eski modeller
1201-2058	W890 CAP GROMMET CAMF	4	Cap Grommet CamF	0,09			eski modeller
1201-2069	W890 RUBBER GND	5	Rubber GND	0,09			eski modeller
1201-2245	K850 IND WW 4.7uH+-20%	5	Ind WW 4.7 uH +-20% 2,95x2,95x0,9	0,165			eski modeller
1201-2253	DIODE PROTECTION 0.7 V SOD-882	4	Diode Protection 0.7 V SOD-882	0,09			eski modeller
1201-2432	J105 CONN LEAF SPRING	4	Conn Leaf Spring 0p	0,045	J105I	2009	Xperia öncesi yeniler
1201-2564	W380 COVER SCREW PURPLE	6	Screw Cover - Purple	0,075			eski modeller
1201-3599	C902 EAR SPEAKER	57	Ear Speaker	0,51	C902	2010	Xperia öncesi yeniler
1201-3866	Z320 MOSFER SCHOTTKY DIODE	5	MOSFET Schottky Diode	0,15			eski modeller
1201-4047	W910 WATER INDICATOR	10	Water Indicator	0,015	W910	2009	Xperia öncesi yeniler
1201-4052	W910 SCREW TOR*6 LEN 5.0	36	Screw Torx6 Len:5.0 Diam:1.7 M	0,015	W910	2009	Xperia öncesi yeniler
1201-4120	C510 ASIC	5	ASIC Baseband	0,27	C510	2010	Xperia öncesi yeniler
1201-4288	K330 TVS DIODE	5	TVS Diode 12V 38pF	0,045			eski modeller
1201-4486	W760 SIM READER	4	Conn SIM Reader	0,27			eski modeller
1201-4488	W760 CONN POGOPIN 2-PIN	5	Conn Pogopin 2-pin	0,24			eski modeller
1201-4706	W380 KEYBOARD RUBBER BASE PINK	5	Keyboard Rubber Base - Pink	0,72			eski modeller
1201-4841	W890 CONN LEAF SPRING	5	Conn Leaf Spring	0,045			eski modeller
1201-4842	C510 VIBRATOIR GROMMET	11	Vibrator Grommet	0,045	C510	2010	Xperia öncesi yeniler
1201-5010	W760 MUSIC WALKMAN KEY	2	Key Music Walkman	0,42			eski modeller
1201-5197	W350 CONN BTB 24 PIN	5	Conn BtB 24 pin	0,15			eski modeller
1201-5496	C510 IND WW 3,3	5	Ind WW 3.3 uH +-20% 3,0x2,8x1,2mm	0,135	C510	2010	Xperia öncesi yeniler
1201-5557	T650 SHIELD CAN	5	Shield Can	0,285			eski modeller
1201-5672	W380 HINGE PLUG PURPLE	3	Hinge plug - Purple	0,21			eski modeller
1201-5769	W350 CONN POGOPIN PLUG 5P	5	Conn Pogopin Plug 5p	0,495			eski modeller
1201-5928	HPM-70 BULK BLUE	4	PHF Stereo HPM-70 turquoise	4,41			eski modeller
1201-5932	W910 ADHESIVE FPC SPEAKER	10	Adhesive FPC Speaker	0,015	W910	2009	Xperia öncesi yeniler
1201-6260	K770 SHIELD CAN CLOSED	10	Shield Can Closed	0,045			eski modeller
1201-6416	T707 INDUCTOR	5	Ind WW 4.7 uH +-20% 3.6X2.8X1.0	0,135	T707	2009	Xperia öncesi yeniler
1201-6465	W595 IC	5	IC Vreg PLP1010-4	0,075	W595	2009	Xperia öncesi yeniler
1201-6555	LT15 INPUT SW PUSH SKSC ALPS	20	Input Switch Side Push SKSC ALPS	0,105	LT15I		Xperia
1201-6833	C510 FILTER	5	Filter 100, MHz K1210	0,045	C510	2010	Xperia öncesi yeniler
1201-7111	W890 CAMERA 3,2	3	Camera 3.2 Mpixel	10,02			eski modeller
1201-7269	W890 REAR COVER MOCHA BROWN	13	Rear Cover Assembly, Mocha Brown	2,535			eski modeller
1201-7310	K660 KEYBOARD WINE ON BLACK	3	Main Keypad, Wine on Black	3,015			eski modeller
1201-7311	K660 FRAME MAIN BLACK	5	Main Frame Assembly,Black	1,785			eski modeller
1201-7313	W890 ON-OFF KEY BROWN	7	Key On/Off, Mocha Brown	0,18			eski modeller
1201-7318	K660 COVER MS M2 BLACK	2	M2 Cover,Black	0,165			eski modeller
1201-7319	W890 VOLUME KEY BROWN	8	Key Volume, Mocha Brown	0,195			eski modeller
1201-7327	K660 VOLUME KEY BLACK	1	Volume Key,Black	0,3			eski modeller
1201-7328	K660 ON-OFF KEY BLACK	3	On/Off key,Black	0,27			eski modeller
1201-7329	K660 CAMERA KEY	2	Camera Key	0,3			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1201-7330	K660 ANTENNA	4	Antenna Assy	0,375			eski modeller
1201-7340	W890 KEYBOARD MAIN BROWN	8	Keyboard Main latin, Mocha Brown	2,91			eski modeller
1201-7345	W890 CAP RF BROWN	13	RF Cap, Mocha Brown	0,105			eski modeller
1201-7347	K660 BACK COVER WINE ONJ BLACK	1	Back Cover Assembly, Wine on Black	1,905			eski modeller
1201-7348	K660 ANTENNA COVER BLACK	2	Antenna cover Assy,Black	0,375			eski modeller
1201-7353	K660 BATTERY COVER BLACK	6	Battery Cover,Black	0,675			eski modeller
1201-7357	W890 CAP SCREW BROWN	11	Screw Cap, Mocha Brown	0,06			eski modeller
1201-7362	K660 LCD FRAME	5	Lcd frame assy	0,645			eski modeller
1201-7365	K660 KEYFOIL DOME	3	Keyfoil Dome Assy	4,32			eski modeller
1201-7375	W890 FRAME ASS CAMERA	5	Frame Sub Assembly Camera	0,555			eski modeller
1201-7382	K660 TAPE CAMERA PROTECTIVE	5	Camera protective tape	0,03			eski modeller
1201-7383	K660 GASKET CAMERA VGA	5	VGA Camera Gasket	0,015			eski modeller
1201-7468	W890 SHEET ISOLATION	5	MComp Sheet Isolation	0,015			eski modeller
1201-7578	K660 SPEAKER BOX	7	Speaker Box Assmebly	0,72			eski modeller
1201-7762	W380 SCREW PHILIPS 00-1.4*2.5	20	Screw - Philips 00 -1.4X2.5	0,015			eski modeller
1201-7884	T707 SCREW	5	Screw 3,5 x1,6	0,015	T707	2009	Xperia öncesi yeniler
1201-8051	W380 VIBRATOR CLIP	6	Vibrator Clip	0,12			eski modeller
1201-8077	C510 IC DRIVER	5	IC Driver	0,75	C510	2010	Xperia öncesi yeniler
1201-8100	C902 CAMERA 5MP	8	Camera 5 MPixel CMOS Slim	40,74	C902	2010	Xperia öncesi yeniler
1201-8367	W910 UPPER PBA SUB	66	W910/PBA/Upper Sub Assembly	5,37	W910	2009	Xperia öncesi yeniler
1201-8393	C510 DIODE	5	Diode Protection 0.0 V SOD-923	0,03	C510	2010	Xperia öncesi yeniler
1201-8440	C510 DIODE	5	Diode	0,09	C510	2010	Xperia öncesi yeniler
1201-8563	W380 ANTENNA 900	6	Antenna assy - 900	1,605			eski modeller
1201-8891	T303 DIODE	5	Diode Schottky 30.0 V VMD2	0,03			eski modeller
1201-9009	W760 COVER CHIN LIGHT SILVER	3	Chin Cover Assembly - Light Silver	1,215			eski modeller
1201-9133	W350 ASIC PM LITHIUM2 PMU	5	ASIC Power Management	1,575			eski modeller
1201-9438	C902 KEYBOARD FPC ASS.HIGH VOL	7	PBA C902 Keyboard FPC Assembly High volu	4,365	C902	2010	Xperia öncesi yeniler
1201-9440	C902 FRAME BLACK	2	Frame Assembly Black	4,005	C902	2010	Xperia öncesi yeniler
1201-9559	K660 SYSTEM CON	29	System Connector with BT antenna	0,255			eski modeller
1201-9753	C902 BATTERY COVER BLACK	2	Battery Cover Assembly Black	4,065	C902	2010	Xperia öncesi yeniler
1201-9869	C510 CONNECTOR	5	Connector	0,78	C510	2010	Xperia öncesi yeniler
1201-9881	C702 LOUDSPEAKER	6	Loudspeaker 0.0 Box C702 Water proof gas	0,9			eski modeller
1201-9906	C902 PBA CARD READER	5	PBA C902 Card Reader Assembly	4,125	C902	2010	Xperia öncesi yeniler
1201-9911	C902 SIDE KEYS	28	Side Keys	0,465	C902	2010	Xperia öncesi yeniler
1201-9946	C702 SIM CONNECTOR	3	Card Conn SIM	0,195			eski modeller
1201-9998	C902 BT ANTENNA	5	BT Antenna	0,255	C902	2010	Xperia öncesi yeniler
1202-0003	C902 SPEAKER BOX	37	Speakerbox Assembly	3,66	C902	2010	Xperia öncesi yeniler
1202-0012	C902 PBA TOUCH SENSOR FPC	52	PBA C902 touch sensor fpc assembly	5,205	C902	2010	Xperia öncesi yeniler
1202-0070	C702 KEYBOARD FPC	8	Keyboard FPC	4,245			eski modeller
1202-0090	K660 GASKET FUNCTION KEY COND	5	Function Key conductive gasket	0,015			eski modeller
1202-0108	W350 LCD	9	Display 1.9 TFT	11,685			eski modeller
1202-0454	W380 UPPER BACK COVER BLUE	3	Upper Back Cover Assy - Blue	1,86			eski modeller
1202-0466	W380 LOWER FRONT DARK GREY	4	Lower front cover assy - Dark Grey	2,01			eski modeller
1202-0479	W380 HINGE PLUG DARK GREY	8	Hinge plug - Dark Grey	0,21			eski modeller
1202-0488	W380 FLEX PLUG DARK GREY	5	Flex plug - Dark Grey	0,135			eski modeller
1202-0528	LT15 SIM READER	4	Card Conn SIM SIM reader	0,15	LT15I		Xperia
1202-0549	K660 CAMERA LENS WINE ON BLACK	2	Camera lens Assembly, Wine on Black	0,345			eski modeller
1202-0550	K660 CAMERA RING ASS	2	Camera Ring Assembly	0,675			eski modeller
1202-0657	W380 LOWER BACK COVER DARK GRE	5	Lower Back Cover Assy - Dark Grey	0,72			eski modeller
1202-0680	W380 COVER LIGHT PANEL BLACK	5	Cover Light Panel Assy - Black	0,135			eski modeller
1202-0683	W380 BATTERY COVER DARK GREY	13	Battery Cover - Dark Grey	0,435			eski modeller
1202-0686	W380 COVER SCREW DARK GREY	18	Screw Cover - Dark Grey	0,075			eski modeller
1202-0835	C702 CAM HR C702	3	Camera Socket	0,72			eski modeller
1202-0843	C702 SHIELD CAN	5	Shield Can	0,03			eski modeller
1202-0850	C702 SHIELD CAN	5	Shield Can	0,03			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1202-0851	C702 SHIELD CAN	5	Shield Can	0,045			eski modeller
1202-0852	W380 VOLUM KEY DARK GREY	8	Volume Key - Grey	0,15			eski modeller
1202-0855	C702 SYSTEM CON	12	System connector	0,84			eski modeller
1202-0857	C702 SHIELD CAN	5	Shield Can	0,045			eski modeller
1202-0859	C702 CONNECTOR BTB	5	Connector BtB	0,195			eski modeller
1202-0861	W380 LABEL MAIN DARK SILVER	5	Main Window Label - Dark Silver	0,645			eski modeller
1202-0882	W380 KEYBOARD BLACK	2	Keyboard Latin - Black	2,67			eski modeller
1202-1069	K660 GASKET RECEIVER CONDUCTIV	5	receiver conductive gasket	0,015			eski modeller
1202-1195	W595 SYSTEM CONN.	26	System Connector	0,24	W595	2009	Xperia öncesi yeniler
1202-1364	C905 PBA KEY FLEX	2	PBA Key Flex Flip	24,24			eski modeller
1202-1672	W205 ZENER DIODE	5	Zener Diode	0,015	W205	2009	Xperia öncesi yeniler
1202-1676	W760 ASIC ACCELEROMETER	3	ASIC Accelerometer	1,275			eski modeller
1202-1861	W760 LABEL SIM	4	Label, SIM	0,015			eski modeller
1202-1873	W302 IC AUDIO AMP.	5	IC Audio amp.	0,27	W302	2009	Xperia öncesi yeniler
1202-1901	W302 DIODE	3	Diode ESD protection 6.8V	0,045	W302	2009	Xperia öncesi yeniler
1202-2127	W302 IC	5	IC reg 2V8	0,24	W302	2009	Xperia öncesi yeniler
1202-2264	HBH-IV840 BATTERY	3	Battery	1,365			eski modeller
1202-2326	K660 VOLUME KEY LIME ON WHITE	3	Volume Key, Lime on White	0,195			eski modeller
1202-2327	K660 ON-OFF KEY LIME ON WHITE	3	On/Off key, Lime on White	0,195			eski modeller
1202-2330	K660 COVER MS M2 LIME ON WHITE	3	M2 Cover, Lime on White	0,165			eski modeller
1202-2331	K660 FRAME MAIN LIME ON WHITE	1	Main Frame Assembly, Lime on White	1,77			eski modeller
1202-2333	K660 CAMERA LENS LIME ON WIHIT	2	Camera lens Assembly, Lime on White	0,345			eski modeller
1202-2334	K660 BACK COVER LIME ON WHITE	2	Back Cover Assembly, Lime on White	1,905			eski modeller
1202-2891	W350 SIM M2 ASS	11	PBA W350 SIM M2 PBA complete Updated SIM	2,685			eski modeller
1202-2896	W350 KEYFOIL	7	PBA W350 Key Foil Flex Complete Cost Dow	2,505			eski modeller
1202-2973	W350 KEY LOCK BLACK PURP	2	Key lock key/Hypnotic Black	0,33			eski modeller
1202-3245	C902 CO-BRAND CYBERSHOT	74	Co-Brand Label Cybershot	0,435	C902	2010	Xperia öncesi yeniler
1202-3652	W760 SCREW LEN 2,6 DIAM 1,6	7	Screw-Len:2,6 Diam:1,6	0,03			eski modeller
1202-3679	W760 CONDUCTIVE COAX GROUND	10	Conductive Coax Ground	0,12			eski modeller
1202-4187	C702 FLASH FPC	3	Flash FPC	3,195			eski modeller
1202-4196	W890 REAR COVER BLACK	5	Rear Cover Assembly, Espresso Black	2,52			eski modeller
1202-4202	C702 LCD 2,2 QVGA	7	LCD 2.2" QVGA	14,925			eski modeller
1202-4216	W890 ON-OFF BLACK	12	Key On/Off, Espresso Black	0,165			eski modeller
1202-4218	W890 VOLUME KEY BLACK	13	Key Volume, Espresso Black	0,18			eski modeller
1202-4251	W890 KEYBOARD BLACK	6	Keyboard Main Latin, Espresso Black	2,73			eski modeller
1202-4268	W890 CAP RF BLACK	11	RF Cap, Espresso Black	0,105			eski modeller
1202-4271	W890 CAP SCREW BLACK	1	Screw Cap, Espresso Black	0,06			eski modeller
1202-4283	W890 CO-BRAND BLACK	2	Co-Brand Label, Generic, Espresso Black	0,09			eski modeller
1202-4297	W890 BATTERY COVER BLACK	1	Battery Cover, Espresso Black	3,24			eski modeller
1202-4357	W350 VOLUME KEY BLACK	3	Volume key/Hypnotic Black	0,27			eski modeller
1202-4362	W350 HINGE	2	Hinge	0,315			eski modeller
1202-4687	W595 VIBRATOR	5	Vibrator	0,66	W595	2009	Xperia öncesi yeniler
1202-4703	W910 ADHESIVE	10	Adhesive	0,015	W910	2009	Xperia öncesi yeniler
1202-4832	W350 FRONT PANEL BLACK	7	Front Panel/Black	0,15			eski modeller
1202-4900	W380 SYSTEM CONN	37	Conn I/O Receptacle 12p System Connector	0,18			eski modeller
1202-5123	W350 BLUETOOTH ANTENNA	5	Bluetooth antenna assy	0,945			eski modeller
1202-5979	W350 SPEAKER BOX 900	6	Speaker Box Assembly 900	1,77			eski modeller
1202-6041	W910 SHEET DISPLAY FLEX	10	Sheet Display Flex	0,015	W910	2009	Xperia öncesi yeniler
1202-6449	R300 IC RADIO REC.	5	IC AM/FM Radio Receiver	2,1			eski modeller
1202-6532	W350 ESD PROTECTION	5	ESD Protection	0,015			eski modeller
1202-7371	W380 GASKET SYSTEM CONN	5	System Connector Gasket	0,015			eski modeller
1202-7650	W595 IC	5	IC Vreg	0,18	W595	2009	Xperia öncesi yeniler
1202-7923	W380 COAX CABLE CONDUCTIVE	20	Coax cable Conductive Cushion	0,06			eski modeller
1202-8420	C905 COVER FLIP FRONT BLACK	1	Cover Flip Front Assembly Black	1,635			eski modeller
1202-8590	C905 LOUDSPEAKER	4	Loudspeaker Assembly	2,04			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1202-8671	C905 COVER REAR BLACK	1	Cover Base Rear Assembly Black	11,445			eski modeller
1202-8687	C905 KEYFOIL NUMERIC	2	Numeric Key Foil	3,075			eski modeller
1202-8856	C905 SLIDER FPC	1	Slider FPC Assy	1,23			eski modeller
1202-9266	C702 CONN BTB RECEPTACLE 26P	5	Connector	0,21			eski modeller
1202-9271	W595 SMD VIBRATOR	5	SMD Vibrator	0,6	W595	2009	Xperia öncesi yeniler
1202-9428	W302 IC	5	IC Dri QFN10	0,24	W302	2009	Xperia öncesi yeniler
1202-9472	W302 DIODE	5	Diode Schottky 30, V SC79	0,015	W302	2009	Xperia öncesi yeniler
1202-9483	S312 DIODE	5	Diode Zener 20, V SOD-523	0,015	S312	2009	Xperia öncesi yeniler
1202-9828	W910 BLUETOOT FLEX ANTENNA	3	Ant BT Flex CS Unique Assembly	3,915	W910	2009	Xperia öncesi yeniler
1203-0011	W980 HINGE FLEX	1	Hinge Flex	8,595			eski modeller
1203-0108	W380 CONN BTB RECEPTACLE 26P	5	Conn BtB Receptacle 26p	0,21			eski modeller
1203-0201	J105 DIODE	10	Diode Zener 5, V SOT-723	0,045	J105I	2009	Xperia öncesi yeniler
1203-0253	W910 FRONT COVER PLASTIC BLACK	7	Cover Front Plastic Assy Complete, CS Un	6,81	W910	2009	Xperia öncesi yeniler
1203-0256	W910 FRONT COVER PLASTIC WHITE	1	Cover Front Plastic Assy Complete, CS Un	7,365	W910	2009	Xperia öncesi yeniler
1203-0322	C510 INDUCTOR	5	Inductor Wirewound	0,09	C510	2010	Xperia öncesi yeniler
1203-0598	C902 MİKROFON	6	Microphone	0,3	C902	2010	Xperia öncesi yeniler
1203-0662	W910 SHEET BADET	10	Sheet (B)	0,015	W910	2009	Xperia öncesi yeniler
1203-1139	G502 LCD	5	Display 1.96 TFT	12,165	G502	2009	Xperia öncesi yeniler
1203-1286	G502 RECEIVER	11	Receiver	0,525	G502	2009	Xperia öncesi yeniler
1203-1287	K660 RECEIVER	6	Receiver	0,435			eski modeller
1203-1288	G502 LOUDSPEAKER BOX	10	Loudspeaker Speaker box Assy	0,69	G502	2009	Xperia öncesi yeniler
1203-1339	W910 SHEET R CENTER	7	Sheet (R center)	0,015	W910	2009	Xperia öncesi yeniler
1203-1348	W910 SHEET (R REAR)	10	Sheet (R rear)	0,015	W910	2009	Xperia öncesi yeniler
1203-1510	G502 KEYFOIL FPC	12	Key Dome Foil FPC Assembly	3,18	G502	2009	Xperia öncesi yeniler
1203-1515	K660 FRONT COVER WINE BLACK	2	K660,Front Cover, La, Wine on Black	9,69			eski modeller
1203-1517	K660 FRONT COVER LIME WHITE	2	K660,Front Cover, La, Lime on White	9,69			eski modeller
1203-1606	C702 SHIELD CAN	5	Shield Can	0,03			eski modeller
1203-1853	C702 LCD FRAME	4	LCD Frame Assy	0,705			eski modeller
1203-1889	C702 O-RING FOR SYSTEM CON	4	O-ring for system conn	0,15			eski modeller
1203-1900	C702 MAIN ANTENNA AGPS	5	Main Antenna AGPS	0,51			eski modeller
1203-1904	C702 ANTENNA BLUETOOTH	4	Bluetooth Antenna	0,135			eski modeller
1203-2039	C702 KEYBOARD CYAN SPLASH	2	Keyboard Cyan Splash Latin	2,505			eski modeller
1203-2040	C702 COVER KEYPAD CYAN SPLASH	4	Keypad Cover Cyan Splash	0,81			eski modeller
1203-2043	G502 MAIN ANTENNA	5	Main Antenna assembly	0,42	G502	2009	Xperia öncesi yeniler
1203-2046	C702 MS COVER M2	4	M2 Cover	0,39			eski modeller
1203-2052	C702 CO-BRAND CYAN SPLASH	5	Co-brand Cyan Splash	0,375			eski modeller
1203-2053	C702 ON-OFF KEY	4	Key On/Off Power Key	0,195			eski modeller
1203-2065	C702 VOLUME KEY	4	Key Volume	0,195			eski modeller
1203-2067	C702 CAMERA KEY	3	Key Camera	0,3			eski modeller
1203-2069	C702 BACK COVER	1	Back Cover	3,315			eski modeller
1203-2079	W910 SHEET (R LCD)	10	Sheet (R LCD)	0,015	W910	2009	Xperia öncesi yeniler
1203-2133	C702 SCREW OTHER LEN 0.0 D:1.2	8	Screw Other Len:0.0 Diam:1.2	0,015			eski modeller
1203-2142	C702 SCREW OTHER L:0.0 D:1.7	11	Screw Other Len:0.0 Diam:1.7 Screw M1.7	0,015			eski modeller
1203-2151	C702 BATTERY COVER CYAN SPLASH	12	Battery Cover Cyan Splash	1,95			eski modeller
1203-2162	W350 WALKMAN KEY HYPTONİC BLK	2	Walkman key/Hypnotic Black	0,255			eski modeller
1203-2575	KRH LABEL W350	20	Label	0,075			eski modeller
1203-2598	W350 CARRIER INNER FRAME	3	Carrier inner frame	2,235			eski modeller
1203-2697	K660 ANTENNA COVER WHITE	3	Cover Plastic antenna cover for white co	0,39			eski modeller
1203-2790	G705 ASIC	27	ASIC PM WLAN PMU	0,51	G705	2010	Xperia öncesi yeniler
1203-2842	MPS-30 PORTABLE SPEAKER BLAC	1	MPS-30 Portable Speaker/Black Silver	6,78			eski modeller
1203-2881	C702 MAIN RUBBER RING	5	Main Rubber Ring	0,165			eski modeller
1203-3101	C702 GASKET	5	Gasket	0,015			eski modeller
1203-3156	C702 BATTERY CON	5	Battery connector	0,225			eski modeller
1203-4183	C702 ADHESIVE RF HOLE	5	RF Hole Adhesive	0,015			eski modeller
1203-4594	S312 IC	4	IC Amplifier 500mA	0,18	S312	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1203-4761	W350 SHIELD CAN LID BB	5	Shield Can Lid bb	0,135			eski modeller
1203-4820	W595 MS CONNECTOR	4	MS Connector	0,27	W595	2009	Xperia öncesi yeniler
1203-4827	W350 SHIELD CAN LID BT	5	Shield Can Lid BT	0,03			eski modeller
1203-4926	C902 FOIL ADH. DOUBLE SIDE	2	Foil Adhesive Double Side 0.235 mmLCD ta	0,225	C902	2010	Xperia öncesi yeniler
1203-5167	HPM-70 WHITE-PINK	2	HPM-70 Pink/White	4,41			eski modeller
1203-5255	C902 LOUDSPEAKER GASGET	360	Loudspeaker gasket	0,03	C902	2010	Xperia öncesi yeniler
1203-5259	C902 ANTENNA COVER BLACK	2	Antenna Cover Assembly Black	2,295	C902	2010	Xperia öncesi yeniler
1203-5307	U5 SIM CONNECTOR	5	SIM Card Connector	0,18	U5I		Xperia öncesi yeniler
1203-5460	K850 FRONT COVER KEYPAD GREEN	8	Cover Front Plastic Latin CS Unique Lumi	10,005			eski modeller
1203-5688	K850 FRONT COVER KEYPAD BLUE	9	Front Assy Latin CS Blue/Silver/Black	10,005			eski modeller
1203-5870	C510 IC LINEAR	5	IC Linear	0,885	C510	2010	Xperia öncesi yeniler
1203-6150	C702 GASKET LCD CONDUTIVE	5	LCD Conductive gasket	0,015			eski modeller
1203-6152	C702 GASKET BATTERY CONDUCTIVE	5	Battery Conductive Gasket	0,045			eski modeller
1203-6314	C902 SCREW 1,6 X 6,1	18	Screw 1,6 x 6,1	0,015	C902	2010	Xperia öncesi yeniler
1203-6349	W302 LCD	6	LCD assy	11,04	W302	2009	Xperia öncesi yeniler
1203-6579	K850 RF MODULE TOR PRE-BUMPED	1	RF-Module Thor Pre-bumped	24,75			eski modeller
1203-6680	W350 CAMERA WINDOW	5	Camera Window	0,225			eski modeller
1203-7705	W350 DIODE SCHOTTKY	5	Diode Schottky	0,06			eski modeller
1203-8243	W890 SHEET (GSM)	5	MComp Sheet (GSM)	0,015			eski modeller
1203-8246	W890 SHEET (UMTS)	5	MComp Sheet (UMTS)	0,015			eski modeller
1203-8392	W350 SCREW PH 6,0*1,4MM BLAC	4	Screw PH 6.0x1.4 mm /black	0,015			eski modeller
1203-8687	T303 CHARGE IC	9	Charge IC	0,285			eski modeller
1203-8800	W350 RECEIVER eski	2	Net Earspeaker	0,03			eski modeller
1203-9125	W302 DIODE	5	Diode ESD protection 12V	0,03	W302	2009	Xperia öncesi yeniler
1203-9138	W302 DIODE	5	Diode Protection	0,135	W302	2009	Xperia öncesi yeniler
1203-9142	W302 EMI FILTER	4	EMI/RFI Filter	0,105	W302	2009	Xperia öncesi yeniler
1203-9688	C510 CONNECTOR	5	Conn Coax Plug 6p RF-probe contact	0,12	C510	2010	Xperia öncesi yeniler
1204-0066	C902 CORE UNIT LABEL	70	Core unit Label	0,09	C902	2010	Xperia öncesi yeniler
1204-0763	W890 REAR COVER SLIVER	10	Rear Cover Assembly, Sparkling Silver	2,55			eski modeller
1204-0821	W890 ON-OFF KEY SILVER	16	Key On/Off, Sparkling Silver	0,165			eski modeller
1204-0823	W890 VOLUME KEY SILVER	16	Key Volume, Sparkling Silver	0,18			eski modeller
1204-0841	W890 CAP RF SILVER	25	RF Cap, Sparkling Silver	0,105			eski modeller
1204-0850	W890 CAP SCREW SILVER	24	Screw Cap, Sparkling Silver	0,06			eski modeller
1204-0894	W890 SPACER (LCD_CON)	5	Spacer(LCD_conn)	0,015			eski modeller
1204-1072	W760 A-B KEY SILVER	4	Key A/B Button Silver	0,225			eski modeller
1204-1074	W760 REAR FRAME GRAPHITE GREY	1	Rear Frame - Graphite Grey	1,47			eski modeller
1204-1075	W760 VOLUME KEY GRAPHITE GREY	1	Key Volume - Graphite Grey	0,18			eski modeller
1204-1395	W760 COVER M2 GRAPHITE GREY	1	Cover M2 Graphite Grey	0,09			eski modeller
1204-1401	W760 NAVIGATION KEY SILVER	2	Keyboard Navigation Silver	3,135			eski modeller
1204-1402	W760 KEYBOARD NUMERIC GRAPHITE	2	Keyboard Numeric Graphite Grey	2,79			eski modeller
1204-1408	W760 A/B BUTTON RED	5	Key A/B Button Red	0,225			eski modeller
1204-1419	W760 TOP REAR METAL MINT GREEN	1	Top Rear Metal Reflector Mint Green	3,27			eski modeller
1204-1670	K850 RF MODULE MAMMOTH PRE-BUM	1	RF-Module Mammoth Pre-bumped(850,1900,21	25,98			eski modeller
1204-1674	K660 RF MODULE SqUIDE PRE	1	RF-Module Squid Pre -bumped	14,685			eski modeller
1204-1957	K660 CUSHION 0 MMNON CONDUCTIV	5	Cushion 0, mmnon_conductive tape	0,015			eski modeller
1204-2807	W760 TAPE KAPTON	5	Kapton Tape	0,105			eski modeller
1204-2930	C905 BATTERY COVER BLACK	2	Battery Cover Black	0,975			eski modeller
1204-3109	T303 IC AUDIO POWER	5	IC Audio Power Amplifier	0,21			eski modeller
1204-3120	R300 IC 2 BIT VOL.TRANS.	5	IC 2bit Voltage Level Translator	0,24			eski modeller
1204-3124	T303 IC CHARGING	6	IC Lin 2x2 SON	0,285			eski modeller
1204-3441	W380 KEYBOARD RUBBER BASE ORAN	4	Keyboard Rubber Base - Orange	0,72			eski modeller
1204-3443	W380 KEYBOARD RUBBER CHAMPAGNE	5	Keyboard Rubber Base - Champagne	0,72			eski modeller
1204-3461	W380 VOLUME KEY BLACK	5	Volume Key - Black	0,15			eski modeller
1204-4497	C902 BATTERY COVER RED	5	Battery Cover Assembly Red	5,4	C902	2010	Xperia öncesi yeniler
1204-4555	W910 CAMERA	4	2MP Camera Module	6,27	W910	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1204-5334	R300 REAR FRAME BLACK	5	Rear Frame Black	1,17			eski modeller
1204-5336	R300 LCD	14	Display TFT 1,77"	8,445			eski modeller
1204-5378	C905 EAR SPEAKER	3	Ear Speaker	0,51			eski modeller
1204-5398	W705 CAMERA 3,2 MP	3	Camera 3.2 MPixel CMOS	6,66	W705 / W715	2010	Xperia öncesi yeniler
1204-5399	G705 CAMERA 3,2 MP	6	Camera 3.2 MPixel CMOS	10,02	G705	2010	Xperia öncesi yeniler
1204-5837	C510 ASIC	5	ASIC	0,885	C510	2010	Xperia öncesi yeniler
1204-5842	SPEAKER BOX GRAPHITE GREY	3	Speaker Box - Graphite Grey	1,755			eski modeller
1204-5903	C510 IC VOL.REG.	5	IC Voltage Regulator	0,165	C510	2010	Xperia öncesi yeniler
1204-6487	W890 CUSHION 0.0mm(SYSTEM CON)	5	Cushion 0,0 mm(System conn)	0,015			eski modeller
1204-4499	C902 FRAME ASSY RED	4	Frame Assembly Red	4,215	C902	2010	Xperia öncesi yeniler
1204-6673	C902 SCREW COVER BLACK	54	Screw Cover Coated Black	0,015	C902	2010	Xperia öncesi yeniler
1204-6720	W350 CONN RECEPTACLE 0P HIROSE	5	Conn Receptacle 0p Hirose RF connector	0,15			eski modeller
1204-7255	K770 SIM CARD WANING STICKER	15	SIM card warning sticker	0,06			eski modeller
1204-7629	C905 KEYBOARD NAV. BLACK	1	Keyboard Navigation Black	2,31			eski modeller
1204-8066	C905 KEY AB LEFT BLACK	4	Key A/B Left Black	0,435			eski modeller
1204-8068	C905 CO-BRAND	1	Co brand Label, Generic	0,09			eski modeller
1204-8117	C905 VOLUME KEY	1	Key Volume	0,15			eski modeller
1204-8121	C905 KEY MODE	1	Key Mode	0,18			eski modeller
1204-8135	C905 CAMERA KEY	1	Key Camera	0,435			eski modeller
1204-8144	C905 M2 LID	1	M2 Lid	0,27			eski modeller
1204-8172	ST17 VIBRATOR	3	Vibr Bar Analog DC	0,6	ST17I		Xperia
1204-8457	W100 HINGE	5	Hinge assy	1,41	W100I	2011	Xperia öncesi yeniler
1204-8458	W395 H-H FPC	2	H-H FPC	0,435			eski modeller
1204-8474	G502 CARD CONN.	6	SIM Card Conn Micro SD Hight, 2.2 mm	0,18	G502	2009	Xperia öncesi yeniler
1204-8948	C902 CONN. CCR-70	4	Connectivity CCR-70 M2 USB Adapter/RED	3,225	C902	2010	Xperia öncesi yeniler
1204-9440	W595 SIM CONN.	5	SIM Connector	0,15	W595	2009	Xperia öncesi yeniler
1205-0228	C702 FOIL 0.0 MM	5	Foil 0.0 mm	0,06			eski modeller
1205-0232	G502 MYLAR FOR SIM COMPENENTS	5	Mylar for sim components	0,03	G502	2009	Xperia öncesi yeniler
1205-0233	G502 LCD FRAME	6	LCD frame assy	1,125	G502	2009	Xperia öncesi yeniler
1205-0250	G502 FRAME COVER BLACK	1	Frame Cover assy Premium Black	2,835	G502	2009	Xperia öncesi yeniler
1205-0268	G502 CAMERA KEY BLACK	1	Camera Key Champagne Black	0,285	G502	2009	Xperia öncesi yeniler
1205-0269	G502 VOLUME KEY BLACK	3	Volume Key Champagne Black	0,285	G502	2009	Xperia öncesi yeniler
1205-0271	G502 CAMERA LENS WINDOW	6	Camera Lens window	0,15	G502	2009	Xperia öncesi yeniler
1205-0277	G502 KEYBOARD BLACK	2	Keyboard Champagne Black	2,53	G502	2009	Xperia öncesi yeniler
1205-0289	G502 BACK COVER BLACK	4	Back Cover Assy Black	1,455	G502	2009	Xperia öncesi yeniler
1205-0298	G502 BATTERY COVER BLACK	10	Battery Cover Premium Black	1,155	G502	2009	Xperia öncesi yeniler
1205-1102	W350 TAPE KEYPAD ADHESIVE	12	Keypad adhesive tape	0,555			eski modeller
1205-2016	C510 CONNECTOR	5	Connector	0,225	C510	2010	Xperia öncesi yeniler
1205-2049	W302 IC	5	IC Linear	0,945	W302	2009	Xperia öncesi yeniler
1205-2085	C702 KEYPAD COVER BLACK	3	Keypad Cover Metallic Black	0,81			eski modeller
1205-2087	C702 CO-BRAND BLACK	4	Co-brand Metallic Black	0,375			eski modeller
1205-2094	C702 SCREW COVER BLACK	2	Screw Cover Metallic Black	2,715			eski modeller
1205-2095	C702 BATTERY COVER BLACK	4	Battery Cover Metallic Black	1,95			eski modeller
1205-2393	C902 DOME FOIL	25	Dome Foil	0,435	C902	2010	Xperia öncesi yeniler
1205-2542	W760 FRONT COVER RED	2	Front Cover Assembly Red	5,475			eski modeller
1205-2738	C905 LEFT SIDE PANEL GREY	1	Left Sidepanel Dark Grey	0,435			eski modeller
1205-2747	C905 RIGHT SIDE PANEL TOP GREY	1	Right Sidepanel Top Dark Grey/Silver	0,3			eski modeller
1205-2752	C905 LIGHT GUIDE NAV.	11	Light Gu Navigation	0,525			eski modeller
1205-2835	C905 FOIL FLIP INNER BLACK	1	Foil Flip Inner Black	0,06			eski modeller
1205-3241	C905 KEYBOARD BLACK/SILVER	3	Keyboard Latin Black/Silver	0,975			eski modeller
1205-3372	C902 FLAT HEAD SCREW	6	Flat head screw	0,015	C902	2010	Xperia öncesi yeniler
1205-3382	C902 CUSHION	9	Cushion	0,03	C902	2010	Xperia öncesi yeniler
1205-3677	C902 CARRIER TOP FRONT INNER P	72	Carrier Top front inner panel assy	0,09	C902	2010	Xperia öncesi yeniler
1205-3995	C902 ADHESİVE DOUBLE SİDE KEYB	8	Adhesive Double Side Keyboardflex	0,015	C902	2010	Xperia öncesi yeniler
1205-4011	C905 AB KEY RIGHT BLACK	1	Key A/B Right Black	0,435			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1205-4262	C902 INSULATION TAPE KEYBOARD	6	Insulationtape keyboardflex	0,015	C902	2010	Xperia öncesi yeniler
1205-4332	C902 GASGET FOR KEYBOARD BTB	8	Gasket for Keyboard BtB	0,015	C902	2010	Xperia öncesi yeniler
1205-4490	C702 RECEIVER	15	Receiver Ear Speaker	0,495			eski modeller
1205-5076	C902 WONDOW PROTECTION TAPE	8	Window protection tape	0,06	C902	2010	Xperia öncesi yeniler
1205-5177	C905 MAGNET METAL	1	Magnet Metal	0,12			eski modeller
1205-5198	C902 PLASTIC SLIDER SNAP	8	Plastic Slider Snap	0,06	C902	2010	Xperia öncesi yeniler
1205-5606	W595 CONN. FPC	5	Connector FPC 26p	0,57	W595	2009	Xperia öncesi yeniler
1205-5717	W302 FRONY BLACK	7	Front assy black	4,935	W302	2009	Xperia öncesi yeniler
1205-5718	W302 KEYPAD BLACK	7	Keypad black latin	2,055	W302	2009	Xperia öncesi yeniler
1205-5720	W302 LCD WINDOW	7	LCD Window assy	0,675	W302	2009	Xperia öncesi yeniler
1205-5722	W302 BATTERY COVER BLACK	11	Batt Cover assy black	1,335	W302	2009	Xperia öncesi yeniler
1205-5723	W302 SCREW CAP BLACK	4	Screw cap black	0,06	W302	2009	Xperia öncesi yeniler
1205-5724	W302 SCREW	18	Screw	0,015	W302	2009	Xperia öncesi yeniler
1205-6201	W760 CHIN COVER GRAPHITE GREY	1	Chin Cover Assembly - Graphite Grey	1,2			eski modeller
1205-6232	W760 FRONT FRAME GRAPHITE GREY	1	Front Frame Complete Graphite	4,635			eski modeller
1205-6238	W760 REAR COVER SILVER	2	Rear Cover Assembly Silver	2,64			eski modeller
1205-6242	W760 REAR COVER RED	1	Rear Cover Assembly Red	2,64			eski modeller
1205-6247	W760 BATTERY COVER SILVER	2	Battery Door Assembly Silver	1,515			eski modeller
1205-6248	W760 BATTERY COVER RED	2	Battery Door Assembly Red	1,305			eski modeller
1205-6581	C905 DOME FOIL FLIP	7	Dome Foil Flip	0,255			eski modeller
1205-7314	R300 BTB CONNECTOR	1	BtB Connector Keyboard 20pin	0,27			eski modeller
1205-7316	R300 BTB CONN. LCD	1	BtB Connector Display 24pin	0,24			eski modeller
1205-7323	R300 EAR SPEAKER	20	Ear Speaker 10x4.8mm	1,125			eski modeller
1205-7654	C905 CAP NUMERIC KEYBOARD	1	Cap Numeric Keyboard	0,045			eski modeller
1205-7689	W350 KEYBOARD ICE BLUE	6	Keyboard Latin Ice blue	1,59			eski modeller
1205-7691	W350 FRONT COVER ICE BLUE	4	Front assembly/Ice blue	3,645			eski modeller
1205-7717	W350 GASKET MIKROFON GROMMER	5	Gasket Microphone grommet	0,06			eski modeller
1205-7724	W350 KEY LOCK BLACK ORANGE	5	Key lock key/Electric black	0,33			eski modeller
1205-7725	W350 KEY LOCK ICE BLUE	9	Key lock key/Ice blue	0,315			eski modeller
1205-7726	W350 WALKMAN BLACK ORANGE	6	Walkman key/Electric black	0,255			eski modeller
1205-7727	W350 WALKMAN KEY ICE BLUE	11	Walkman key/Ice blue	0,255			eski modeller
1205-7728	W350 VOLUME KEY BLACK ORANGE	6	Volume key/Electric black	0,27			eski modeller
1205-7729	W350 VOLUME KEY ICE BLUE	3	Volume key/Ice blue	0,27			eski modeller
1205-7730	W350 COVER REAR PLASTIC BACK	6	Rear cover assy /Blue	1,56			eski modeller
1205-7732	W350 FRONT PANEL ICE BLUE	7	Front Panel/Ice blue	0,15			eski modeller
1205-7805	C902 MCOMP SPRING METAL POGO S	10	MComp Spring Metal pogo spring	0,15	C902	2010	Xperia öncesi yeniler
1205-7992	C905 SIDE PANEL RIGHT BOT GREY	1	Sidepanel Right Bottom Dark Grey/Silver	0,18			eski modeller
1205-8115	K660 KEYBOARD CYAN ON BLACK	1	Main Keypad, Cyan on Black	3,015			eski modeller
1205-8141	K660 CAMERA LENS,CYAN ON BLACK	1	Camera lens Assembly,Cyan on Black	0,345			eski modeller
1205-8787	W595 IC	5	IC Vreg 600mA	0,45	W595	2009	Xperia öncesi yeniler
1205-9308	R300 MICROPHONE	13	Microphone 4mm Rubber Contact	0,42			eski modeller
1205-9362	W890 FRONT COVER BROWN	10	Front Cover Assy Complete, Mocha Brown	10,905			eski modeller
1205-9363	W890 FRONT COVER BLACK	6	Front Cover Assy Complete, Espresso Blac	9,915			eski modeller
1205-9364	W890 FRONT SILVER	10	Front Cover Assy Complete, Sparkling Sil	10,905			eski modeller
1205-9614	W380 KEY LOCKING PINK	12	Key Locking Assembly - Pink	0,39			eski modeller
1205-9617	W380 LEY LOCKING ORANGE	3	Key Locking Assembly - Orange	0,39			eski modeller
1205-9618	W380 KEY LOCKING CHAMPAGNE	11	Key Locking Assembly - Champagne	0,39			eski modeller
1205-9723	C902 SYSTEM CONNECTOR I/O REC.	151	System connector I/O Receptacle 12p	0,18	C902	2010	Xperia öncesi yeniler
1205-9750	W595 CAPACITOR	5	Capacitor 220.0 uF 4.0 V	0,135	W595	2009	Xperia öncesi yeniler
1205-9955	W350 FOIL ADHESIVE COND BT	5	Foil adhesive conductive BT	0,165			eski modeller
1206-0335	W302 KEYPAD SILVER	3	Keypad Silver latin	1,77	W302	2009	Xperia öncesi yeniler
1206-0339	W302 SCREW CAP SILVER WHITE	3	Screw cap silver white	0,06	W302	2009	Xperia öncesi yeniler
1206-0342	W302 FRONT SILVER	6	Front assy silver	4,68	W302	2009	Xperia öncesi yeniler
1206-0351	4 GB M2 MEMORY STICK MIKRO	26	Memcard 4 Gbyte 40.0 MHz 1.8 V M2	15,075			eski modeller
1206-0380	W350 MICROPHONE	12	Microphone	0,3			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1206-1531	W350 SHIELD CAN LID RF2	5	Shield Can Lid RF2	0,045			eski modeller
1206-2211	W350 FRONT COVER BLACK ORANGE	4	Front assembly/Electric black	4,515			eski modeller
1206-2736	W302 CAMERA FLEX	8	Camera Flex assy	11,475	W302	2009	Xperia öncesi yeniler
1206-2746	W350 GASKET CAMERA	5	Camera gasket	0,03			eski modeller
1206-2770	W595 FRONT BLUE	8	Front Cover Active Blue	3,63	W595	2009	Xperia öncesi yeniler
1206-2890	W350 GASKET SYSTEM CON	5	Gasket system connector	0,015			eski modeller
1206-2937	W705 CONN. POGOPIN	4	Conn Pogopin 5p	0,765	W705 / W715	2010	Xperia öncesi yeniler
1206-2940	W705 BTB CONN	2	Conn BtB Receptacle 70p	0,375	W705 / W715	2010	Xperia öncesi yeniler
1206-3316	W595 CONN. FPC	3	Connector FPC 51p	0,63	W595	2009	Xperia öncesi yeniler
1206-3481	W595 REAR COVER BLUE	5	Rear Cover Assy Active Blue	3,81	W595	2009	Xperia öncesi yeniler
1206-3517	W595 GASGET CAM.	5	Gasket Camera	0,015	W595	2009	Xperia öncesi yeniler
1206-3522	W595 CAP TOP BLUE	9	Cap Top Assy Active Blue	0,81	W595	2009	Xperia öncesi yeniler
1206-3534	W595 CAP BOTTOM BLUE	5	Cap Bottom Assy Active Blue	0,855	W595	2009	Xperia öncesi yeniler
1206-3542	W595 BATTERY COVER BLUE	9	Battery Cover Active Blue	0,795	W595	2009	Xperia öncesi yeniler
1206-4070	W595 MICROPHONE	18	Microphone	0,3	W595	2009	Xperia öncesi yeniler
1206-4089	W350 FLIP BLACK ORANGE	22	Flip assembly/ Electric Black	3,3			eski modeller
1206-4188	W595 PBA MAIN KEYBOARD FPC	2	PBA Main Keyboard FPC	3,48	W595	2009	Xperia öncesi yeniler
1206-4190	W595 LIGHT GUIDE MAIN KEYBOARD	3	Light Guide Main Keyboard	0,24	W595	2009	Xperia öncesi yeniler
1206-4196	W595 LIGHT GUIDE NAVI KEYBOARD	3	Light Guide Navi Keyboard	0,24	W595	2009	Xperia öncesi yeniler
1206-4202	W595 WALKMAN KEY	5	Walkman Key	0,39	W595	2009	Xperia öncesi yeniler
1206-4204	W595 VOLUME KEY BLUE	9	Volume Key Active Blue	0,3	W595	2009	Xperia öncesi yeniler
1206-4209	W595 KEYBOARD MAIN BLUE	2	Keyboard Main Latin Active Blue	2,67	W595	2009	Xperia öncesi yeniler
1206-4211	W595 KEYBOAR NAV. BLUE	3	Keyboard Navigation Active Blue	2,7	W595	2009	Xperia öncesi yeniler
1206-4788	W595 HALF TO HALF FPC	6	Half to Half FPC	0,51	W595	2009	Xperia öncesi yeniler
1206-4855	W705 WTB CONN.	5	Conn WtB Receptacle 2p	0,135	W705 / W715	2010	Xperia öncesi yeniler
1206-5067	RF HOLDER C702	1	RF Holder	69,255			eski modeller
1206-5418	W705 CAMERA CON. SOKET	5	Conn Camera Socket 0p	0,555	W705 / W715	2010	Xperia öncesi yeniler
1206-5455	W595 SHIELD CAN LID CAMERA	3	Shield Can Lid Camera	0,09	W595	2009	Xperia öncesi yeniler
1206-5529	C902 TOP FRONT OUTER PANEL	41	Top Front Outer Panel Assy	0,525	C902	2010	Xperia öncesi yeniler
1206-5570	W350 CUSHION BTB	5	Cushion BtB	0,015			eski modeller
1206-5717	W350 CUSHION CONDUCTIVE CARRIE	5	Cushion Conductive Carrier	0,045			eski modeller
1206-5800	W595 SHIELD CAN LID MAIN	3	Shield Can Lid Main	0,18	W595	2009	Xperia öncesi yeniler
1206-5801	W595 SHEILD CAN LID USB	3	Shield Can Lid USB	0,03	W595	2009	Xperia öncesi yeniler
1206-5815	W595 GASGET MICROPHONE	3	Gasket Microphone	0,21	W595	2009	Xperia öncesi yeniler
1206-6016	W380 GASKET ESD	5	ESD gasket	0,015			eski modeller
1206-6021	W380 GASKET ESD HINGE FLEX	5	ESD hinge flex gasket	0,015			eski modeller
1206-6196	W595 DEC PLATE BLUE	9	Decoration Plate Active Blue	1,41	W595	2009	Xperia öncesi yeniler
1206-6350	G705 LCD	1	Display 2.41 TFT	15,255	G705	2010	Xperia öncesi yeniler
1206-6531	W595 FRAME	5	Frame Assy	1,935	W595	2009	Xperia öncesi yeniler
1206-6545	W595 GASGET SPEAKER BOTTOM	5	Gasket Speaker Bottom	0,03	W595	2009	Xperia öncesi yeniler
1206-6546	W595 ADH.SPEAKER BOTTOM	5	Adhesive Speaker Bottom	0,045	W595	2009	Xperia öncesi yeniler
1206-6885	W595 SCREW	5	Screw Ph 1.6x6.5	0,015	W595	2009	Xperia öncesi yeniler
1206-6886	W595 SCREW	1	Screw Ph 1.2x3.4	0,015	W595	2009	Xperia öncesi yeniler
1206-6889	W595 SCREW	1	Screw Ph 1.6x3.0	0,015	W595	2009	Xperia öncesi yeniler
1206-6961	W595 SCREW	5	Screw Ph 1.4x2.1	0,015	W595	2009	Xperia öncesi yeniler
1206-7574	W595 HINGE	4	Hinge	4,785	W595	2009	Xperia öncesi yeniler
1206-7696	W350 DISPLAY GASGET	8	Display gasket	0,195			eski modeller
1206-8712	W350 FLIP HYPTONIC BLACK	4	Flip assembly/Hypnotic Black	3,3			eski modeller
1206-8751	W350 FLIP ASS ICE BLUE	14	Flip assembly/Ice blue	3,3			eski modeller
1206-9354	C902 MCOMP SHEET METAL	5	MComp Sheet Metal	0,105	C902	2010	Xperia öncesi yeniler
1206-9377	C902 CONDUCTIVE GASGET	10	Conductive gasket	0,015	C902	2010	Xperia öncesi yeniler
1206-9465	W380 UPPER FRONT COVER DARK GR	3	Cover Upper Front Cover Assy - Dark Grey	19,725			eski modeller
1206-9506	W380 FLEX TOUCH KEY LIGHT	3	Touch Keys Light Guide/Flex Assy	3,66			eski modeller
1206-9606	W705 INPUT SIDE SWITCH	19	Input Switch Side Push	0,12	W705 / W715	2010	Xperia öncesi yeniler
1207-0091	W595 LOUDSPEAKER	7	Loudspeaker 9x18	0,495	W595	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1207-0874	G705 SİM FLEX	30	Sim flex module	3,165	G705	2010	Xperia öncesi yeniler
1207-1165	W595 GASGET HINGE	5	Gasket Hinge	0,06	W595	2009	Xperia öncesi yeniler
1207-1167	W595 DUST GASGET HINGE	5	Dust Gasket Hinge	0,015	W595	2009	Xperia öncesi yeniler
1207-1173	W595 ADH. NAVIGATION PBA	5	Adhesive Navigation PBA	0,03	W595	2009	Xperia öncesi yeniler
1207-1694	C902 CONDUCTİVE GASGET GREY	10	Conductive gasket Grey	0,015	C902	2010	Xperia öncesi yeniler
1207-1842	W595 MAIN WINDOW	16	Main window	1,365	W595	2009	Xperia öncesi yeniler
1207-2059	C902 LIGHT GU LIGHT DIF. FILM	34	Light Gu Light diffusion film	0,06	C902	2010	Xperia öncesi yeniler
1207-2098	G705 PBA KEY NAVI	11	PBA Key Navi	4,26	G705	2010	Xperia öncesi yeniler
1207-2220	W595 ADH. HTH	5	Adhesive HtH	0,015	W595	2009	Xperia öncesi yeniler
1207-2232	W595 ADH. MAIN KEYBOARD	5	Adhesive Main Keyboard	0,015	W595	2009	Xperia öncesi yeniler
1207-2953	G705 INPUT SWITCH OTHER DOME	12	Input Switch Other Dome sheet for upper	0,135	G705	2010	Xperia öncesi yeniler
1207-3059	HPM-64 WALKMAN ICE BLUE	9	PHF Stereo HPM-64 Walkman /Ice blue	4,05			eski modeller
1207-3069	HPM-64 WALKMAN HYPNOTIC BLACK	5	HF Wired Portable PHF Stereo HPM-64 Hypn	4,05			eski modeller
1207-3072	HPM-64 WHITE	1	HF Wired Portable PHF Stereo HPM-64 Grap	4,095			eski modeller
1207-3389	C702 SIM TAPE	10	SIM Tape	0,015			eski modeller
1207-3407	G705 LOUDSPEAKER	44	Loudspeaker	0,66	G705	2010	Xperia öncesi yeniler
1207-3442	W595 GASGET SPEAKER TOP	5	Gasket Speaker Top	0,03	W595	2009	Xperia öncesi yeniler
1207-3776	HPM-64 HYPTONIC BLUE	6	PHF Stereo HPM-64 WALKMAN GREY	4,05			eski modeller
1207-6424	8 GB M2 MEMORY STICK MIKRO	2	Memorycard M2 8GB	27,93			eski modeller
1207-6685	C702 FRONT COVER CYAN SPLASH	1	Front Cover Assy Cyan Splash	8,34			eski modeller
1207-6697	C702 FRONT COVER METALLIC BLAC	1	Front Cover Assy Metallic Black	8,01			eski modeller
1207-7270	G502 FRONT BLACK	2	CS Front Assy Premium Black	8,295	G502	2009	Xperia öncesi yeniler
1207-7397	T303 LCD	9	Display 128x160 TFT	8,835			eski modeller
1207-7404	T303 LOUDSPEAKER BOX	24	Loudspeaker Box 38.5x19	1,155			eski modeller
1207-7627	W595 ADH. EARSPEAKER FPC BOTTO	44	Adhesive Earsp FPC Top	0,015	W595	2009	Xperia öncesi yeniler
1207-7657	W595 ADH. EARSPEAKER	5	Adhesive Earspeaker	0,09	W595	2009	Xperia öncesi yeniler
1207-8072	G705 SCREW OTHER LEN1,6 DIAM	53	Screw Other Len:1.6 Diam:1.4 M	0,015	G705	2010	Xperia öncesi yeniler
1207-8174	G705 CARRIER HOLDER SIM	4	Carrier Holder SIM	0,165	G705	2010	Xperia öncesi yeniler
1207-8178	G705 VOLUME KEY	10	Key Volume	0,33	G705	2010	Xperia öncesi yeniler
1207-8182	G705 CAMERA KEY	6	Key Camera	0,33	G705	2010	Xperia öncesi yeniler
1207-8184	G705 MUSIC KEY	15	Key Music	0,36	G705	2010	Xperia öncesi yeniler
1207-8200	G705 GASGET SIM	10	Gasket SIM	0,015	G705	2010	Xperia öncesi yeniler
1207-8206	G705 COVER LOWER REAR	3	Cover Lower Rear Sub Assembly	2,22	G705	2010	Xperia öncesi yeniler
1207-8216	G705 BATTERY COVER KNOB LOCK	1	Knob Lock Battery Cover	0,135	G705	2010	Xperia öncesi yeniler
1207-8592	G705 UPPER FRONT COVER	7	Cover Upper Front Sub Assembly	5,4	G705	2010	Xperia öncesi yeniler
1207-8625	G705 SCREW OTHER LEN 2,3 D 1,4	4	Screw Other Len:2.3 Diam:1.4 M	0,015	G705	2010	Xperia öncesi yeniler
1207-8627	G705 SCREW SHEET	49	Sheet Screw	0,015	G705	2010	Xperia öncesi yeniler
1207-8727	T303 EAR SPEAKER	13	Ear Speaker 11.0x7.0 Rectangular	0,42			eski modeller
1207-8729	T303 CAMERA 1.3 MP	2	Camera 1.3 MPixel CMOS	7,62			eski modeller
1207-8839	HPM-77 PHF	11	HF Wired HPM-77/Phantom Black	6,765			eski modeller
1207-9497	C905 COVER FLIP INNER METAL SI	1	Cover Flip Inner Metal Light Silver	1,005			eski modeller
1207-9792	HPA-30	48	HPA-30 Headphone Portable Antenna	3,93			eski modeller
1207-9843	C905 RIGHT SIDE PANEL TOP BLAC	1	Right Sidepanel Top Black/Silver	0,3			eski modeller
1207-9844	C905 RIGHT SIDE PANEL BOTTOM B	1	Right Sidepanel Bottom Black/Silver	0,18			eski modeller
1207-9846	C905 LEFT SIDE PANEL BLACK	1	Left Sidepanel Black	0,435			eski modeller
1207-9934	W760 FRONT COVER ROCKY SILVER	4	FrontCoverAssy/Rogers/RockySilver	5,745			eski modeller
1208-0601	X10 VIBRATOR	5	Vibrator Bar Sanyo SMD	0,945	X10I		Xperia
1208-0743	W302 KRH LABEL	20	IMEI Label	0,045	W302	2009	Xperia öncesi yeniler
1208-0913	C905 COVER REAR	2	Cover Rear assembly	1,74			eski modeller
1208-1001	W350 ADHESIVE DISPLAY	5	Display assy adhesive	0,12			eski modeller
1208-1341	W350 INNER FRAME PORON CUSHI	5	Inner frame poron cushions	0,21			eski modeller
1208-1603	K660 KEYBOARD SILVER ON BLACK	2	Main Keypad, Silver on Black	3,075			eski modeller
1208-1604	K660 CAMERA LENS SILVER&BLACK	5	Camera lens Assembly,Silver on Black	0,345			eski modeller
1208-1608	K660 BACK COVER SILVER & BLACK	2	Back Cover Assembly, Silver on Black	2,43			eski modeller
1208-2706	C510 CONNECTOR	5	Connector	0,27	C510	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1208-3002	W302 RECEIVER	4	Receiver	0,375	W302	2009	Xperia öncesi yeniler
1208-3003	W302 VİBRATÖR	5	Vibrator	0,555	W302	2009	Xperia öncesi yeniler
1208-4111	R300 KEYBOARD SILVER	1	Keyboard Latin Silver	3,645			eski modeller
1208-4124	R300 KEYBOARD BLACK	12	Keyboard Latin Black	3,645			eski modeller
1208-4741	W302 MICROPHONE	14	Microphone	0,675	W302	2009	Xperia öncesi yeniler
1208-4895	W760 SCREW LEN 2.1 DIAM 1.6	4	Screw-Len:2.1 Diam:1.6	0,03			eski modeller
1208-5489	W595 ADHESIVE	55	Adhesive Earsp FPC Bottom	0,015	W595	2009	Xperia öncesi yeniler
1208-6790	W350 ESD SHIELDING LABEL	5	ESD shielding label	0,03			eski modeller
1208-7013	W595 FRONT WHITE	7	Front Cover Cosmo White	4,035	W595	2009	Xperia öncesi yeniler
1208-7850	W595 CAP TOP WHITE	8	Cap Top Assy Cosmo White	0,93	W595	2009	Xperia öncesi yeniler
1208-7880	W595 CAP BOTTOM WHITE	8	Cap Bottom Assy Cosmo White	0,945	W595	2009	Xperia öncesi yeniler
1208-7904	W595 REAR COVER WHITE	9	Rear Cover Assy Cosmo White	4,245	W595	2009	Xperia öncesi yeniler
1208-7971	W595 BATTERY COVER WHITE	1	Battery Cover Cosmo White	1,59	W595	2009	Xperia öncesi yeniler
1208-8066	W595 CO BRAND BLUE	10	Co-Brand Active Blue	0,195	W595	2009	Xperia öncesi yeniler
1208-8261	W595 CO-BRAND WHITE	10	Co-Brand Cosmo White	0,21	W595	2009	Xperia öncesi yeniler
1209-0361	W760 LCD 2.2 TFT	3	Display 2.2 TFT Toshiba	15,105			eski modeller
1209-1901	C902 SLIDING LENS COVER BLACK	4	Sliding Lens Cover Coated Swift Black	2,76	C902	2010	Xperia öncesi yeniler
1209-2632	T700 CAMERA FLEX	47	Camera flex module	6,18	T700	2009	Xperia öncesi yeniler
1209-2634	T700 KEYFOIL	30	Key Flex Module	5,85	T700	2009	Xperia öncesi yeniler
1209-2636	T700 SIM/M2 FLEX MODULE	24	PBA T700	2,865	T700	2009	Xperia öncesi yeniler
1209-3372	W380 FLEX GASGET	10	Flex Gasket	0,015			eski modeller
1209-3583	W380 BTB TAPE	10	BTB Tape	0,015			eski modeller
1209-3891	HPM-64 GREY	10	HPM-64 WALKMAN SILVER	4,08			eski modeller
1209-3893	HPM-64 YELLOW	6	HPM-64 WALKMAN BLACK	4,05			eski modeller
1209-5423	R300 REAR FRAME SILVER	8	Rear Frame Silver	1,17			eski modeller
1209-6023	C510 DIODE	5	Diode Protection 5.0 V SOD-923	0,03	C510	2010	Xperia öncesi yeniler
1209-6782	W350 FLIP SENSOR	8	Flip sensor	0,12			eski modeller
1209-7277	W350 DISPLAY WINDOW BLACK	3	Window Main Display Printed Johanna Blac	0,72			eski modeller
1209-7278	W350 DISPLAY WINDOW ICE BLUE	3	Display window/Generic/Ice blue	0,795			eski modeller
1209-7282	W302 LIQ. INS. INDICATOR	10	liquid intrusion indicator#	0,015	W302	2009	Xperia öncesi yeniler
1209-8565	T303 VIBRATOR SMD	5	SMD Vibrator	0,615			eski modeller
1209-8717	W595 VOLUME KEY WHITE	3	Volume Key Cosmo White	0,3	W595	2009	Xperia öncesi yeniler
1209-8718	W595 KEYBOARD MAIN WHITE	10	Keyboard Main Latin Cosmo White	2,955	W595	2009	Xperia öncesi yeniler
1209-8719	W595 KEYBOARD NAVI. WHITE	11	Keyboard Navigation Cosmo White	2,97	W595	2009	Xperia öncesi yeniler
1209-9571	W350 FOIL INNER FRAME EFR	4	Foil inner frame EFR	0,195			eski modeller
1209-9940	T303 SYSTEM CONN. BT ANTENNA	44	System Connector BT Antenna	0,33			eski modeller
120AFH00000	ST26 SUB BOARD	4	Sub Board Assembly	6,945	ST26I		Xperia
120AFH00001	ST26 FRONT COVERDISPLAY	1	Front Cover Display Assembly	90	ST26I		Xperia
1210-0080	W350 KEYFOIL CARRIER EFR	5	Keyfoil Carrier EFR	0,345			eski modeller
1210-0318	G502 MAIN ANTENNA EDGE	2	Main Antenna assembly Edge	0,36	G502	2009	Xperia öncesi yeniler
1210-0424	G705 CUSHION SPEAKER CONN.	10	Cushion Speaker Connector	0,015	G705	2010	Xperia öncesi yeniler
1210-0438	G705 BATTERY COVER BLACK	36	Battery Cover Sub Assembly Black	1,53	G705	2010	Xperia öncesi yeniler
1210-0451	G705 KEY NAVI BLACK	34	Key Navi Black	2,01	G705	2010	Xperia öncesi yeniler
1210-0455	G705 KEYBOARD BLACK	32	Keyboard Latin Black	1,845	G705	2010	Xperia öncesi yeniler
1210-0559	C510 SYSTEM CONNECTOR	170	Connector	0,255	C510	2010	Xperia öncesi yeniler
1210-0708	W595 TAPE MAIN KEYBOARD LED	5	Tape Main Keyboard LED	0,015	W595	2009	Xperia öncesi yeniler
1210-0722	W595 TAPE NAVI KEY LED MIDDLE	5	Tape Navi Key LED middle	0,015	W595	2009	Xperia öncesi yeniler
1210-1397	W380 TAPE PROTECTIVE PLATE	50	Protective Plate Tape	0,015			eski modeller
1210-1400	C903 SCREW	50	Screw Other Len:1.6 Diam:1.4 M (EG)	0,015	C903	2010	Xperia öncesi yeniler
1210-2557	W595 CO BRAND JUNGLE GREY	8	Co-Brand Jungle Grey	0,195	W595	2009	Xperia öncesi yeniler
1210-2569	W595 DEC.PLATE JUNGLE GREY	3	Decoration Plate Jungle Grey	1,41	W595	2009	Xperia öncesi yeniler
1210-2756	W595 FRONT JUNGLE GREY	1	Front Cover Jungle Grey	3,495	W595	2009	Xperia öncesi yeniler
1210-2870	K660 FRONT COVER CYAN & BLACK	3	K660 Front Cover, La, Cyan on Black	10,125			eski modeller
1210-2942	W595 BATTERY COVER JUNGLE GREY	2	Battery Cover Jungle Grey	1,095	W595	2009	Xperia öncesi yeniler
1210-2946	W595 CAP TOP JUNGLE GREY	3	Cap Top Assy Jungle Grey	0,795	W595	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1210-2961	W595 CAP BOTTOM JUNGLE GREY	3	Cap Bottom Assy Jungle Grey	0,795	W595	2009	Xperia öncesi yeniler
1210-2968	W595 REAR COVER JUNGLE GREY	2	Rear Cover Assy Jungle Grey	5,43	W595	2009	Xperia öncesi yeniler
1210-3726	W595 LIQUID INDICATOR	5	Liquid Indicator	0,015	W595	2009	Xperia öncesi yeniler
1210-3896	LT15 CONN OTHER REC. 24P	30	Conn Other Receptacle 24p	0,24	LT15I		Xperia
1210-4353	W595 VOLUME KEY JUNGLE GREY	4	Volume Key Jungle Grey	0,3	W595	2009	Xperia öncesi yeniler
1210-4379	W595 KEYBOARD MAIN JUNGLE GREY	5	Keyboard Main Latin Jungle Grey	2,565	W595	2009	Xperia öncesi yeniler
1210-4381	W595 KEYBOARD NAV. JUNGLE GREY	5	Keyboard Navigation Jungle Grey	2,7	W595	2009	Xperia öncesi yeniler
1210-5319	W350 CUSHION BTB	5	Cushion BtB	0,015			eski modeller
1210-5696	W760 SPEAKER BOX PAD	10	Speaker box pad	0,03			eski modeller
1210-5806	K660 FRONT COVER SILVER&BLACK	2	K660 Front Cover, Latin, Silver on Black	10,125			eski modeller
1210-6285	W595 SCREW	5	Screw Ph 1.4x1.6	0,03	W595	2009	Xperia öncesi yeniler
1210-6458	T700 ANT MAIN PIFA	9	Ant Main PIFA	0,48	T700	2009	Xperia öncesi yeniler
1210-6575	K330 BATTERY COVER BLACK	4	Battery Cover Black	0,33			eski modeller
1210-6820	C510 CONNECTOR	5	Connector	0,33	C510	2010	Xperia öncesi yeniler
1210-6987	IND WW 10.0UH +/-20%4.0	5	Ind WW 10.0 uH +/-20% 4.0#4.0#1.2mm	0,09			eski modeller
1210-7090	T700 FRAME PWB SUB	3	Frame PWB Sub Assembly	1,35	T700	2009	Xperia öncesi yeniler
1210-7097	T700 MCOMP SHEET BTOB	5	MComp Sheet B to B	0,015	T700	2009	Xperia öncesi yeniler
1210-7099	T700 FRAME CAMERA SUB	1	Frame Camera Sub Assembly	0,51	T700	2009	Xperia öncesi yeniler
1210-7103	T700 SCREW OTHER LEN:3.5 DIAM	16	Screw Other Len:3.5 Diam:1.4 M	0,015	T700	2009	Xperia öncesi yeniler
1210-7277	T700 COVER M2 SILVER	6	Cover M2 Silver	0,075	T700	2009	Xperia öncesi yeniler
1210-7398	T700 WIN.OTHER PIC.LIGHT SILVE	3	Window Other Picture Light Silver	0,135	T700	2009	Xperia öncesi yeniler
1210-7403	T70 FOIL ADH. DOUBLE SIDE 0.0	5	Foil Adhesive Double Side 0.0 mmWindow P	0,015			eski modeller
1210-7410	G705 MICROPHONE	8	Microphone	0,48	G705	2010	Xperia öncesi yeniler
1210-7413	T700 GRILL SPEAKER SILVER	9	Grill Speaker Silver	0,12	T700	2009	Xperia öncesi yeniler
1210-7829	W760 LCD DRIVER SHIM	5	LCD Driver Shim	0,12			eski modeller
1210-7834	4 GB MICRO SD	1	icro SD 4Gb	11,625			eski modeller
1210-7835	8 GB MICRO SD CARD	16	Micro SD 8Gb	27,585			eski modeller
1210-7840	W760 PORON CUSHION 2.36MM*8.5	5	Poron cushion - 2.36MMX8.5MMX5MM	0,015			eski modeller
1210-7880	T700 VOLUME KEY SILVER	18	Key Volume Silver	0,225	T700	2009	Xperia öncesi yeniler
1210-7884	T700 KEY CAMERA	3	Key Camera	0,375	T700	2009	Xperia öncesi yeniler
1210-7918	T700 KEYBOARD LATIN SILVER	3	Keyboard Latin Silver	2,355	T700	2009	Xperia öncesi yeniler
1210-7922	T700 CAP SCREW SILVER	7	Cap Screw Silver	0,06	T700	2009	Xperia öncesi yeniler
1210-7935	T700 CO-BRAND SILVER	127	Co-branding Generic Silver	0,075	T700	2009	Xperia öncesi yeniler
1210-7939	T700 KRH LABEL	50	Label Core Unit 0.0 mm x 0.0 mm (KRH-Lab	0,09	T700	2009	Xperia öncesi yeniler
1210-7941	T700 SCREW OTHER LEN:5.0 DIAM	110	Screw Other Len:5.0 Diam:1.7	0,015	T700	2009	Xperia öncesi yeniler
1210-7944	T700 BAT.COVER SILVER	4	Cover Battery Sub Assembly Silver	3,09	T700	2009	Xperia öncesi yeniler
1210-8132	T700 BAT.COVER BLACK	4	Cover Battery Sub Assembly Black	3,09	T700	2009	Xperia öncesi yeniler
1210-8137	T700 REAR COVER RED	7	Cover Rear Sub Assembly Red	3,555	T700	2009	Xperia öncesi yeniler
1210-8139	T700 COVER M2 RED	16	Cover M2 Red	0,075	T700	2009	Xperia öncesi yeniler
1210-8142	T700 GRILL SPEAKER BLACK	12	Grill Speaker Black	0,12	T700	2009	Xperia öncesi yeniler
1210-8144	T700 VOLUME KEY RED	8	Key Volume Red	0,225	T700	2009	Xperia öncesi yeniler
1210-8154	T700 KEYBOARD RED	3	Keyboard Latin Red	2,355	T700	2009	Xperia öncesi yeniler
1210-8155	T700 CAP SCREW RED	23	Cap Screw Red	0,06	T700	2009	Xperia öncesi yeniler
1210-8156	T700 CO-BRAND RED	9	Co-branding Generic Red	0,075	T700	2009	Xperia öncesi yeniler
1210-8839	C902 GASGET	590	Gasket Conductive Shild can grounding	0,015	C902	2010	Xperia öncesi yeniler
1210-9667	W595 CAMERA	2	Camera Assy	7,575	W595	2009	Xperia öncesi yeniler
1211-0473	C510 LCD	25	LCD	15,09	C510	2010	Xperia öncesi yeniler
1211-2095	C901 ANT. BT FLEX	1	Ant BT Flex Assy	0,18			eski modeller
1211-2099	W595 FRONT BLACK	13	Front Cover Ruby Black	4,8	W595	2009	Xperia öncesi yeniler
1211-2362	K330 KEYPAD GREEN	4	Keypad Latin Green	1,35			eski modeller
1211-2434	W595 DECO PLATE BLACK	6	Decoration Plate, Red	1,41	W595	2009	Xperia öncesi yeniler
1211-2904	W595 VOLUME KEY BLACK	19	Volume Key Black	0,3	W595	2009	Xperia öncesi yeniler
1211-2947	W595 KEYBOARD MAIN BLACK	10	Keyboard Main Latin Ruby Black	2,67	W595	2009	Xperia öncesi yeniler
1211-2953	W595 KEYBOARD NAVI BLACK	11	Keyboard Navigation Ruby Black	2,835	W595	2009	Xperia öncesi yeniler
1211-3673	W205 BALANCED FILTER	4	Balanced Filter	0,09	W205	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1211-4173	W595 BATTERY COVER BLACK	8	Battery Cover Black	0,72	W595	2009	Xperia öncesi yeniler
1211-4174	W595 CAP TOP BLACK	23	Cap Top Assy Ruby Black	0,63	W595	2009	Xperia öncesi yeniler
1211-4180	W595 REAR COVER BLACK	1	Rear Cover Assy Black	3,72	W595	2009	Xperia öncesi yeniler
1211-4192	W595 CAP BOTTOM BLACK	12	Cap Bottom Assy Ruby Black	0,825	W595	2009	Xperia öncesi yeniler
1211-6819	C901 ANTENNA MAIN FLEX	1	Antenna Main Flex	0,39			eski modeller
1211-6823	C901 LIGHT GUIDE FRONT	1	Light Guide Front	0,87			eski modeller
1211-6915	T707 UPPER FRONT SCREW	10	Upper front screw	0,015	T707	2009	Xperia öncesi yeniler
1211-7995	R300 VOLUME KEY BLACK	13	Volume Key Black	0,375			eski modeller
1211-7997	R300 VOLUME KEY SILVER	5	Volume Key Silver	0,375			eski modeller
1211-8286	S312 DIODE	4	Diode Protection 5, V SOD882	0,045	S312	2009	Xperia öncesi yeniler
1211-8762	W705 BATTERY COVER BROWN	7	Battery Cover Brown	2,16	W705 / W715	2010	Xperia öncesi yeniler
1211-8983	W705 NAVI KEY SILVER/GOLD	1	Key Navi Silver/Gold	2,625	W705 / W715	2010	Xperia öncesi yeniler
1211-9118	W705 KEYBOARD BROWN	2	Keyboard Latin Brown	1,845	W705 / W715	2010	Xperia öncesi yeniler
1211-9137	W705 CO-BRAND SILVER	1	Co-Branding Label Generic L-Silver	0,165	W705 / W715	2010	Xperia öncesi yeniler
1211-9666	W705 HINGE SLIDER SUB GOLD	2	Hinge Slider Sub Assembly Gold	12,18	W705 / W715	2010	Xperia öncesi yeniler
1211-9674	W705 KEY WALKMAN	5	Key Walkman	0,375	W705 / W715	2010	Xperia öncesi yeniler
1211-9677	W705 MCOMP SHEET SCREW BROWN	8	MComp Sheet Screw Brown	0,015	W705 / W715	2010	Xperia öncesi yeniler
1211-9908	G705 GASGET BB	5	Gasket BB	0,03	G705	2010	Xperia öncesi yeniler
1212-0887	W350 RECEIVER eski	5	Ear Speaker	0,57			eski modeller
1212-1597	C902 CARRIER FRAME SILVER	1	Carrier Frame Assembly Silver	4,575	C902	2010	Xperia öncesi yeniler
1212-1599	C902 ANTENNA COVER SILVER	13	Antenna Cover Assy Silver	2,385	C902	2010	Xperia öncesi yeniler
1212-1600	C902 BATTERY COVER SILVER BOND	15	Battery Cover Assy Silver	5,265	C902	2010	Xperia öncesi yeniler
1212-1601	C902 SCREW COVER SILVER BOND	52	Screw Cover Coated Siver	0,015	C902	2010	Xperia öncesi yeniler
1212-1663	C901 EARSPEAKER	1	Ear Speaker	0,63			eski modeller
1212-1725	K330 KEYPAD GOLD	3	Keypad Latin Gold	1,35			eski modeller
1212-1968	T707 SIM FPC PBA	10	SIM FPC PCBA	1,425	T707	2009	Xperia öncesi yeniler
1212-2350	C903 A-GPS PBA SHORT	1	A-GPS PBA short	8,805	C903	2010	Xperia öncesi yeniler
1212-4356	W595 PBA NAVIGATION	3	PBA Navigation	5,805	W595	2009	Xperia öncesi yeniler
1212-4663	C510 SHIELD CAN	5	Shield Can	0,03	C510	2010	Xperia öncesi yeniler
1212-4715	W350 GASKET RECEIVER	5	Gasket Earspeaker	0,015			eski modeller
1212-4945	C903 KEYBOARD BLACK	10	Keyboard Latin Black	1,14	C903	2010	Xperia öncesi yeniler
1212-4950	C903 NAVI KEY BLACK	11	Keyboard Latin Navigation Black	1,875	C903	2010	Xperia öncesi yeniler
1212-4961	C903 VOLUME KEY	12	Key volume	0,3	C903	2010	Xperia öncesi yeniler
1212-5033	C903 CAMERA KEY	13	Key Camera	0,33	C903	2010	Xperia öncesi yeniler
1212-5177	C903 SIM FLEX	3	SIM Flex Assy	2,355	C903	2010	Xperia öncesi yeniler
1212-5218	W205 CAMERA	3	Camera 1.3MPixel	4,425	W205	2009	Xperia öncesi yeniler
1212-5329	W205 MICROPHONE	16	Microphone SMD	0,255	W205	2009	Xperia öncesi yeniler
1212-5865	C510 SHIELD CAN	5	Shield Can,Cajsa	0,06	C510	2010	Xperia öncesi yeniler
1212-5866	C510 SHIELD CAN	5	Shield Can,Vera	0,03	C510	2010	Xperia öncesi yeniler
1212-5867	C510 ANTENNA CABLE	5	Antenna Cable	0,945	C510	2010	Xperia öncesi yeniler
1212-5870	C510 DOME FOIL MAIN	71	Main dome foil	0,525	C510	2010	Xperia öncesi yeniler
1212-6129	W595 TAPE NAV.LED	5	Tape Navigation LED	0,015	W595	2009	Xperia öncesi yeniler
1212-6588	CK15 CONN. REC.	5	Conn BtB Receptacle 50p AXE550124	0,27	CK15I		Xperia
1212-7792	T707 M2 CARD READER	3	M2 Card reader	0,24	T707	2009	Xperia öncesi yeniler
1212-7855	W595 LCD	3	Display 2.2 TFT	10,29	W595	2009	Xperia öncesi yeniler
1213-0288	T700 SPACER FRAME	5	Spacer Frame	0,03	T700	2009	Xperia öncesi yeniler
1213-0778	W995 CAMERA	11	Camera W995 8 MPixel CMOS	53,265	W995	2010	Xperia öncesi yeniler
1213-2063	C702 GASKET LOUDSPEAKER	5	Loudspeaker Gasket with adhesive	0,09			eski modeller
1213-2135	C702 GASKET RECEIVER	5	Receiver Gasket with adhesive	0,045			eski modeller
1213-2542	C903 KEY PLAY MODE	5	key play mode	0,3	C903	2010	Xperia öncesi yeniler
1213-4870	U10 PBA TOP	5	PBA Top	2,775	U10I	2010	Xperia öncesi yeniler
1213-5426	W380 VİBRATÖR	4	Vibrator	0,51			eski modeller
1213-6266	T700 M2 COVER BLACK	26	Cover M2 Black	0,075	T700	2009	Xperia öncesi yeniler
1213-6428	T700 VOLUME KEY BLACK	30	Key Volume Shining Black	0,225	T700	2009	Xperia öncesi yeniler
1213-6658	U10 EARSPEAKER	2	Ear Speaker 15.0 Rectangular	0,675	U10I	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1213-6873	T700 SCREW CAP BLACK	65	Cap Screw Shining Black	0,06	T700	2009	Xperia öncesi yeniler
1213-6928	T700 CO-BRAND BLACK	16	Co-branding Generic Shining Black	0,075	T700	2009	Xperia öncesi yeniler
1213-7719	U10 HINGE SLIDE	11	Hinge Slide Assembly	5,385	U10I	2010	Xperia öncesi yeniler
1213-7722	U10 KEYBOARD BLACK	4	Keyboard Latin Black	2,835	U10I	2010	Xperia öncesi yeniler
1213-7758	U10 LIGHT GUIDE KEYBOARD	3	Light Gu Keyboard	0,63	U10I	2010	Xperia öncesi yeniler
1213-7759	U10 COVER TOP REAR BLACK	7	Cover Top Rear Assembly Black	1,32	U10I	2010	Xperia öncesi yeniler
1213-7782	U10 COVER BOTTOM RIGHT BLACK	5	Cover Bottom Right Assembly Black	1,725	U10I	2010	Xperia öncesi yeniler
1213-7791	U10 BATTERY COVER BLACK	7	Cover Bottom Rear Assembly Black	2,37	U10I	2010	Xperia öncesi yeniler
1213-7846	BST-41 BATARYA	1	BST-41/Std Battery/Blister	22,5			eski modeller
1213-8214	T707 SHIELDING CAN	5	Vera shielding can lid	0,03	T707	2009	Xperia öncesi yeniler
1213-8279	T700 FRONT BLACK/SILVER	2	Front assembly Black/Silver	13,29	T700	2009	Xperia öncesi yeniler
1213-8280	T700 FRONT BLACK/RED	12	Front assembly Black/Red	13,29	T700	2009	Xperia öncesi yeniler
1213-9841	W595 CO BRAND BLACK	3	Co-Brand Lava Black	0,195	W595	2009	Xperia öncesi yeniler
1214-1440	T715 SUB PBA	2	PBA T715 Sub PBA AP2	5,865	T715	2009	Xperia öncesi yeniler
1214-1927	C510 CONN POGOPIN	5	Connector	0,255	C510	2010	Xperia öncesi yeniler
1214-3134	C510 ANTENNA TIGER 1	12	Antenna(tiger 1)	1,545	C510	2010	Xperia öncesi yeniler
1214-3162	C510 CAMERA	2	Camera	18,915	C510	2010	Xperia öncesi yeniler
1214-3220	C510 MAIN FPC WITH RECEIVER	6	Main FPC with receiver, vib and Flash LE	5,01	C510	2010	Xperia öncesi yeniler
1214-3276	C510 FPC WITH CAMERA KEY	8	FPC with camera key	2,685	C510	2010	Xperia öncesi yeniler
1214-5348	X10 BTB CONN.	5	BtB Connector 16p	0,195	X10I		Xperia
1214-6594	C903 KEYPAD FLEX	7	Keypad Flex Assy	2,295	C903	2010	Xperia öncesi yeniler
1214-6829	G705 SCREW 2,8 DIAM 1,4	27	Screw Other Len:2.8 Diam:1.4	0,015	G705	2010	Xperia öncesi yeniler
1214-7370	W705 BTB CONN	5	Conn BtB Receptacle 16p	0,195	W705 / W715	2010	Xperia öncesi yeniler
1214-7556	G705 CO-BRANDING GENERIC	30	Co-Branding Generic	0,18	G705	2010	Xperia öncesi yeniler
1214-7860	LT26 SCREW	50	Screw Len:2.0 Diam:1.4	0,015	LT26I		Xperia
1214-8996	C510 CAMERA SHIELD CAN	5	Camera Shield Can	0,06	C510	2010	Xperia öncesi yeniler
1214-9000	C510 CARRIER	3	Carrier	0,855	C510	2010	Xperia öncesi yeniler
1214-9013	C510 GASGET COND. KEYBOARD	5	Gasket Conductive Keyboard	0,03	C510	2010	Xperia öncesi yeniler
1214-9016	C510 GASGET CON.FRAME METAL	5	Gasket Conductive Frame metal	0,03	C510	2010	Xperia öncesi yeniler
1214-9027	C510 GASGET CON.SLIDER 1	5	Gasket Conductive Slider 1	0,03	C510	2010	Xperia öncesi yeniler
1214-9028	C510 GASGET CON.SLIDER 2	5	Gasket Conductive Slider 2	0,03	C510	2010	Xperia öncesi yeniler
1214-9032	C510 FRAME COVER BLACK	3	Frame Cover, Future Black	2,49	C510	2010	Xperia öncesi yeniler
1214-9042	C510 BACK COVER BLACK	1	Back Cover, Future Black	4,815	C510	2010	Xperia öncesi yeniler
1214-9051	C510 CO-BRANDING BLACK	17	Co-branding, Future Black	0,315	C510	2010	Xperia öncesi yeniler
1214-9054	C510 BATTERY COVER BLACK	10	Battery Cover, Future Black	0,825	C510	2010	Xperia öncesi yeniler
1214-9070	C510 M2 COVER BLACK	8	M2 cover, Future Black	0,195	C510	2010	Xperia öncesi yeniler
1214-9072	C510 SCREW CAP BLACK	21	Screw Cap, Future Black	0,345	C510	2010	Xperia öncesi yeniler
1214-9082	C510 CAMERA WINDOW BLUE	13	Camera Window, Blue	0,495	C510	2010	Xperia öncesi yeniler
1214-9088	C510 CAMERA KEY	6	Camera Key	0,315	C510	2010	Xperia öncesi yeniler
1214-9089	C510 VOLUME KEY	4	Volume Key	0,315	C510	2010	Xperia öncesi yeniler
1214-9103	C510 MAIN KEYBOARD BLACK	3	Main Keyboard, Latin, Future Black	2,43	C510	2010	Xperia öncesi yeniler
1214-9297	T715 SISTEM CONN.	27	Conn I/O Receptacle 12p	0,195	T715	2009	Xperia öncesi yeniler
1215-0116	T707 CAMERA (YENİ)	2	Camera Module 3.2 MPixel	7,245	T707	2009	Xperia öncesi yeniler
1215-0241	C901 KEY LATCH DUAL	1	Key Latch Dual Assy	0,225			eski modeller
1215-0623	W705 BATTERY COVER BLACK	3	Battery Cover Black	2,16	W705 / W715	2010	Xperia öncesi yeniler
1215-0639	W705 MCOMP SHEET SCREW BLACK	3	MComp Sheet Screw Black	0,015	W705 / W715	2010	Xperia öncesi yeniler
1215-0644	W705 HINGE SLIDER SUB SILVER	8	Hinge Slider Sub Assembly Silver	11,55	W705 / W715	2010	Xperia öncesi yeniler
1215-1195	C903 BATTERY COVER BLACK	7	Battery Cover Assy Black	7,44	C903	2010	Xperia öncesi yeniler
1215-1224	C903 FRONT FRAME COVER	3	Cover Front Assy	3,735	C903	2010	Xperia öncesi yeniler
1215-1225	C903 REAR SLIDER	4	Rear Assy Slider	2,685	C903	2010	Xperia öncesi yeniler
1215-1226	C903 HINGE SLIDER	3	Hinge Slider Assy	3	C903	2010	Xperia öncesi yeniler
1215-1227	C903 REAR COVER	19	Rear Cover Assy	2,94	C903	2010	Xperia öncesi yeniler
1215-2815	U1 RECEIVER FPC	2	FPC Receiver	6,81			eski modeller
1215-3039	W595 CO BRAND BLACK	5	Co-Brand Ruby Black	0,195	W595	2009	Xperia öncesi yeniler
1215-8291	C902 FRAME SILVER BOND	1	Frame Assy Silver	48,945	C902	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1215-9723	W705 KEY FLEX	7	Key flex module	2,34	W705 / W715	2010	Xperia öncesi yeniler
1215-9781	W995 KEY FLEX	9	Key Flex Assy	5,31	W995	2010	Xperia öncesi yeniler
1215-9794	W995 SIM FLEX	7	SIM Flex Assy	5,355	W995	2010	Xperia öncesi yeniler
1216-0601	W995 MAIN ANTENNA	2	Main Antenna	2,28	W995	2010	Xperia öncesi yeniler
1216-0602	W995 BT GPS ANTENNA	5	BT GPS Antenna	2,205	W995	2010	Xperia öncesi yeniler
1216-0615	W995 AUDIO JACK	8	Audio Jack	0,405	W995	2010	Xperia öncesi yeniler
1216-0971	U10 CAMERA 8 MP	2	Camera 8 MPixel CMOS	19,71	U10I	2010	Xperia öncesi yeniler
1216-1097	W595 ADH. SIDEKEY FPC	40	Adhesive Sidekey FPC	0,015	W595	2009	Xperia öncesi yeniler
1216-1263	W995 PBA NAVI KEY	3	PBA Navi key	4,575	W995	2010	Xperia öncesi yeniler
1216-3320	W995 SHIELD CAN LID	3	Shield Can Lid AGPS	0,03	W995	2010	Xperia öncesi yeniler
1216-3322	W995 SHIELD CAN VERA	3	Shield Can Lid VERA	0,045	W995	2010	Xperia öncesi yeniler
1216-3324	W995 SHIELD CAN	3	Shield Can Lid KAJSA	0,15	W995	2010	Xperia öncesi yeniler
1216-3326	W995 SHIELD CAN	3	Shield Can Lid WLAN	0,045	W995	2010	Xperia öncesi yeniler
1216-4337	W995 LCD	3	Display 2.55 TFT	19,65	W995	2010	Xperia öncesi yeniler
1216-5398	K330 CO BRAND BLACK	10	Co-Brand K330 Black	0,12			eski modeller
1216-6309	C903 A-GPS ANTENNA	3	A-GPS Antenna	0,33	C903	2010	Xperia öncesi yeniler
1216-7105	T707 KEYBOARD FPC	1	Keyboard FPC Assy	4,635	T707	2009	Xperia öncesi yeniler
1216-7478	C903 SIM HOLDER	3	SIM Holder	0,18	C903	2010	Xperia öncesi yeniler
1216-7947	C903 SCREW CAP SILVER	12	Screw Cap Silver	0,015	C903	2010	Xperia öncesi yeniler
1216-9053	T700 CUSHION MICROPHONE	12	Cushion microphone	0,015	T700	2009	Xperia öncesi yeniler
1216-9623	C903 CUSION SLIDER	3	Cusion Slider	0,06	C903	2010	Xperia öncesi yeniler
1216-9624	C903 CAMERA WINDOW	2	Camera Window	0,405	C903	2010	Xperia öncesi yeniler
1217-0449	T707 LIGHT GUIDE	1	Light Guide	2,025	T707	2009	Xperia öncesi yeniler
1217-0473	T707 UPPER INNER COVER	5	Upper inner Cover	2,13	T707	2009	Xperia öncesi yeniler
1217-0485	T707 LOWER INNER COVER	5	Lower inner Cover	1,905	T707	2009	Xperia öncesi yeniler
1217-0493	T707 VOLUME KEY	13	Volume key	0,24	T707	2009	Xperia öncesi yeniler
1217-0498	T707 GASGET SIM CONN	5	Gasket SIM connector	0,015	T707	2009	Xperia öncesi yeniler
1217-0499	T707 UPPER OUTER COVER BLACK	8	Upper outer Cover Black	4,86	T707	2009	Xperia öncesi yeniler
1217-0511	T707 LOWER OUTER COVER BLACK	3	Lower outer Cover Black	0,945	T707	2009	Xperia öncesi yeniler
1217-0516	T707 SCREW COVER LEFT	15	Screw Cover Left	0,165	T707	2009	Xperia öncesi yeniler
1217-0518	T707 SCREW COVER RIGHT	15	Screw Cover Right	0,165	T707	2009	Xperia öncesi yeniler
1217-0519	T707 KEYPAD BLACK	3	Keypad Latin Black	3,195	T707	2009	Xperia öncesi yeniler
1217-0520	T707 BATTERY COVER BLACK	5	Battery Cover Black	1,155	T707	2009	Xperia öncesi yeniler
1217-0789	T715 FPC H-H	6	H-H FPC	0,495	T715	2009	Xperia öncesi yeniler
1217-0790	T715 RECEIVER FPC	7	Receiver FPC	2,37	T715	2009	Xperia öncesi yeniler
1217-1425	U10 COVER BOTTOM LEFT BLACK	2	Cover Bottom Left Assembly Black	1,74	U10I	2010	Xperia öncesi yeniler
1217-1428	U10 KEY UP-DOWN BLACK	9	Key Up-Down Black	0,24	U10I	2010	Xperia öncesi yeniler
1217-1433	U10 CAMERA KEY BLACK	7	Key Camera Black	0,24	U10I	2010	Xperia öncesi yeniler
1217-1530	U10 LIGHT GUIDE PROXIMITY	3	Light Gu Proximity Assembly	0,06	U10I	2010	Xperia öncesi yeniler
1217-1653	C510 GASGET CON.ANTENNA	5	Gasket Conductive antenna	0,015	C510	2010	Xperia öncesi yeniler
1217-1655	C510 GASGET MAIN FPC	5	main FPC BtoB Gasket	0,015	C510	2010	Xperia öncesi yeniler
1217-1664	C510 SIM CARD TAPE	5	SIM card tape	0,015	C510	2010	Xperia öncesi yeniler
1217-1683	C510 GASGET MAIN CAMERA	5	Main camera BtoB Gasket	0,015	C510	2010	Xperia öncesi yeniler
1217-1748	C510 FRAME SILVER	2	Frame Cover, Radiation Silver	3,255	C510	2010	Xperia öncesi yeniler
1217-1755	C510 MAIN KEYBOARD SILVER	6	Main Keyboard, Latin, Radiation Silver	2,295	C510	2010	Xperia öncesi yeniler
1217-1759	C510 M2 COVER SILVER	5	M2 cover, Radiation Silver	0,03	C510	2010	Xperia öncesi yeniler
1217-1815	C510 CAMERA WINDOW GREY	3	Camera Window, Dark grey	0,495	C510	2010	Xperia öncesi yeniler
1217-1823	C510 BACK COVER SILVER	9	Back Cover, Radiation Silver	0,705	C510	2010	Xperia öncesi yeniler
1217-1844	C510 CO BRAND SILVER	4	Co-branding, Radiation Silver	0,315	C510	2010	Xperia öncesi yeniler
1217-1856	C510 SCREW CAP SILVER	8	Screw Cap, Radiation Silver	0,06	C510	2010	Xperia öncesi yeniler
1217-1861	C510 BATTERY COVER SILVER	5	Battery Cover, Radiation Silver	0,12	C510	2010	Xperia öncesi yeniler
1217-2692	G502 BATTERY COVER	3	Cover Plastic Emilie Battery cover assy	1,17	G502	2009	Xperia öncesi yeniler
1217-2760	T707 MAIN LCD	18	Main LCD	13,02	T707	2009	Xperia öncesi yeniler
1217-2775	U1 LCD	1	Display 3.47 TFT	41,535			eski modeller
1217-3558	C903 ADH. NAVI PBA	2	Adhesive Navi PBA	0,06	C903	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1217-3648	U10 CAMERA WINDOW	2	Window Camera	0,93	U10I	2010	Xperia öncesi yeniler
1217-4016	W350 TAPE PROTECTIVE	10	Protective tape	0,015			eski modeller
1217-4523	W995 HINGE SLIDER	4	Hinge Silder Assembly	8,085	W995	2010	Xperia öncesi yeniler
1217-5398	T707 MAIN BT ANTENNA SPEAKER	2	Main&BT Antenna Box with speaker	1,515	T707	2009	Xperia öncesi yeniler
1217-5443	W995 LIGHT GUIDE	19	Light Guide	0,69	W995	2010	Xperia öncesi yeniler
1217-5607	U10 NET EARSPEAKER	3	Net Earspeaker	0,255	U10I	2010	Xperia öncesi yeniler
1217-5870	U10 CAMERA WINDOW FOIL	3	Foil Camera Window	0,135	U10I	2010	Xperia öncesi yeniler
1217-6107	U10 SCREW RECESS BIRIDGE	5	Screw recess bridge	0,045	U10I	2010	Xperia öncesi yeniler
1217-9902	WT13 BTB CONN.	5	BtB Connector	0,135	WT13I		Xperia
1218-0453	W995 CARRIER HOLDER	5	Carrier Holder VT Cam	0,03	W995	2010	Xperia öncesi yeniler
1218-0491	W995 CARRIER HOLDER SIM	3	Carrier Holder SIM	0,06	W995	2010	Xperia öncesi yeniler
1218-0502	W995 CUSHION	3	Cushion 0.0 VT Cam	0,015	W995	2010	Xperia öncesi yeniler
1218-0519	W995 GASGET FLASH	5	Gasket Flash	0,03	W995	2010	Xperia öncesi yeniler
1218-0522	W995 ADHESİVE	5	ADHESIVE (HP Jack)	0,015	W995	2010	Xperia öncesi yeniler
1218-0672	W995 PANEL KEY DUMMY BLACK	20	Panel Key Dummy Black	0,06	W995	2010	Xperia öncesi yeniler
1218-0675	W995 NET SPEAKER	16	Net Speaker Top Black	0,285	W995	2010	Xperia öncesi yeniler
1218-0682	W995 NET SPEAKER BOTTOM BLACK	12	Net Speaker Bottom Black	0,285	W995	2010	Xperia öncesi yeniler
1218-0687	W995 GRILL SPEAKER TOP	7	Grill Speaker Top	0,27	W995	2010	Xperia öncesi yeniler
1218-0694	W995 GRILL SPEAKER BOTTOM	17	Grill Speaker Bottom	0,285	W995	2010	Xperia öncesi yeniler
1218-0709	W995 SIDE KEY BLACK	23	Key Side Black	0,615	W995	2010	Xperia öncesi yeniler
1218-0893	W995 CAMERA KEY BLACK	8	Key Camera Black	0,465	W995	2010	Xperia öncesi yeniler
1218-0911	W995 KEY NAVI BLACK	5	Key Navi Black	3,285	W995	2010	Xperia öncesi yeniler
1218-0919	W995 NUM.KEYPAD SILVER	105	Keyboard Latin Silver	3,015	W995	2010	Xperia öncesi yeniler
1218-0949	W995 CAP SCREW LOWER BLACK	71	Cap Screw Lower Black	0,03	W995	2010	Xperia öncesi yeniler
1218-0965	W995 CAP SCREW UPPER	34	Cap Screw Upper	0,015	W995	2010	Xperia öncesi yeniler
1218-1007	W995 LABEL CO-BRAND BLACK	16	Label Co-Branding Generic Black	0,075	W995	2010	Xperia öncesi yeniler
1218-3960	J105 CONN ZIF FPC	4	Conn ZIF FPC Receptacle 23p	0,24	J105I	2009	Xperia öncesi yeniler
1218-5011	U10 SLIDER FPC	2	Slider FPC Assy	4,68	U10I	2010	Xperia öncesi yeniler
1218-5012	U10 KEYBOARD FPC	11	Keyboard FPC Assy	6,315	U10I	2010	Xperia öncesi yeniler
1218-6182	C510 FRONT BLACK	1	Front Cover Assy, Future Black	4,965	C510	2010	Xperia öncesi yeniler
1218-6185	C510 FRONT SILVER	9	Front Cover Assy, Radiation Silver	4,965	C510	2010	Xperia öncesi yeniler
1218-7159	U10 CAMERA COVER WINDOW	11	Cover Camera Window	0,33	U10I	2010	Xperia öncesi yeniler
1218-7946	U1 WINDOW MAIN DISPLAY	1	Window Main Display	14,415			eski modeller
1218-8458	T707 HINGE	10	Hinge	0,51	T707	2009	Xperia öncesi yeniler
1218-9713	E15 VİBRATOR	5	Vibrator	0,6	E15I		Xperia
1219-0066	U10 KRH LABEL	20	Core unit label	0,075	U10I	2010	Xperia öncesi yeniler
1219-0455	U10 SCREW 4,85 - 1,6	17	Screw Torx 5IP Len:4.85 Diam:1.6	0,015	U10I	2010	Xperia öncesi yeniler
1219-0474	U10 SCREW 2,5 - 1,6	20	Screw Other Len:2.5 Diam:1.6	0,015	U10I	2010	Xperia öncesi yeniler
1219-0599	U10 NET MICROPHONE	5	Net Microphone	0,045	U10I	2010	Xperia öncesi yeniler
1219-0879	T715 LCD FRAME	2	LCD frame assy	4,815	T715	2009	Xperia öncesi yeniler
1219-0884	T715 LIGHT GUIDE NAV. DOME	5	Light Gu navigation dome assy	0,48	T715	2009	Xperia öncesi yeniler
1219-0889	T715 LIGHT GUIDE NUMERIC DOME	5	Light Gu numeric dome assy	0,48	T715	2009	Xperia öncesi yeniler
1219-0902	T715 KEYBOARD BLACK	4	Keyboard Latin Black	1,635	T715	2009	Xperia öncesi yeniler
1219-1051	T715 VOLUME KEY	5	Volume Key	0,345	T715	2009	Xperia öncesi yeniler
1219-1219	T715 LOWER REAR COVER	3	Lower Rear Cover Assy	2,85	T715	2009	Xperia öncesi yeniler
1219-1226	T715 LOWER FRONT	3	Lower Front Assy	5,145	T715	2009	Xperia öncesi yeniler
1219-1251	T715 CAMERA KEY	12	Camera Key	0,345	T715	2009	Xperia öncesi yeniler
1219-1285	T715 BOTTOM CO-BRAND PLATE SIL	2	Bottom co-brand plate assy Silver	0,48	T715	2009	Xperia öncesi yeniler
1219-1287	T715 TOP PLASTIC BLACK	12	Top Plastic assy Black	0,3	T715	2009	Xperia öncesi yeniler
1219-1313	T715 BAT. COVER SILVER	1	Battery Metal lid assy Silver	3,375	T715	2009	Xperia öncesi yeniler
1219-4974	U10 FOIL ADH. LCD	29	Foil Adhesive Display	0,255	U10I	2010	Xperia öncesi yeniler
1219-5232	W715 CO-BRAND BLACK	8	Co-Branding Label Generic Black	0,165	W705 / W715	2010	Xperia öncesi yeniler
1219-5595	W995 CUSHION CAM	5	Cushion Cam B to B	0,015	W995	2010	Xperia öncesi yeniler
1219-6789	J105 SYSTEM CONN.	64	System Connector	0,195	J105I	2009	Xperia öncesi yeniler
1219-7793	U10 CONN.BTB 30 PIN	5	Conn BtB Receptacle 30p PEW F4S H=1.2 mm	0,48	U10I	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1219-8198	U10 FOIL CAMERA RING	5	Foil Camera Ring	0,03	U10I	2010	Xperia öncesi yeniler
1219-8423	CK13 BATTERY CONN.	4	Battery Connector	0,21	CK13I		Xperia
1219-8461	W705 CO-BARAND SILVER	6	Co-Branding Label Generic M-Silver	0,165	W705 / W715	2010	Xperia öncesi yeniler
1219-8482	W705 NAVIKEY SILVER/BLACK	7	Key Navi Silver/Black	2,625	W705 / W715	2010	Xperia öncesi yeniler
1219-8546	W705 BATTERY COVER BLACK SILVE	1	Battery Cover Black with Silver	2,16	W705 / W715	2010	Xperia öncesi yeniler
1219-8607	E10 EARSPEAKER	123	Ear Speaker	0,525	E10I		Xperia
1220-0119	C903 LCD---YENI---	5	Display 2.41 A-SI TFT	16,875	C903	2010	Xperia öncesi yeniler
1220-0258	W302 WALKMAN KEY BLACK	5	Walkman key platinecrome (black)	0,345	W302	2009	Xperia öncesi yeniler
1220-0261	W302 REAR COVER WHITE (YENİ)	2	Rear cover assy white	1,335	W302	2009	Xperia öncesi yeniler
1220-0263	W302 ANTENNA MAIN STAMPED	8	Ant Main Stamped with plastic support	0,135	W302	2009	Xperia öncesi yeniler
1220-0574	J105 CAMERA SOCKET	5	Camera Socket	0,285	J105I	2009	Xperia öncesi yeniler
1220-0747	MT15 LED	4	LED Multi-color	0,165	MT15I		Xperia
1220-1093	W995 MCOMP SHEET FPC	5	MComp Sheet FPC Main	0,015	W995	2010	Xperia öncesi yeniler
1220-1112	W995 WM LABEL 10MM	14	WM Label 10mm Holo	0,225	W995	2010	Xperia öncesi yeniler
1220-1114	W995 BATTERY COVER BLACK	2	Cover Battery Black	5,07	W995	2010	Xperia öncesi yeniler
1220-1142	W995 WM LABEL 12 MM	11	WM Label 12mm Holo	0,225	W995	2010	Xperia öncesi yeniler
1220-1161	W995 COVER LOWER REAR SILVER	2	Cover Lower Rear Silver	8,295	W995	2010	Xperia öncesi yeniler
1220-1198	W995 BAT.COVER RED	2	Cover Battery Red	5,625	W995	2010	Xperia öncesi yeniler
1220-1216	W995 BATTERY COVER SILVER	1	Cover Battery Silver	5,625	W995	2010	Xperia öncesi yeniler
1220-1246	W995 PANEL KEY DUMMY SILVER	2	Panel Key Dummy Silver	0,075	W995	2010	Xperia öncesi yeniler
1220-1271	W995 KEY SIDE SILVER	3	Key Side Silver	0,615	W995	2010	Xperia öncesi yeniler
1220-1279	W995 CAMERA KEY SILVER	5	Key Camera Silver	0,465	W995	2010	Xperia öncesi yeniler
1220-1282	W995 KEY NAVI RED	1	Key Navi Red	3,36	W995	2010	Xperia öncesi yeniler
1220-1283	W995 NAVI KEY SILVER	8	Key Navi Silver	3,36	W995	2010	Xperia öncesi yeniler
1220-1285	W995 CAP SCREW LOWER SILVER	7	Cap Screw Lower Silver	0,03	W995	2010	Xperia öncesi yeniler
1220-1290	W995 COBRAND RED	5	Label Co-Branding Generic Red	0,075	W995	2010	Xperia öncesi yeniler
1220-1291	W995 LABEL CO-BRANDING SILVER	10	Label Co-Branding Generic Silver	0,075	W995	2010	Xperia öncesi yeniler
1220-1925	W995 SYSTEM CONN. COVER BLACK	12	Cover System Connector Black	0,12	W995	2010	Xperia öncesi yeniler
1220-1928	W995 COVER SISTEM CON. SILVER	6	Cover System Connector Silver	0,135	W995	2010	Xperia öncesi yeniler
1220-3227	W995 LIQUID INS.IND.	5	Liquid intrusion indicator	0,015	W995	2010	Xperia öncesi yeniler
1220-3717	LT15 MICRO SD CONN.	3	Micro SD connector	0,615	LT15I		Xperia
1220-4434	T715 ANTENNA SPEAKER BOX	3	Antenna&Speaker box assembly	1,515	T715	2009	Xperia öncesi yeniler
1220-7778	T715 LCD	2	Display 2.2 TFT	10,71	T715	2009	Xperia öncesi yeniler
1220-8799	T707 HINGE CLIP	5	Hinge clip	0,03	T707	2009	Xperia öncesi yeniler
1220-9600	W302 SIM/M2 PBA	2	SIM/M2 pba assy	3,015	W302	2009	Xperia öncesi yeniler
1220-9816	W150 MICRO SD CONN.	3	Micro SD Connector	0,51	W150I	2011	Xperia öncesi yeniler
1221-0131	W350 BATTERY COVER ICE BLUE	3	Battery cover assy/Ice blue	1,365			eski modeller
1221-0139	W350 BAT.COVER ELK.BLACK	19	Battery cover assy/Electric black	1,38			eski modeller
1221-0462	F100 SİSTEM KONN.	3	System Connector	0,195			eski modeller
1221-1017	T707 ESD FABRIC FOR CAMERA	3	ESD Fabric for camera	0,06	T707	2009	Xperia öncesi yeniler
1221-1018	C510 SHAIDING TAPE FOR MAIN KE	5	Shading Tape for Main Keypad LED	0,015	C510	2010	Xperia öncesi yeniler
1221-2068	E10 CONN. ZIF 19P	5	Connector ZIF 19p	0,21	E10I		Xperia
1221-2326	T707 KEYPAD BLUE	1	Keypad Latin Blue	3,195	T707	2009	Xperia öncesi yeniler
1221-2371	T707 UPPER OUTER COVER BLUE	18	Upper outer Cover Blue	5,28	T707	2009	Xperia öncesi yeniler
1221-2395	T707 LOWER OUTER COVER BLUE	14	Lower outer Cover Blue	0,99	T707	2009	Xperia öncesi yeniler
1221-2411	T707 BATTERY COVER BLUE	4	Battery cover Blue	1,185	T707	2009	Xperia öncesi yeniler
1221-3351	T707 NET FABRIC RECEIVER BLUE	2	Net Fabric receiver Blue	0,015	T707	2009	Xperia öncesi yeniler
1221-3567	T715 BATTERY CONN.	5	Battery connector	0,21	T715	2009	Xperia öncesi yeniler
1221-6477	U10 CONN. COAX	4	Conn Coax Receptacle 0p test switch	0,105	U10I	2010	Xperia öncesi yeniler
1221-6481	ST15 CONN. ZIF 25P	5	Conn ZIF 25p	0,21	ST15I		Xperia
1221-6627	W580 ESD CLEANING BRUSH	3	ESD Cleaning Brush	4,92			eski modeller
1221-8480	C903 MAGNET	3	Magnet	0,15	C903	2010	Xperia öncesi yeniler
1221-8502	C903 KEY BAT.COVER	2	Key Battery Cover Latch	0,165	C903	2010	Xperia öncesi yeniler
1221-8503	C903 FLASH WINDOW	2	Flash Window	0,54	C903	2010	Xperia öncesi yeniler
1221-8506	C903 ANT BT	3	Ant BT	0,075	C903	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1221-8621	C903 RF PLUG	3	RF-plug	0,045	C903	2010	Xperia öncesi yeniler
1221-8627	C903 ADH. CAMERA	3	Adhesive Camera	0,015	C903	2010	Xperia öncesi yeniler
1222-0016	W705 FRONT COVER SILVER/SILVER	2	Cover Front Silver/Silver	11,16	W705 / W715	2010	Xperia öncesi yeniler
1222-0020	W715 FRONT COVER BLACK/BLACK	12	Cover Front Black/Black	11,16	W705 / W715	2010	Xperia öncesi yeniler
1222-1396	T715 CARD CONN. MICRO SD	3	Card Conn Micro SD push-push	0,435	T715	2009	Xperia öncesi yeniler
1222-1475	C903 CAPTON TAPE	5	Caption tape	0,015	C903	2010	Xperia öncesi yeniler
1222-1575	W995 MCOMP SHEET	5	MComp Sheet MP202	0,015	W995	2010	Xperia öncesi yeniler
1222-1769	C903 AGPS HEAT TRANSFER TAPE	5	AGPS Heat Transfer Tape	0,09	C903	2010	Xperia öncesi yeniler
1222-2187	U10 COVER BOTTOM RIGHT WHITE	2	Cover Bottom Right Assembly White	1,8	U10I	2010	Xperia öncesi yeniler
1222-2189	U10 COVER BOTTOM LEFT WHITE	2	Cover Bottom Left Assembly White	1,815	U10I	2010	Xperia öncesi yeniler
1222-2192	U10 COVER TOP FRONT WHITE	1	Cover Top Front Assembly White	4,155	U10I	2010	Xperia öncesi yeniler
1222-2195	U10 BATTERY COVER WHITE	4	Cover Bottom Rear Assembly White	2,565	U10I	2010	Xperia öncesi yeniler
1222-2399	W595 WALKMAN STICKER BLUE	9	Walkman Sticker, Active Blue	0,225	W595	2009	Xperia öncesi yeniler
1222-2414	W595 WALKMAN STICKER WHITE	8	Walkman Sticker, Cosmo White	0,225	W595	2009	Xperia öncesi yeniler
1222-3223	C510 SHADING TAPE	5	Shading Tape	0,015	C510	2010	Xperia öncesi yeniler
1222-3464	J105 SHIELD CAN LID	5	Shield Can Lid	0,075	J105I	2009	Xperia öncesi yeniler
1222-3534	WT19 ZIF CONN.17P	5	ZIF Connector 17p	0,255	W19I		Xperia
1222-5289	W20 BTB CONN. 20P	5	Conn BtB Receptacle 20p AXE520124	0,165	W20I	2011	Xperia öncesi yeniler
1222-5301	U20 EARSPEAKER	10	Ear Speaker	0,645	U20I	2011	Xperia öncesi yeniler
1222-5320	J105 LED WHITE	5	LED White Side 3.8x1.05x0.6 mm	0,105	J105I	2009	Xperia öncesi yeniler
1222-6125	W595 TAPE FOR DECO PLATE BLUE	10	Tape for Deco plate, Active Blue	0,015	W595	2009	Xperia öncesi yeniler
1222-7088	W705 KEYBOARD BLACK	2	Keyboard Latin Black	2,04	W705 / W715	2010	Xperia öncesi yeniler
1222-7501	J105 IND	5	Ind WW 4.7 uH +-20%	0,06	J105I	2009	Xperia öncesi yeniler
1222-7950	S312 SYSTEM CONN.	23	System Connector	0,15	S312	2009	Xperia öncesi yeniler
1222-7987	1 GB MICRO SD	1	Micro SD 1Gb	5,61			eski modeller
1222-8916	T707 SUB PCBAWITHOUT SUB CAMER	2	SUB PCBA without sub camera	4,335	T707	2009	Xperia öncesi yeniler
1222-9819	T707 GPS PCBA DUMMY BRACKET	4	GPS PCBA dummy Bracket	0,18	T707	2009	Xperia öncesi yeniler
1223-0254	W302 CARRIER METAL	11	Carrier metal	8,73	W302	2009	Xperia öncesi yeniler
1223-3084	ST25 LOUDSPEAKER	5	Loudspeaker 13.6 Rectangular	0,975	ST25I		Xperia
1223-4612	U10 DESK ST.DUAL CHARG.WHITE	1	Desk Stand Dual Charging Luminous White	3,075	U10I	2010	Xperia öncesi yeniler
1223-5020	W995 SCREW	52	Screw Other Len:2.7 Diam:1.4	0,015	W995	2010	Xperia öncesi yeniler
1223-5057	W995 SCREW	46	Screw Other Len:1.6 Diam:1.4	0,015	W995	2010	Xperia öncesi yeniler
1223-5090	W995 KEYBOARD RED	2	Keyboard Latin Red	3,075	W995	2010	Xperia öncesi yeniler
1223-6035	T707 MAIN WINDOW GLOBAL	5	Main window assy(no qcif hole)Global	3,165	T707	2009	Xperia öncesi yeniler
1223-6140	T707 BATTERY COVER ROSE	3	Battery cover Rose	1,215	T707	2009	Xperia öncesi yeniler
1223-6144	X10 SCREW 4,5 - 1,7	47	Screw Other Len:4.5 Diam:1.7	0,015	X10I		Xperia
1223-6186	T707 UPPER OUTER COVER ROSE	12	Upper outer Cover Rose	5,28	T707	2009	Xperia öncesi yeniler
1223-6195	T707 NET FABRIC RECEIVER ROSE	8	Net Fabric receiver Rose	0,015	T707	2009	Xperia öncesi yeniler
1223-6198	T707 KEYPAD ROSE	1	Keypad Latin Rose	3,195	T707	2009	Xperia öncesi yeniler
1223-6264	X10 LCD	6	Display 4.0 TFT	50,625	X10I		Xperia
1223-6977	J105 KEYBOARD SILVER	3	Keyboard Latin Vapour Silver	2,25	J105I	2009	Xperia öncesi yeniler
1223-6982	J105 VOLUME KEY	12	Volume Key	0,18	J105I	2009	Xperia öncesi yeniler
1223-7000	J105 CAMERA WINDOW	4	Camera Window	0,21	J105I	2009	Xperia öncesi yeniler
1223-7712	X10 BTB CONN. 26 P	4	BtB Connector 26p	0,24	X10I		Xperia
1223-8345	J105 DOME SHEET	12	Domesheet	0,225	J105I	2009	Xperia öncesi yeniler
1223-8346	J105 RECEIVER BOX	27	Receiver Box Assy	0,675	J105I	2009	Xperia öncesi yeniler
1223-8454	U20 RF ANTENNA	5	RF Antenna QUAD 850/900/1800/1900/UMTS	1,53	U20I	2011	Xperia öncesi yeniler
1223-9123	J105 QCIF CAMERA GASGET	5	QCIF Camera Gasket	0,015	J105I	2009	Xperia öncesi yeniler
1223-9969	X10 CAMERA 8 MP	5	Camera 8 MPixel CMOS	18,27	X10I		Xperia
1224-0228	U1 BATTERY COVER RED	1	Battery Cover Sub Assy Red	1,365			eski modeller
1224-0652	X10 CONN. USB MIKRO	6	Conn USB micro B 0p front dip	0,195	X10I		Xperia
1224-0804	J105 MIC.	150	Mic 4.0 Electret	0,27	J105I	2009	Xperia öncesi yeniler
1224-1548	X10 SIM AND MICRO SD FPC	5	SIM and MicroSD FPC	2,835	X10I		Xperia
1224-1571	X10 MAIN KEY FPC	9	Main Key FPC	1,62	X10I		Xperia
1224-1749	C903 BATTERY COV.BLACK CO BRAN	7	Batt Cover assy Black Co-brand	9,585	C903	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1224-3413	U10 DESK ST.DUAL CHARG.BLACK	2	Desk Stand Dual Charging Obsidian Black	3,075	U10I	2010	Xperia öncesi yeniler
1224-5383	J105 IC IF	5	IC IF	0,495	J105I	2009	Xperia öncesi yeniler
1224-7778	J10I2 LCD	13	2.2 TFT LCD	7,335	J10I2	2011	Xperia öncesi yeniler
1224-8749	J105 IC VOLTAGE	3	IC Voltage Regulator	0,3	J105I	2009	Xperia öncesi yeniler
1224-9062	X10 AUDIO JACK CONN.	8	Audio Jack Connector	0,405	X10I		Xperia
1224-9106	W995 CUSHION UPPER PBA	5	Cushion Upper PBA	0,075	W995	2010	Xperia öncesi yeniler
1224-9467	W995 SCREW	50	Screw M1.4 x 1.6 silver	0,015	W995	2010	Xperia öncesi yeniler
1224-9689	ST18 CONN.BTB 34 P	3	Conn BtB Receptacle 34p Panasonic A4S	0,315	ST18I		Xperia
1225-0025	E15 FPC CONN. 23P	5	Conn FPC 23p	0,24	E15I		Xperia
1225-0982	C903 AGPS PBA LONG	3	A-GPS PBA long	9,885	C903	2010	Xperia öncesi yeniler
1225-1055	LT15 CONN. OTHER REC.12P	10	Conn Other Receptacle 12p	0,405	LT15I		Xperia
1225-1653	U10 CARD CONN. MICRO SD	2	Card Conn Micro SD height 2.85 mm	0,27	U10I	2010	Xperia öncesi yeniler
1225-2035	W995 MCOMP SHEET	5	MComp Sheet shade camera led	0,015	W995	2010	Xperia öncesi yeniler
1225-2078	W995 FRONT SILVER	4	Front Cover Assy Silver	13,32	W995	2010	Xperia öncesi yeniler
1225-2083	W995 FRONT BLACK	7	Front Cover Assy Black	13,41	W995	2010	Xperia öncesi yeniler
1225-2087	W995 FRONT RED	1	Front Cover Assy Red	13,605	W995	2010	Xperia öncesi yeniler
1225-5033	U5 USB MICRO CONN.	6	Conn USB micro B Receptacle 5p	0,24	U5I		Xperia öncesi yeniler
1225-5299	W20 CONN.BTB REC.30P	5	Conn BtB Receptacle 30p P4S, h=1.5mm	0,195	W20I	2011	Xperia öncesi yeniler
1225-5461	X10 MAIN ANTENNA	11	Main Antenna	0,39	X10I		Xperia
1225-5463	X10 ANTENNA SPEAKER BOX NON CE	15	Non-Celler Antenna Speaker Box	1,125	X10I		Xperia
1225-5520	W20 CARD CONN. MICRO SD	5	Card Conn Micro SD	0,345	W20I	2011	Xperia öncesi yeniler
1225-6043	T707 WATERPROF TAPE	10	Waterproof tape	0,015	T707	2009	Xperia öncesi yeniler
1225-6047	T707 GASGET LCD	10	Gasket LCD connector for no sub camera	0,015	T707	2009	Xperia öncesi yeniler
1225-6731	MH300 PHF	2	HF Wired Portable PHF Stereo MH300 Black	3,525			eski modeller
1225-7407	J10I2 CAMRA 5 MP	3	Camera 5 MPixel	11,79	J10I2	2011	Xperia öncesi yeniler
1225-7424	E10 CAMERA 5MP	2	Camera 5 MPixel	13,62	E10I		Xperia
1225-8165	E10 LCD	6	Display 2.55 TFT	12,615	E10I		Xperia
1225-9041	W995 WINDOW MAIN CAMERA	23	Window Main Camera	0,285	W995	2010	Xperia öncesi yeniler
1225-9043	W995 WINDOW FLASH	3	window flash	0,255	W995	2010	Xperia öncesi yeniler
1225-9982	X10 COVER MICRO USB BLACK	6	Cover Micro USB Black	0,495	X10I		Xperia
1226-0053	X10 KEY ONOF BLACK	6	Key On/Off Metallic-Black	0,18	X10I		Xperia
1226-0066	X10 KEY MAIN BLACK	7	Key Main Metallic-Black	0,495	X10I		Xperia
1226-0419	X10 MAIN KEY FRAME	4	Main Key Frame	2,97	X10I		Xperia
1226-0424	X10 FRAME SUB	3	Frame Sub Assembly	2,085	X10I		Xperia
1226-0436	X10 ADHESIVE FRAME SUB	32	Adhesive Frame Sub Assembly	0,42	X10I		Xperia
1226-0523	X10 REAR COVER BLACK	8	Rear Cover Assembly Metallic-Black	5,79	X10I		Xperia
1226-1046	HPM-78 BLACK	3	MH100 HPM-78 PHF Stereo Black	3,255			eski modeller
1226-2115	U10 BATTERY COVER BLACK	8	Cover Bottom Rear Recessed Assy Black	2,37	U10I	2010	Xperia öncesi yeniler
1226-2118	U10 BATTERY COVER WHITE	2	Cover Bottom Rear Recessed Assy White	2,565	U10I	2010	Xperia öncesi yeniler
1226-2133	J10I2 INPUT SWITCH	5	Input Switch Side Push	0,225	J10I2	2011	Xperia öncesi yeniler
1226-2606	X10 VOLUME KEY BLACK	10	Key Volume Metallic-Black	0,345	X10I		Xperia
1226-2614	X10 CAMERA KEY BLACK	12	Key Camera Metallic-Black	0,285	X10I		Xperia
1226-2616	X10 KRH LABEL	220	Core Unit Label	0,075	X10I		Xperia
1226-2624	X10 BATTERY COVER BLACK	14	Battery Cover Co-brand Pocket Black	2,1	X10I		Xperia
1226-2653	X10 COVER SENSOR	3	Cover Sensor	1,44	X10I		Xperia
1226-2691	X10 AUDIO JACK HOLDER	7	Audio Jack Holder	0,165	X10I		Xperia
1226-2702	X10 CONDUCTIVE GASGET	5	Conductive Gasket	0,03	X10I		Xperia
1226-3301	J105 KEYBOARD RED	8	Keyboard Latin Ginger Red	2,25	J105I	2009	Xperia öncesi yeniler
1226-3534	MH500 PHF	11	HF Wired MH500 Entry PHF Light Silver 3	4,26			eski modeller
1226-3971	X10 BATTERY COVER BLACK *GEÇER	15	Battery Cover Black	2,13	X10I		Xperia
1226-4176	MT15 CONN. POGO PIN 5P	2	Conn Pogopin 5p	0,465	MT15I		Xperia
1226-4760	U5 MAIN ANTENNA	2	Main antenna	0,75	U5I		Xperia öncesi yeniler
1226-5144	J10I2 SİSTEM KONN.	15	System Connector	0,36	J10I2	2011	Xperia öncesi yeniler
1226-5359	J105 CARRIER FRAME	5	Carrier Frame Assy	1,395	J105I	2009	Xperia öncesi yeniler
1226-5364	J105 BAT. COVER RED	13	Battery Cover Ginger Red, Generic	1,02	J105I	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1226-5365	J105 BAT. COVER BLACK	7	Battery Cover Black, Generic	0,99	J105I	2009	Xperia öncesi yeniler
1226-6377	J105 RECEIVER BOX GASGET	20	Receiver Box Gasket	0,03	J105I	2009	Xperia öncesi yeniler
1226-7037	U5 KEY FPC	3	Key FPC Assembly	7,68	U5I		Xperia öncesi yeniler
1226-7065	J105 SPEAKER MESH	5	Speaker Mesh	0,045	J105I	2009	Xperia öncesi yeniler
1226-7255	LT15 EARSPEAKER	64	Ear Speaker	1,005	LT15I		Xperia
1226-7653	U5 RECEIVER FPC	3	Receiver FPC Assembly	2,715	U5I		Xperia öncesi yeniler
1226-9295	CCR-80 MICRO SD MEMORY ADAPTER	1	CCR-80 micro SD memory adapter, black	3,51			eski modeller
1226-9432	CCR-80 MICRO SD ADAPTER	1	CCR-80 micro SD memory adapter, silver	3,915			eski modeller
1227-0024	U5 RF CABLE	14	RF Cable	0,765	U5I		Xperia öncesi yeniler
1227-0046	U10 CARRIER INNER	3	Carrier Inner Assembly	4,065	U10I	2010	Xperia öncesi yeniler
1227-0048	U10 LIGHT GU FLASH	6	Light Gu Flash	0,18	U10I	2010	Xperia öncesi yeniler
1227-0117	U5 ANTENNA FPC	6	Antenna FPC Assembly	0,645	U5I		Xperia öncesi yeniler
1227-0125	W995 MCOMP SHHET CAM.KEY	5	MComp Sheet Camera Key	0,015	W995	2010	Xperia öncesi yeniler
1227-0424	J10I2 RECEIVER FPC	1	Receiver FPC	0,87	J10I2	2011	Xperia öncesi yeniler
1227-0853	U10 CAP ANTENNA BLACK	5	Cap Antenna Connector Black	0,075	U10I	2010	Xperia öncesi yeniler
1227-1092	U5 TOUCH PANEL	2	Touch Panel	14,25	U5I		Xperia öncesi yeniler
1227-2461	U5 PANEL ADH. LEFT	1	Foil Adhesive Double Side Panel Left	0,075	U5I		Xperia öncesi yeniler
1227-2470	U5 PANEL ADH. RIGHT	1	Foil Adhesive Double Side Panel Right	0,09	U5I		Xperia öncesi yeniler
1227-2476	U5 ONOF KEY	1	Key On/Off	0,285	U5I		Xperia öncesi yeniler
1227-2716	ST25 SCREW	25	Screw Other Len:4.0 Diam:1.4	0,015	ST25I		Xperia
1227-3532	R800 CARD CONN.SIM	1	Card Conn SIM push-pull w/switch	0,255			eski modeller
1227-3739	EP300 CHARGER	5	Charger EP300 EU-version	1,98			eski modeller
1227-4003	J20 CAMERA SOCKET	3	Cam Socket	0,39	J20I	2011	Xperia öncesi yeniler
1227-5113	E10 FRONT BLACK	1	Cover Front Black	24,39	E10I		Xperia
1227-5395	E10 INNER FRAME	16	Inner Frame	2,64	E10I		Xperia
1227-5443	E10 CO BRAND BLACK	10	Co-Brand Black	0,06	E10I		Xperia
1227-5446	E10 BACK COVER BLACK	5	Cover Back Black	1,44	E10I		Xperia
1227-5973	C903 FOIL CAMERA FPC TAPE	5	Foil 0.0 mmCamera FPC Tape	0,015	C903	2010	Xperia öncesi yeniler
1227-6382	E10 USB CAP	5	Cap USB	0,075	E10I		Xperia
1227-6706	E10 CAMERA WINDOW	5	Window Camera	0,405	E10I		Xperia
1227-6707	E10 CAMERA GASGET	3	Gasket Camera	2,64	E10I		Xperia
1227-6754	E10 LCD SUPPORT	3	Support LCD	0,87	E10I		Xperia
1227-6756	E10 CLIP EARSPEAKER CONTACT	5	Clip Earspeaer contact	0,075	E10I		Xperia
1227-6777	E10 KRH LABEL	20	Label MobilePhone	0,075	E10I		Xperia
1227-6784	E10 SCREW 3,5 X 3,0 M1,4	41	Screw Torx 3.55x3.0 M1.4	0,015	E10I		Xperia
1227-6788	E10 SCREW 3,5 X 3,0	36	Screw Torx 3.5x3.0	0,015	E10I		Xperia
1227-7106	E10 MIC. GASGET	10	Gasket Mic	0,09	E10I		Xperia
1227-7928	U5 PANEL SIDE RIGHT BLUE	1	Panel Side Right Sub Assembly Blue	2,37	U5I		Xperia öncesi yeniler
1227-8211	U20 LCD	11	Display 2.55 TFT QVGA	11,49	U20I	2011	Xperia öncesi yeniler
1227-8348	E10 MIC. CHANNEL GASGET	10	Gasket Mic Channel	0,105	E10I		Xperia
1227-8469	T715 UPPER FRONT SILVER	3	Upper Front Cover Assy Silver	10,95	T715	2009	Xperia öncesi yeniler
1227-8701	E10 LOUDSPEAKER GASGET	10	Gasket Loudspeaker	0,015	E10I		Xperia
1227-8702	E10 EARSPEAKER GASGET	10	Gasket Earspeaker	0,015	E10I		Xperia
1227-9587	J105 LCD	16	Main Display	9,975	J105I	2009	Xperia öncesi yeniler
1228-1759	ST23 VIBRATOR	4	Vibrator	0,69	ST23I		Xperia
1228-1893	J10I2 LOUDSPEAKER	8	Loudspeaker	1,245	J10I2	2011	Xperia öncesi yeniler
1228-1938	J10I2 DOME SHEET	5	Keypad dome sheet	0,015	J10I2	2011	Xperia öncesi yeniler
1228-1955	J10I2 CAMERA KEY FPC	5	Camera Key FPC Assembly	0,42	J10I2	2011	Xperia öncesi yeniler
1228-2364	U20 HALT TO HALF PBA FLEX	1	PBA H2H Flex	6,675	U20I	2011	Xperia öncesi yeniler
1228-2783	J20 CONN FPC 4P	5	Conn FPC 4p	0,18	J20I	2011	Xperia öncesi yeniler
1228-2940	J20 SUB KEYBOARD PBA	10	Sub Keyboard	3,84	J20I	2011	Xperia öncesi yeniler
1228-2974	E10 CONN I/O 7P	3	Conn I/O 7p 3.5mm AVP	0,375	E10I		Xperia
1228-2979	J20 MAIN FPC	16	Main FPC	1,89	J20I	2011	Xperia öncesi yeniler
1228-3107	J20 MAIN CAMERA KEY FPC	1	Main Camera Key FPC	0,585	J20I	2011	Xperia öncesi yeniler
1228-3136	E10 PROXI GASGET	10	Gasket Proxi	0,06	E10I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1228-3234	J20 CONN.FPC 67P	5	Conn FPC 67p	0,795	J20I	2011	Xperia öncesi yeniler
1228-3659	J105 FRONT SILVER	4	Front Cover Assy Vapour Silver Generic	4,14	J105I	2009	Xperia öncesi yeniler
1228-3674	J105 FRONT RED	8	Front Cover Assy Ginger Red Generic	4,14	J105I	2009	Xperia öncesi yeniler
1228-3692	J105 KEYPAD ADH. FOIL	3	Keypad Foil Adhesive	0,18	J105I	2009	Xperia öncesi yeniler
1228-3758	E10 CONN FPC 33 P	3	Conn FPC 33p	0,435	E10I		Xperia
1228-3791	U10 GASGET MICROPHONE	5	Gasket Microphone	0,075	U10I	2010	Xperia öncesi yeniler
1228-3973	E10 INPUT SWITCH	5	Input Switch side push dual	0,195	E10I		Xperia
1228-4744	U5 LCD	3	Display 3.2 TFT	22,14	U5I		Xperia öncesi yeniler
1228-4766	J20 RECEIVER	14	Receiver	0,615	J20I	2011	Xperia öncesi yeniler
1228-5530	J10I2 KEYBOARD BLACK	1	Keyboard Latin Black	1,905	J10I2	2011	Xperia öncesi yeniler
1228-5601	J10I2 CAMERA KEY SILVER	2	Camera Key Silver	0,225	J10I2	2011	Xperia öncesi yeniler
1228-5621	J10I2 CARRIER	5	Carrier Assy	1,86	J10I2	2011	Xperia öncesi yeniler
1228-5624	J10I2 VOLUME KEY SILVER	5	Volume Key Silver	0,15	J10I2	2011	Xperia öncesi yeniler
1228-5645	J10I2 SPEAKER MESH BLACK	6	Speaker Mesh Black	0,03	J10I2	2011	Xperia öncesi yeniler
1228-5652	J10I2 ANTENNA COVER BLACK	1	Anatenna cover Black	0,225	J10I2	2011	Xperia öncesi yeniler
1228-5707	J10I2 CO-BRAND BLACK	3	Co-brand Assy Black	0,195	J10I2	2011	Xperia öncesi yeniler
1228-5723	J10I2 BATTERY COVER SILVER	2	Battery Cover assy Silver	4,17	J10I2	2011	Xperia öncesi yeniler
1228-5864	J10I2 RECEIVER CARRIER FRAME	4	Receiver Carrier Frame	0,045	J10I2	2011	Xperia öncesi yeniler
1228-5929	J10I2 SCREW 4,5 X 1,4	20	Screw Len:4.5 Diam:1.4	0,015	J10I2	2011	Xperia öncesi yeniler
1228-8301	J10I2 SCREW 3,25 X 1,24	20	Screw Len:3.25 Diam:1.4	0,015	J10I2	2011	Xperia öncesi yeniler
1228-9120	U10 GASGET CAMERA TOP	5	Gasket Camera top	0,015	U10I	2010	Xperia öncesi yeniler
1228-9700	E10 BATTERY CONN. WTB	5	Conn WtB 3p Battery	0,18	E10I		Xperia
1229-0066	X10 COVER MICRO USB WHITE	10	Cover Micro USB White	0,54	X10I		Xperia
1229-0071	X10 ON-OFF KEY WHITE	2	Key On/Off Metallic-White	0,21	X10I		Xperia
1229-0072	X10 KEY MAIN WHITE	2	Key Main Metallic-White	0,375	X10I		Xperia
1229-0086	X10 VOLUME KEY WHITE	3	Key Volume Metallic-White	0,255	X10I		Xperia
1229-0119	X10 CAMERA KEY WHITE	6	Key Camera Metallic-White	0,21	X10I		Xperia
1229-0132	X10 BATTERY COVER WHITE **GEÇ*	8	Battery Cover White	2,235	X10I		Xperia
1229-0366	J105 FRAME MESH	2	Frame Mesh	0,015	J105I	2009	Xperia öncesi yeniler
1229-1390	E10 SIM FPC	3	SIM FPC	2,7	E10I		Xperia
1229-1842	E10 FLASH GASGET	10	Gasket Camera Flash	0,03	E10I		Xperia
1229-2161	U20 CARRIER PLASTIC QWERTY SUP	5	Carrier Plastic Qwerty Support Assembly	0,36	U20I	2011	Xperia öncesi yeniler
1229-2860	R800 RECEIVER PBA FLEX	2	PBA Receiver Flex	6,945			eski modeller
1229-3192	U10 LIQUID IND.	5	Liquid Intrusion Indicator	0,015	U10I	2010	Xperia öncesi yeniler
1229-3233	R800 PBA TOP KEYPAD FLEX	1	PBA Top Keypad Flex	1,515			eski modeller
1229-3662	U20 CAMERA 5 MP	5	Camera 5 MPixel	12,21	U20I	2011	Xperia öncesi yeniler
1229-3918	C903 NAVI KEY PBA	8	Navi Key PBA assy	8,625	C903	2010	Xperia öncesi yeniler
1229-4387	U20 EAR SPEAKER GASGET	9	Gasket Ear Speaker	0,03	U20I	2011	Xperia öncesi yeniler
1229-5900	J105 CAMERA FIVTIVE	4	Camera 2 MPixel CMOS MP revers	5,085	J105I	2009	Xperia öncesi yeniler
1229-6802	E10 RF CAP	9	Cap RF	0,06	E10I		Xperia
1229-7119	U10 COPPERTAPE SINGLE SIDE CON	5	Copper tape Single Side Conductive	0,075	U10I	2010	Xperia öncesi yeniler
1229-7650	E10 BATTERY CAP	6	Cap Battery	0,06	E10I		Xperia
1229-7662	E10 CONDUCTIVE GASGET 5,6X1,9	10	Gasket Conductive 5,6x1,9	0,51	E10I		Xperia
1229-7667	E10 CONDUCTIVE GASGET 3,1X2,0	10	Gasket Conductive 3,1x2,0	0,3	E10I		Xperia
1229-8389	U20 KEYBOARD	86	Keyboard Latin QWERTY	2,595	U20I	2011	Xperia öncesi yeniler
1229-8394	U20 KOYLOCK ON/OFF	5	Key lock/onoff	0,27	U20I	2011	Xperia öncesi yeniler
1229-8398	U20 CAMERA KEY BLACK	4	Camera Key Black	0,225	U20I	2011	Xperia öncesi yeniler
1229-8400	U20 VOLUME KEY BLACK	5	Volume Key Black	0,195	U20I	2011	Xperia öncesi yeniler
1229-8650	J105 LCD CONN. FOIL	5	LCD Connector Foil	0,015	J105I	2009	Xperia öncesi yeniler
1229-9358	U20 BATTERY COVER BLACK	11	Battery Cover Assembly Black	1,365	U20I	2011	Xperia öncesi yeniler
1229-9391	E10 SCREW 5,2X3,0 M1,4	32	Screw Torx 5.2x3.0 M1.4	0,015	E10I		Xperia
1229-9805	U20 PBA DOME COMPLETE	5	PBA Dome, Complete	3,795	U20I	2011	Xperia öncesi yeniler
1229-9998	U20 PLASTIC COVER PROXIMITY	10	Plastic Cover Proximity	0,09	U20I	2011	Xperia öncesi yeniler
1230-0894	E10 SIM FPC GASGET	10	Gasket SIM FPC	0,015	E10I		Xperia
1230-0897	E10 TOUCH FPC GASGET	10	Gasket Touch FPC	0,015	E10I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1230-1020	U20 HINGE	7	1Hinge assembly	4,725	U20I	2011	Xperia öncesi yeniler
1230-1227	U20 LOUDSPEAKER MESH	8	Loudspeaker Mesh	0,06	U20I	2011	Xperia öncesi yeniler
1230-1278	U20 PBA AVP	21	PBA AVP Assy	1,11	U20I	2011	Xperia öncesi yeniler
1230-1308	J10I2 SİM CARD CONN.	3	Card Conn SIM	0,195	J10I2	2011	Xperia öncesi yeniler
1230-1533	U20 FLASH LENS WINDOW	32	Flash Lens Window	0,105	U20I	2011	Xperia öncesi yeniler
1230-1685	U5 PANEL SIDE LEFT RUBY BLACK	2	Panel Side Left Sub Assembly Ruby	1,845	U5I		Xperia öncesi yeniler
1230-1871	U20 CONN. USB MIC. B REC. 5 P	28	Conn USB micro B Receptacle 5p Splash Pr	0,315	U20I	2011	Xperia öncesi yeniler
1230-2194	E10 LED RED/GREEN/BLUE	5	LED Red/Green/Blue	0,105	E10I		Xperia
1230-2269	E10 EARSPEAKER ADHESIVE	10	Adhesive Earspeaker	0,06	E10I		Xperia
1230-2848	W100 SIM CONN.	3	SIM Card Connector	0,285	W100I	2011	Xperia öncesi yeniler
1230-2857	W150 MICRO USB CONN.	2	Micro USB Connector	0,135	W150I	2011	Xperia öncesi yeniler
1230-3760	U20 MICRO SD CARD CONN.	4	Card Conn Micro SD	0,42	U20I	2011	Xperia öncesi yeniler
1230-3985	E10 FOIL INSULATION	10	Foil Insulation	0,015	E10I		Xperia
1230-4120	WT13 FPC CONN.	5	Connector FPC	0,21	WT13I		Xperia
1230-4736	E10 FOIL GROUNDING CAMERA	10	Foil Grounding Camera	0,015	E10I		Xperia
1230-5083	J20 UPPER FRONT BLACK	6	Upper Front Cover Black	4,425	J20I	2011	Xperia öncesi yeniler
1230-5139	J20 SUB KEYPAD BLACK	8	Sub Keypad Black	1,23	J20I	2011	Xperia öncesi yeniler
1230-5192	J20 SUB KEYPAD ADHESIVE	170	Sub keypad adhesive	0,195	J20I	2011	Xperia öncesi yeniler
1230-5537	J20 LOWER REAR COVER FRAME ANT	2	Lower Rear Cover Frame with ANT	1,995	J20I	2011	Xperia öncesi yeniler
1230-5539	J20 BAT.COVER SILVER	8	Battery Cover Silver	1,305	J20I	2011	Xperia öncesi yeniler
1230-5577	J20 SUB KEYBOARD DOME SHEET	52	Sub Keyboard Domesheet	0,165	J20I	2011	Xperia öncesi yeniler
1230-5720	J20 HINGE METAL SLIDE	8	Hinge Metal Slide	1,95	J20I	2011	Xperia öncesi yeniler
1230-5757	J20 UPPER REAR COVER	4	Upper Rear Cover	1,26	J20I	2011	Xperia öncesi yeniler
1230-5762	J20 LOWER FRONT COVER	5	Lower Front Cover	2,37	J20I	2011	Xperia öncesi yeniler
1230-5800	J20 KEYBOARD MAIN BLACK	6	Main Keypad Latin Black	1,11	J20I	2011	Xperia öncesi yeniler
1230-5803	J20 MAIN KEYPAD ADHESIVE	32	Main Keypad Adhesive	0,195	J20I	2011	Xperia öncesi yeniler
1230-5809	J20 VOLUME KEY	1	Volume Key	0,165	J20I	2011	Xperia öncesi yeniler
1230-5811	J20 CAMERA KEY MAIN	1	Main Camera Key	0,165	J20I	2011	Xperia öncesi yeniler
1230-5814	J20 CO-BRAND BLACK	5	Co Branding Black	0,465	J20I	2011	Xperia öncesi yeniler
1230-5819	J20 SCREW M1.6 X 2.5	46	Screw M1.6#2.5	0,015	J20I	2011	Xperia öncesi yeniler
1230-5821	J20 SCREW M1.7 X 4.0	89	Screw M1.7##4.0	0,015	J20I	2011	Xperia öncesi yeniler
1230-6138	J20 SPEAKER GASGET	10	Speaker Gasket	0,015	J20I	2011	Xperia öncesi yeniler
1230-6148	U20 CAMERA WINDOW	5	Camera Window	0,33	U20I	2011	Xperia öncesi yeniler
1230-6279	J20 SUB KEYBOARD FRAME	6	Sub Keyboard Frame	0,165	J20I	2011	Xperia öncesi yeniler
1230-6345	J20 SUB CAMERA FRAME	9	Sub Camera Frame	0,075	J20I	2011	Xperia öncesi yeniler
1230-6456	J105 CARD CONN. MICRI SD	6	Card Conn Micro SD	0,285	J105I	2009	Xperia öncesi yeniler
1230-6587	SK17 CAMERA 5.1 MP	6	Camera 5.1 MPixel CMOS	13,035	SK17I		Xperia
1230-6621	J20 DECO SHHET BLACK	10	Deco Sheet Black	0,54	J20I	2011	Xperia öncesi yeniler
1230-6681	J20 SCREW M1.4 X 2.0	66	Screw M1.4X2.0	0,015	J20I	2011	Xperia öncesi yeniler
1230-6816	W20 CAMERA 3MP	4	Camera 3 MPixel	5,94	W20I	2011	Xperia öncesi yeniler
1230-6823	WT13 CAMERA 3 MP	4	Camera 3 MPixel	6,21	WT13I		Xperia
1230-7005	U20 CARRIER METAL QWERTY SUPPO	7	Carrier Metal Qwerty Support Assy	7,89	U20I	2011	Xperia öncesi yeniler
1230-7899	J105 SPEAKER BOX	12	Speaker Box_Antenna Assy J105i	1,305	J105I	2009	Xperia öncesi yeniler
1230-8279	J20 RECEIVER GASGET	9	Receiver Gasket	0,015	J20I	2011	Xperia öncesi yeniler
1230-8287	J20 FOIL SIM CONN.	10	SIM Connector Foil	0,015	J20I	2011	Xperia öncesi yeniler
1230-8434	J20 GSGET LCD	10	Display Gasket	0,15	J20I	2011	Xperia öncesi yeniler
1230-8891	E15 CAVER REAR WHITE/SILVER	5	Cover Rear White/Silver	3,84	E15I		Xperia
1230-8897	U20 CAMERA GASGET	5	Camera Gasket	0,015	U20I	2011	Xperia öncesi yeniler
1230-8898	E15 SIDE KEYS	10	Keys Side	0,48	E15I		Xperia
1230-8927	E15 USB CAP WHITE	3	Cap USB White	0,705	E15I		Xperia
1230-8928	E15 KEYS FRONT	9	Keys Front	0,525	E15I		Xperia
1230-8938	E15 CARRIER LCM	4	Carrier LCM	3,57	E15I		Xperia
1230-8952	E15 WINDOW CAMERA	5	Window Camera	0,3	E15I		Xperia
1230-8955	E15 GROMMET MİK.	5	Grommet Mic	0,225	E15I		Xperia
1230-9135	MT15 CONNECTOR	1	Conn 0p	0,45	MT15I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1230-9478	W100 LCD	12	Main Display	9,9	W100I	2011	Xperia öncesi yeniler
1231-0078	R800 PBA ZEUS USB BOARD	1	PBA Zeus uSD Board	3,315			eski modeller
1231-0572	U8 LCD	1	Display 3.2 TFT	21,57			eski modeller
1232-1232	U20 KRH LABEL	50	Core unit label	0,0195	U20I	2011	Xperia öncesi yeniler
1231-2006	W20 LCD	12	Display 2.55 TFT	13,77	W20I	2011	Xperia öncesi yeniler
1231-4253	E15 DOME SHEET	9	Dome Sheet	0,12	E15I		Xperia
1231-4565	SK17 EAR SPEAKER	69	Ear Speaker 15.0 Rectangular	0,45	SK17I		Xperia
1231-4933	U8 TOUCH PANEL	5	Touch panel	11,85			eski modeller
1231-6484	MH810 HEADSET	2	MH810 Remote control headset Black	8,46			eski modeller
1231-6756	W20 HINGE FPC	63	Hinge FPC	1,62	W20I	2011	Xperia öncesi yeniler
1231-6758	W20 FPC MAIN CAM/SIDE KEY/VIB.	13	Main camera/side key/vib FPC	1,68	W20I	2011	Xperia öncesi yeniler
1231-6761	W20 MAIN KEYBOARD FPC	8	Main Keyboard FPC	1,62	W20I	2011	Xperia öncesi yeniler
1231-6763	W20 RECEIVER FPC	10	Receiver FPC	0,51	W20I	2011	Xperia öncesi yeniler
1231-7293	W20 SUB KEYBOARD PBA	17	Sub keyboard	2,535	W20I	2011	Xperia öncesi yeniler
1231-7464	E15 FRONT KEY ACTIVATOR	10	Front Key Activator	0,27	E15I		Xperia
1231-7483	E15 CLIP EAR SPEAKER	10	Clip Ear Speaker	0,075	E15I		Xperia
1231-9529	BST-43 BATARYA	18	BST-43/Acc//Blister/	22,5			eski modeller
1231-9755	E15 ADH. CAMERA WINDOW	10	Adhesive Camera Window	0,015	E15I		Xperia
1232-0434	W20 LOWER FRONT COVER	2	Lower Front Cover	0,825	W20I	2011	Xperia öncesi yeniler
1232-1333	W20 MAIN ANTENNA/SPEAKER BOX	40	Main antenna/Speaker box	1,365	W20I	2011	Xperia öncesi yeniler
1232-1334	W20 SIDE KEY BLACK	5	Side key Black	0,225	W20I	2011	Xperia öncesi yeniler
1232-1340	W20 LOWER REAR COVER BLACK	2	Lower Rear cover Black	1,635	W20I	2011	Xperia öncesi yeniler
1232-1342	W20 BATTERY COVER BLACK	1	Battery Cover Black	0,885	W20I	2011	Xperia öncesi yeniler
1232-1344	W20 SUB KEYPAD BLACK	6	Sub keypad Black	1,245	W20I	2011	Xperia öncesi yeniler
1232-1350	W20 MAIN KEYPAD BLACK	7	Main keypad Latin Black	1,245	W20I	2011	Xperia öncesi yeniler
1232-1355	W20 HINGE METAL SLIDER	5	Hinge Metal Slider	2,955	W20I	2011	Xperia öncesi yeniler
1232-1377	W20 UPPER FRONT BLACK	1	Upper Front cover Black	1,305	W20I	2011	Xperia öncesi yeniler
1232-1401	W20 DECORATION SHEET BLACK	20	Decoration sheet Black	0,24	W20I	2011	Xperia öncesi yeniler
1232-1405	W20 SUB KEYBOARD DOME	10	Sub keyboard Dome	0,39	W20I	2011	Xperia öncesi yeniler
1232-1412	W20 SIDE KEY FPC FILM	7	Side Key FPC Film	0,015	W20I	2011	Xperia öncesi yeniler
1232-1443	W20 KRH LABEL	50	Core Unit label	0,015	W20I	2011	Xperia öncesi yeniler
1232-1490	E15 SIM CONN.	10	Conn SIM	0,18	E15I		Xperia
1232-1629	E15 BATTERY CONN.	9	Connector Battery 5p	0,195	E15I		Xperia
1232-2092	U10 COPPER TAPE	25	Copper tape	0,06	U10I	2010	Xperia öncesi yeniler
1232-2804	U20 SCREW 5,5 X 1,4	26	Screw Philips Len:5.5 Diam:1.4	0,015	U20I	2011	Xperia öncesi yeniler
1232-2921	U20 SCREW 3,0 X 1,4	20	Screw Phillips Len:3.0 Diam:1.4	0,015	U20I	2011	Xperia öncesi yeniler
1232-3427	E15 SCREW 5,5 X 1,6	20	Screw Torx 5.5 x 1.6	0,015	E15I		Xperia
1232-5130	U20 FOIL ADH. DOUBLE SIDE	35	Foil Adhesive Double Side Conductive 0.0	0,015	U20I	2011	Xperia öncesi yeniler
1232-8155	U20 SCREW 1,6 X 1,4	15	Screw Philips Len:1.6 Diam:1.4 Screw M1,	0,015	U20I	2011	Xperia öncesi yeniler
1232-8169	U20 SCREW 5,0 X 1,6	20	Screw Torx T5 Len:5.0 Diam:1.6 No color	0,015	U20I	2011	Xperia öncesi yeniler
1232-8744	U20 FLASH LENS FOIL ADH.	42	Flash Lens Foil Adhesive	0,015	U20I	2011	Xperia öncesi yeniler
1233-0135	J20 INPUT SWITCH PUSH MAIN KEY	7	Input Switch Push Main key dome and ligh	0,405	J20I	2011	Xperia öncesi yeniler
1233-0163	U20 CO-BRAND BLACK	7	Cobrand label XPERIA/Black	0,06	U20I	2011	Xperia öncesi yeniler
1233-0248	E15 LOUDSPEAKER GASGET	65	Gasket Loudspeaker	0,015	E15I		Xperia
1233-0455	W20 MAIN KEYBOARD FPC BRACKET	5	Main Keyboard FPC Bracket	0,105	W20I	2011	Xperia öncesi yeniler
1233-1232	J20 DECO SHEET RED	14	Deco Sheet Red	0,54	J20I	2011	Xperia öncesi yeniler
1233-1838	J20 UPPER FRONT RED	1	Upper Front Cover Red	4,485	J20I	2011	Xperia öncesi yeniler
1233-2177	E10 CONDUCTIVE GASGET 3,8X2,3	10	Gasket Conductive 3,8x2,3	0,015	E10I		Xperia
1233-2431	W20 GASGET SUB KEYBOARD COND.	10	Sub keyboard conductive Gasket	0,015	W20I	2011	Xperia öncesi yeniler
1233-3259	W150 LCD	2	CPL_LCD TFT_Transmissive_240x320 Pixels_	13,2	W150I	2011	Xperia öncesi yeniler
1233-3562	U10 LCD FPC SPACER	5	LCD FPC spacer	0,075	U10I	2010	Xperia öncesi yeniler
1233-3738	W20 SCREW 1.5 X 1.4	49	Screw Other Len:1,5 Diam:1,4 (EG)	0,015	W20I	2011	Xperia öncesi yeniler
1233-3820	X10 SCREEN PROTECTION ET902	1	User Tool ET902 Screen protector	0,225	X10I		Xperia
1233-3960	E15 EARSPEAKER	42	Earspeaker	0,825	E15I		Xperia
1233-4628	R800 VOLUME KEY BLACK	3	Key Volume - Black	0,27			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1233-5757	W20 GASGET SIDE KEY FPC CON.	10	Side key FPC connector Gasket	0,015	W20I	2011	Xperia öncesi yeniler
1233-6330	J108 SIM CARD CONN.	5	Card Conn SIM	0,165	J108I	2010	Xperia öncesi yeniler
1234-0201	ST25 SCREW	50	Screw Torx Len:3.4 Diam:3.0	0,015	ST25I		Xperia
1234-0202	ST25 SCREW	25	Screw Torx Len:5.4 Diam:2.5	0,015	ST25I		Xperia
1234-0447	MW600 NLUETOOTH HEADSET	2	MW600/Exchange Unit/Black	26,4			eski modeller
1234-1552	J108 CONN FPC REC.23P	10	Conn FPC Receptacle 23p	0,255	J108I	2010	Xperia öncesi yeniler
1234-3324	U10 TOP PBA ADHESIVE	5	Top PBA adhesive	0,015	U10I	2010	Xperia öncesi yeniler
1234-3340	J108 CONN. AUDIO JACK REC.6P	9	Conn Audio Jack Receptacle 6p	0,165	J108I	2010	Xperia öncesi yeniler
1234-5088	LT15 CAMERA 8,1 MP	1	Camera 8.1 MPixel CMOS Module	19,005	LT15I		Xperia
1234-5247	J108 MICRO SD CARD CONN.	9	Card Conn Micro SD	0,495	J108I	2010	Xperia öncesi yeniler
1234-5250	LT15 FUSE	5	Fuse	0,03	LT15I		Xperia
1234-6192	W20 BATTERY CONN.	10	Battery Connector	0,24	W20I	2011	Xperia öncesi yeniler
1234-6589	J108 LCD	4	FICTIVE. Display 2.22 A-SI TFT	6,915	J108I	2010	Xperia öncesi yeniler
1234-7421	W150 SIM CARD CONN.	5	SIM Card Connector	0,18	W150I	2011	Xperia öncesi yeniler
1234-7424	W150 FPC CONN.13 P ZIFF	5	Conn FPC 13p ZIFF	0,21	W150I	2011	Xperia öncesi yeniler
1234-7425	W150 SPEAKER CONN.	5	Speaker Connector	0,045	W150I	2011	Xperia öncesi yeniler
1234-8905	J10I2 FRONT COVER BLACK	4	Front Cover Assy Black J10i	9,63	J10I2	2011	Xperia öncesi yeniler
1235-2727	E15 LCD	6	Display 3.0 TFT	23,355	E15I		Xperia
1235-3821	E10 MESH BACK COVER	3	Mesh Back Cover	0,195	E10I		Xperia
1235-4648	LT15 CONN. HDMI REC. 19P	10	Conn HDMI Receptacle 19p D-type, 2 DIP	0,555	LT15I		Xperia
1235-4804	W20 GASGET LCD	8	Display Gasket	0,165	W20I	2011	Xperia öncesi yeniler
1235-4806	W20 RECEIVER FILM	10	Receiver Film	0,015	W20I	2011	Xperia öncesi yeniler
1235-4807	W20 CO-BRAND BLACK	5	Co-Branding Generic Black	0,105	W20I	2011	Xperia öncesi yeniler
1235-4808	W20 CO-BRAND PINK	3	Co-Branding Generic Pink	0,12	W20I	2011	Xperia öncesi yeniler
1235-4809	W20 CO-BRAND SILVER	5	Co-Branding Generic Sliver	0,12	W20I	2011	Xperia öncesi yeniler
1235-4813	W20 MAIN KEYPAD PINK	2	Main keypad Latin Pink	2,49	W20I	2011	Xperia öncesi yeniler
1235-4818	W20 MAIN KEYPAD SILVER	4	Main keypad Latin Sliver	2,49	W20I	2011	Xperia öncesi yeniler
1235-4832	W20 SUB KEYPAD PINK	3	Sub keypad Pink	1,65	W20I	2011	Xperia öncesi yeniler
1235-4833	W20 SUB KEYPAD SILVER	3	Sub keypad Silver	1,65	W20I	2011	Xperia öncesi yeniler
1235-4838	W20 SIDE KEY PINK	1	Side key Pink	0,3	W20I	2011	Xperia öncesi yeniler
1235-4839	W20 SIDE KEY SILVER	3	Side key Silver	0,3	W20I	2011	Xperia öncesi yeniler
1235-4843	W20 UPPER FRONT PINK	1	Upper Front cover Pink	1,395	W20I	2011	Xperia öncesi yeniler
1235-4845	W20 UPPER FRONT SILVER	4	Upper Front cover Silver	1,455	W20I	2011	Xperia öncesi yeniler
1235-4864	W20 BATTERY COVER PINK	1	Battery Cover Pink	0,99	W20I	2011	Xperia öncesi yeniler
1235-4865	W20 BATTERY COVER SILVER	2	Battery Cover Silver	0,945	W20I	2011	Xperia öncesi yeniler
1235-5044	E10 CONDUCTIVE GASGET 2,0X2,0	10	Gasket Conductive 2.0x2.0	0,015	E10I		Xperia
1235-5781	E15 MICRO SD CONN.	10	Conn Micro SD	0,225	E15I		Xperia
1235-5983	ST18 MICROPHONE	10	Microphone	0,495	ST18I		Xperia
1235-6043	X10 FRONT COVER BLACK	1	Front Cover Assy Black	55,5	X10I		Xperia
1235-8092	E10 SIM FPC ADHESIVE	9	Adhesive SIM FPC	0,045	E10I		Xperia
1235-8103	U10 FOIL ADH. TAPE ESD	3	Foil Adhesive tape ESD	0,075	U10I	2010	Xperia öncesi yeniler
1235-8400	W20 DEC. SHEET PINK	18	Decoration sheet Pink	0,24	W20I	2011	Xperia öncesi yeniler
1235-8402	W20 DEC. SHEET SILVER	24	Decoration sheet Silver	0,24	W20I	2011	Xperia öncesi yeniler
1235-9293	EP-500 BATARYA	5	EP500/Std Battery//Blister/	22,5			eski modeller
1235-9486	X10 CUSHION FOR FRAME KEY	5	Cushion for Frame Key	0,015	X10I		Xperia
1235-9700	EP310 MICRO USB CHARGER	10	EP310/Micro USB charger EU/Box/	8,25			eski modeller
1236-0069	E15 SCREW 2,2 X 1,4	20	Screw Phillips 2.2 x 1.4	0,015	E15I		Xperia
1236-0829	U20 BOTTOM CARRIER FRAME 1,8 B	6	Bottom Carrier Frame Assy (1.8 Band)	3,33	U20I	2011	Xperia öncesi yeniler
1236-1296	W150 BATTERY CONN.	8	Battery Connector	0,135	W150I	2011	Xperia öncesi yeniler
1236-1423	MH610 HEADSET	17	PHF Stereo MH610, Black	3,585			eski modeller
1236-2887	E15 ADH. FPC LCD	10	Adhesive FPC Display	0,015	E15I		Xperia
1236-4208	MT15 CONN. HDMI	6	Conn HDMI Receptacle 19p D-type, midmoun	0,555	MT15I		Xperia
1236-4967	E15 MESH EAR SPEAKER	9	Mesh Earspeaker	0,06	E15I		Xperia
1236-8726	U20 FRONT COVER	2	Front Cover Assembly	20,445	U20I	2011	Xperia öncesi yeniler
1237-0350	E15 COVER REAR WHITE/PINK	3	Cover Rear White/Pink	3,84	E15I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1237-1932	LT15 MICRO USB CONN.AB REC.5P	14	Conn USB micro AB Receptacle 5p Splash P	0,27	LT15I		Xperia
1237-2133	J20 SUB KEYBOARD FILM	77	Sub keyboard Film	0,06	J20I	2011	Xperia öncesi yeniler
1237-2994	MT15 RF ANTENNA SWITCH	5	RF Antenna Switch GSM and UMTS/CDMA Dual	1,305	MT15I		Xperia
1237-3826	J108 DOME SHEET	5	Dome Sheet	0,255	J108I	2010	Xperia öncesi yeniler
1237-5889	ST26 ANTEN BT WIFI	5	Antenna BT WIFI	0,3	ST26I		Xperia
1237-5890	ST26 ANTEN GPS	5	Antenna GPS	0,33	ST26I		Xperia
1237-8631	W20 VIBRATOR	3	Vibrator	0,555	W20I	2011	Xperia öncesi yeniler
1238-1450	J108 FRAME	4	Frame Assy Band 1	3,39	J108I	2010	Xperia öncesi yeniler
1238-1460	J108 CAMERA GASGET	10	Camera Gasket	0,015	J108I	2010	Xperia öncesi yeniler
1238-1474	J108 CAMERA LENS	10	Camera Lens	0,135	J108I	2010	Xperia öncesi yeniler
1238-1478	J108 PROTECTIVE FOIL	1	Protective Foil	0,015	J108I	2010	Xperia öncesi yeniler
1238-1484	J108 RECEIVER GASGET	10	Rreceiver Gasket	0,03	J108I	2010	Xperia öncesi yeniler
1238-1488	J108 SPEAKER MESH	10	Speaker Mesh	0,045	J108I	2010	Xperia öncesi yeniler
1238-1490	J108 BATTERY COVER SILVER	4	Battery Cover Assy Silver	0,135	J108I	2010	Xperia öncesi yeniler
1238-1576	J108 RECEIVER GASGET	10	Receiver Gasket Mesh	0,03	J108I	2010	Xperia öncesi yeniler
1238-1585	J108 KEYBOARD BLACK	2	Keyboard Latin Black	2,34	J108I	2010	Xperia öncesi yeniler
1238-1591	J108 VOLUME KEY BLACK	4	Volume Key Black	1,185	J108I	2010	Xperia öncesi yeniler
1238-3821	WT19 CARD CONN. MICRO SD	5	Card Conn Micro SD	0,285	W19I		Xperia
1238-5499	J108 KEYPAD ADHESIVE	10	Keypad Adhesive	0,195	J108I	2010	Xperia öncesi yeniler
1238-5522	LT15 SUB PBA	3	Sub PBA	4,635	LT15I		Xperia
1238-5906	LT15 RCV FLEX PBA	8	RCV Flex PBA	3,345	LT15I		Xperia
1238-5915	LT15 KEY FLEX	9	Key Flex PBA	2,43	LT15I		Xperia
1238-6785	LT15 CONN. 0P	5	Conn 0p	0,075	LT15I		Xperia
1238-8027	LT15 AUDIO JACK REC. 5P	12	Audio Jack Receptacle 5p	0,42	LT15I		Xperia
1238-8761	MT15 KEYFLEX	9	Keyflex	3,84	MT15I		Xperia
1238-9181	EP-800 CHARGER	89	EP800/Std Charger/EU/Box	13,5			eski modeller
1238-9846	W20 SUB KEYBOARD FOIL	7	Sub keyboard Foil	0,015	W20I	2011	Xperia öncesi yeniler
1239-0342	W20 MAIN WINDOW	3	Main Window Assembly	1,05	W20I	2011	Xperia öncesi yeniler
1239-7581	J108I BATTERY COVER RED	1	Battery Cover Assy Red	1,02	J108I	2010	Xperia öncesi yeniler
1239-0427	J108 KRH LABEL	20	Core Unit Label	0,105	J108I	2010	Xperia öncesi yeniler
1239-1944	J10I2 MICROPHONE	10	Mic 0.0 Electret	0,225	J10I2	2011	Xperia öncesi yeniler
1239-3969	E15 FRONT COVER WHITE	3	Cover Front assy White	29,265	E15I		Xperia
1239-4362	E15 REAR COVER WHITE/DARK BLUE	2	Cover Rear White/DarkBlue	3,84	E15I		Xperia
1239-6699	E10 ANTENNA MAIN 1/8	11	Antenna Main 1/8	0,72	E10I		Xperia
1239-6700	E10A ANTENNA MAIN 1/2/5	1	Antenna Main 1/2/5	0,72	E10I		Xperia
1239-6765	LT15 RF CABLE	5	Cable RF	0,87	LT15I		Xperia
1239-6934	MT15 COAX CABLE	4	Cable Coax	0,9	MT15I		Xperia
1239-7033	E15 INNER FRAME 1/8	7	Inner Frame 1/8	3	E15I		Xperia
1239-7133	MT15 COVER LEFT SIDE PANEL	5	Cover Left Side Panel	0,645	MT15I		Xperia
1239-7135	MT15 FRONT COVER BLACK-BLUE	11	Cover Front Assy Black-Blue	3,54	MT15I		Xperia
1239-7150	MT15 MULTIFUNC.FRONT KEYS	9	Multifunc Front keys	0,57	MT15I		Xperia
1239-7153	MT15 CAMERA KEY	23	Camera key	0,195	MT15I		Xperia
1239-7154	MT15 VOLUME KEY	15	Volume key	0,405	MT15I		Xperia
1239-7156	MT15 ON-OF KEY	39	On/Off key	0,195	MT15I		Xperia
1239-7428	MT15 CAMERA 8MP	11	Camera 8.1 MPixel	19,245	MT15I		Xperia
1239-7525	E15 COVER REAR BLACK/SILVER	8	Cover Rear Black/Silver	2,76	E15I		Xperia
1239-7527	E15 COVER REAR BLACK	6	Cover Rear Black	2,76	E15I		Xperia
1239-7569	ST15 LCD	4	Display 3.0 TFT	19,425	ST15I		Xperia
1239-7579	J108 SCREW	50	Screw Len:4.0 Diam:1.4	0,015	J108I	2010	Xperia öncesi yeniler
1239-8325	LT15 ANT. GPS FLEX	6	Ant GPS Flex	0,39	LT15I		Xperia
1239-8569	MT15 BAT.COVER BLACK-BLUE(GEÇ)	15	Battery Cover Assembly Black-Blue	2,925	MT15I		Xperia
1239-9424	MT15 CARRIER CONN.SUPPORT	5	Carrier Connector support assembly	0,12	MT15I		Xperia
1240-0429	E15 REAR COVER WHITE	4	Cover Rear White	3,84	E15I		Xperia
1240-0604	LT15 FRONT COVER BLACK	8	Cover Front Sub Assembly Black	3,495	LT15I		Xperia
1240-0656	LT15 REAR COVER	4	Cover Rear Sub Assembly	2,955	LT15I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1240-0768	E15 USB CAP BLACK	2	Cap USB Black	0,225	E15I		Xperia
1240-1078	LT15 MAIN KEY	5	Key Main	0,645	LT15I		Xperia
1240-1116	LT15 ONOF KEY	3	Key On/Off	0,18	LT15I		Xperia
1240-1156	LT15 SCREW	3	Screw Len:3.0 Diam:1.4 M	0,015	LT15I		Xperia
1240-1166	LT15 BATTERY COVER BLUE	7	Cover Battery Sub Assembly Blue	4,785	LT15I		Xperia
1240-1175	LT15 KRH LABEL	20	Label Core Unit	0,075	LT15I		Xperia
1240-1178	LT15 SCREEN PROTECTION	4	MComp Sheet Protection LCD	0,135	LT15I		Xperia
1240-2652	LT15 INPUT SWITCH PUSH	16	Input Switch Push	0,045	LT15I		Xperia
1240-4122	J108 FRONT BLACK	3	Front Cover Assy Black	0,885	J108I	2010	Xperia öncesi yeniler
1240-5071	ST15 SUPPORT LCD	5	Support LCD	2,175	ST15I		Xperia
1240-5110	ST15 GASGET MİC.	10	Gasket Mic	0,015	ST15I		Xperia
1240-5113	ST15 ADHESİVE	10	Adhesive 3 x 6	0,015	ST15I		Xperia
1240-5169	ST15 INNER FRAME	8	Inner Frame 1/8	3,255	ST15I		Xperia
1240-5186	ST15 GASGET LOUDSPEAKER	10	Gasket Loudspeaker	0,03	ST15I		Xperia
1240-5197	ST15 WINDOW CAMERA	5	Window Camera	0,255	ST15I		Xperia
1240-5198	ST15 GASGET CAMERA	10	Gasket Camera	0,015	ST15I		Xperia
1240-5205	ST15 GASGET SEMİCİCULAR	10	Gasket 8 x 3 semicircular	0,015	ST15I		Xperia
1240-5208	ST15 GASGET NET MİC.	10	Gasket Net Mic	0,015	ST15I		Xperia
1240-5247	ST15 ONOFF KEY BLACK	3	Key On/Off Black	0,225	ST15I		Xperia
1240-5383	ST15 GASGET PROXY	10	Gasket Proxy	0,105	ST15I		Xperia
1240-5763	ST15 DOME SHEET	8	Dome Sheet	0,06	ST15I		Xperia
1240-5768	ST15 USB CAP BLACK	13	Cap USB Black	0,105	ST15I		Xperia
1240-7934	U5 MECH PART PANEL SIDE LEFT	1	Mech Part Vivaz Panel Side Left Sub Asse	1,755	U5I		Xperia öncesi yeniler
1240-7944	U5 MECH PART PANEL SIDE RIGHT	1	Mech Part Vivaz Panel Side Right Sub Ass	2,25	U5I		Xperia öncesi yeniler
1240-9985	MT15 SCREW 1.4	42	Screw Phillips Diam:1.4	0,045	MT15I		Xperia
1241-0695	E15 CO BRAND WHITE	11	Co Brand White	0,105	E15I		Xperia
1241-0704	E15 CO BRAND BLACK	2	Co Brand Black	0,105	E15I		Xperia
1241-0919	ST15 GASGET	10	Gasket 15 x 7	0,015	ST15I		Xperia
1241-0932	ST15 SCREW	50	Screw Torx Len:5.7 Diam:1.7	0,015	ST15I		Xperia
1241-0946	ST15 CONN. MICRO SD READER	5	Conn MicroSD reader	0,27	ST15I		Xperia
1241-1870	HPM-60JS 3,5 MM STEREO PHF	22	HPM-60JS 3.5mm Stereo PHF	1,89			eski modeller
1241-3082	ST15 SHIELD CAN LID CAMERA	5	Shield Can Lid Camera	0,09	ST15I		Xperia
1241-3332	ST15 GASGET CAMERA FLASH	10	Gasket Camera/Flash	0,03	ST15I		Xperia
1241-3463	MT15 FOIL 0.0 MM PROT. TAPE	20	Foil 0.0 mmProtective Tape Touch FPC	0,015	MT15I		Xperia
1241-3501	ST15 SHIELD CAN LID RF	10	Shield Can Lid RF	0,03	ST15I		Xperia
1241-3758	MT15 GASGET	10	Gasket	0,015	MT15I		Xperia
1241-4115	MT15 COVER RIGHT SIDE PANEL	1	Cover Right Side panel right assembly	0,84	MT15I		Xperia
1241-4623	MT15 CARRIER METAL LCM CARRIER	7	Carrier Metal LCM Carrier Assembly	3,27	MT15I		Xperia
1241-5650	MT15 SCREW 5.7 X 1.4	25	Screw Other Len:5.7 Diam:1.4	0,015	MT15I		Xperia
1241-5668	ST15 CAMERA 5 MP	7	Camera 5 MPixel	11,7	ST15I		Xperia
1241-5781	MT15 PROTECTIVE TAPE LEFT	9	Protective Tape Left	0,015	MT15I		Xperia
1241-5782	MT15 PROTECTIVE TAPE RIGHT	9	Protective Tape Right	0,015	MT15I		Xperia
1241-6091	MT15 CAP TOUCH FLEX	8	Cap Touch flex assy	0,075	MT15I		Xperia
1241-6361	CK15 MAIN ANT FPC	2	Ant Main Flex Module 900	0,465	CK15I		Xperia
1241-6364	CK15 HINGE FPC	19	Hinge FPC Assembly	1,575	CK15I		Xperia
1241-6489	ST15 GASGET AUDIO JACK	10	Gasket Audio Jack	0,015	ST15I		Xperia
1241-6722	ST15 CUSHION	10	Cushion 7x7	0,015	ST15I		Xperia
1241-7214	MT15 SCREW 4.5 X 1.4	45	Screw Torx 4IP Len:4.5 Diam:1.4 Screw 1,	0,015	MT15I		Xperia
1241-7544	SK17 HINGE FPC	12	Hinge FPC	10,17	SK17I		Xperia
1241-8093	J108 FRAME 1.2.5	3	Frame Assy Band1.2.5	2,16	J108I	2010	Xperia öncesi yeniler
1241-8112	MT15 RF TAPE	10	Foil 0.0 mmRF tape	0,015	MT15I		Xperia
1241-8123	MT15 FOIL 0.0 MMAV TAPE	10	Foil 0.0 mmAV tape	0,015	MT15I		Xperia
1241-8420	ST15 GASGET CONDUCTIVE	10	Gasket Conductive 19 x 11	0,24	ST15I		Xperia
1241-8767	MT15 GASGET RGB LED	10	Gasket - RGB LED Assembly	0,06	MT15I		Xperia
1241-9008	ST15 SHIELD CAN LID	10	Shield Can Lid BT/WLAN	0,03	ST15I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1241-9044	ST15 SHIELD CAN LID ABB	10	Shield Can Lid ABB	0,135	ST15I		Xperia
1241-9399	E15 FRONT BLACK	7	Cover Front assy Black	29,325	E15I		Xperia
1241-9511	MT15 SIM OPEN LABEL	10	SIM open label	0,015	MT15I		Xperia
1242-0184	MT15 FOIL ADH.SINGLE SIDE 0.1	10	Foil Adhesive Single Side 0.1 mmmicro SD	0,015	MT15I		Xperia
1242-0913	ST15 SWITCH	5	Switch	0,3	ST15I		Xperia
1242-1349	SK17 VIBRATOR	3	Vibrator	0,525	SK17I		Xperia
1242-1878	SK17 FLASH LED FPC	2	Flash LED FPC	2,745	SK17I		Xperia
1242-1879	SK17 CAMERA KEY FPC	5	Camera Key FPC	0,51	SK17I		Xperia
1242-2007	SK17 VOLUME KEY BLACK	10	Volume Key Black	0,3	SK17I		Xperia
1242-2021	SK17 CAMERA KEY BLACK	9	Camera Key Black	0,21	SK17I		Xperia
1242-2022	SK17 MAIN KEYPAD BLACK	6	Main Keypad QWERTY Latin Black	3,03	SK17I		Xperia
1242-2023	SK17 ONOFF KEY BLACK	4	Power Key Black	0,15	SK17I		Xperia
1242-2025	SK17 HINGE SLIDE TOP BLACK	6	Hinge Slide Top Assy Black	5,685	SK17I		Xperia
1242-2274	SK17 LOWER FRONT BLACK	5	Lower Front Cover Assy Black	2,775	SK17I		Xperia
1242-2305	SK17 LOWER REAR COVER	3	Lower Rear Cover Assy Band 18	2,88	SK17I		Xperia
1242-2308	SK17 RECEIVER MESH BLACK	5	Receiver Mesh Black	0,045	SK17I		Xperia
1242-2319	SK17 MICRO USB COVER BLACK	6	Micro USB Cover Black	0,045	SK17I		Xperia
1242-2326	ST25 SCREW	50	Screw Torx Len:3.1 Diam:1.4	0,015	ST25I		Xperia
1242-2349	SK17 LOUDSPEAKER GASGET	10	Loud Speaker Gasket	0,015	SK17I		Xperia
1242-2363	SK17 LOUDSPEAKER MESH BLACK	10	Loud Speaker Mesh Black	0,06	SK17I		Xperia
1242-2364	SK17 FIST MIC. MESH	10	First Mic Mesh	0,015	SK17I		Xperia
1242-2365	SK17 SECOND MIC MESH BLACK	10	Second Mic Mesh Black	0,015	SK17I		Xperia
1242-2377	SK17 COND.CUSHION	10	Conductive Cushion	0,15	SK17I		Xperia
1242-2400	SK17 BATTERY COVER BLACK	4	Battery Cover Assy Black	0,93	SK17I		Xperia
1242-2475	SK17 RECEIVER DECO BLACK	5	Receiver Deco Black	0,21	SK17I		Xperia
1242-2492	SK17 SCREW CAP BLACK	12	Screw Cap Black	0,015	SK17I		Xperia
1242-2766	ST15 BATTERY COVER WHITE	2	Cover Battery White	1,47	ST15I		Xperia
1242-3994	ST18 AUDIO JACK	6	Audio Jack	0,405	ST18I		Xperia
1242-4054	W20 DEC.SHEET RED	8	Decoration sheet Red	0,255	W20I	2011	Xperia öncesi yeniler
1242-6000	J108 LCD METAL	5	LCD Metal Assy	0,48	J108I	2010	Xperia öncesi yeniler
1242-6502	ST15 CUSHION 5 X 2	5	Cushion 5 x 2	0,015	ST15I		Xperia
1242-6545	ST18 MICRO USB CONN.	28	Connector Micro USB	0,285	ST18I		Xperia
1242-6758	MICRO USB CABLE	75	EC450/1m microUSB cable/Bulk	6			eski modeller
1242-7651	ST15 GASGET	5	Gasket 7,3 x 1,5	0,015	ST15I		Xperia
1242-7996	J108 MIC.GASGET	10	Microphone Gasket	0,015	J108I	2010	Xperia öncesi yeniler
1242-8313	SK17 MICRO USB CONN.	4	Micro USB Connector	0,165	SK17I		Xperia
1242-8458	CK13 LOUDSPEAKER	10	Loudspeaker	0,405	CK13I		Xperia
1242-8504	ST15 ADHESIVE IRREGULAR	5	Adhesive Irregular	0,015	ST15I		Xperia
1242-8622	ST15 NET LOUDSPEAKER MESH	5	Net Loudspeaker mesh	0,015	ST15I		Xperia
1242-8650	SK17 SIM CARD CONN.	5	SIM Card Connector	0,165	SK17I		Xperia
1242-8777	EC600 MICRO USB MEDIA CABLE	3	Media Cable Micro USB Cable EC600 Ogawa/	1,44			eski modeller
1242-9009	CK15 LCD	6	Display 3.0 inch TFT	13,32	CK15I		Xperia
1242-9140	W100 SCREEN PROTECTIVE FILM	5	Screen Protective Film	1,14	W100I	2011	Xperia öncesi yeniler
1242-9223	SK17 HINGE FPC CLIP	5	Hinge FPC Clip	0,15	SK17I		Xperia
1242-9472	SK17 AUDIO JACK ADHESIVE FOİL	5	Audio Jack Adhesive Foil	0,015	SK17I		Xperia
1242-9839	LT15 LCD	2	Display 4.2 TFT	87,105	LT15I		Xperia
1243-0332	ST15 USB CAP WHITE	7	Cap USB White	0,105	ST15I		Xperia
1243-0384	LT15 FRONT COVER SILVER	13	Cover Front Sub Assembly Silver	4,095	LT15I		Xperia
1243-0394	LT15 BATTERY COVER SILVER	7	Cover Battery Sub Assembly Silver	5,43	LT15I		Xperia
1243-0427	SK17 GPS SHIELDING COND.GASGET	5	GPS Shielding Conductive Gasket	0,015	SK17I		Xperia
1243-0431	SK17 WLAN SHIELDING ADHESIVE F	5	WLAN Shielding Adhesive Foil	0,015	SK17I		Xperia
1243-0605	SK17 SHIELDING CAN LID ABB	5	Shielding Can Lid ABB	0,045	SK17I		Xperia
1243-0607	SK17 SHIELDING CAN WLAN	5	Shielding Can WLAN	0,03	SK17I		Xperia
1243-0608	SK17 SHIELDING CAN GPS	5	Shielding Can GPS	0,015	SK17I		Xperia
1243-0671	J108 LCD CONN. PROTECTIVE FOIL	10	LCD Connector Protective Foil	0,015	J108I	2010	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1243-1161	MK16 SLIDER FLEX	1	Slider Flex FPC Assy	9,915			eski modeller
1243-1322	MK16 KEYFLEX	3	Qwerty Key Flex PBA	4,815			eski modeller
1243-1626	CK15 REAR COVER SILVER	3	Rear Cover Assy Silver	2,445	CK15I		Xperia
1243-1632	CK15 VOLUME KEY	5	Key Volume	0,315	CK15I		Xperia
1243-1633	CK15 ONOF KEY	5	Key Power	0,45	CK15I		Xperia
1243-1634	CK15 CAMERA KEY	4	Key Camera	0,33	CK15I		Xperia
1243-1635	CK15 REAR CABINET BLACK INNER	4	Rear Cabinet_2325_BLACK_PC_N/A_Inner Rea	0,21	CK15I		Xperia
1243-1636	CK15 METAL DOME HOME KEY	11	Metal Dome Home Key	0,045	CK15I		Xperia
1243-1637	CK15 METAL DOME KEYPAD	10	Metal Dome keypad	0,54	CK15I		Xperia
1243-1697	CK15 SPONGE PROX.SENSOR	7	Sponge Proximity Sensor	0,03	CK15I		Xperia
1243-1700	CK15 SPONGE SPEAKER	10	Sponge Speaker	0,06	CK15I		Xperia
1243-1730	CK15 HINGE MODULE SILVER	4	Hinge module Silver	6,015	CK15I		Xperia
1243-1734	CK15 LCD SHEILDING	5	Display Shielding	0,885	CK15I		Xperia
1243-1738	CK15 CAMERA LENS	3	Camera Lens	0,33	CK15I		Xperia
1243-1747	CK15 SCREW	43	Screw Cross(JCIS) 1.6mm*3.5mm Silver	0,03	CK15I		Xperia
1243-1756	CK15I SCREW	25	Screw FPH (T5) M1.4*L3mm	0,015	CK15I		Xperia
1243-1760	CK15 SCREW	25	Screw Cross(JCIS) 1.6mm*4mm Silver	0,075	CK15I		Xperia
1243-1762	CK15 COND. GASGET	25	Conductive Gasket 3x4x0.5mm	0,045	CK15I		Xperia
1243-1783	CK15 BATTERY COVER BLACK	4	Battery Cover Assy Black	1,155	CK15I		Xperia
1243-1785	CK15 KEYBOARD SILVER	3	Keyboard Qwerty English Silver	2,775	CK15I		Xperia
1243-1786	CK15 KEYBOARD QWERTY ENG WHITE	5	Keyboard Qwerty English White	2,775	CK15I		Xperia
1243-2292	WT13 LCD	2	Display 3.0 inch TFT	12,69	WT13I		Xperia
1243-2484	SK17 MICRO SD CARD CONN.	5	Micro SD Card Connector	0,255	SK17I		Xperia
1243-2862	E15 REAR COVER BLACK/BLUE	2	Cover Rear Black/Blue	2,76	E15I		Xperia
1243-2863	E15 REAR COVER BLACK/RED	3	Cover Rear Black/Red	2,76	E15I		Xperia
1243-3068	CK13 CONN. AUDIO JACK REC. 6 P	8	Conn Audio Jack Receptacle 6p	0,24	CK13I		Xperia
1243-5213	J108 BAT.COVER WHITE	9	Cover battery cover assembly	0,825	J108I	2010	Xperia öncesi yeniler
1243-5396	MT15 BATTERY COVER RED	2	Battery Cover Assembly Red	3,27	MT15I		Xperia
1243-5616	MT15 BATTERY COVER SILVER	7	Battery Cover Assembly Silver	2,775	MT15I		Xperia
1243-5779	J108 VOLUME KEY SILVER	5	Key Volume Volume key Silver	0,225	J108I	2010	Xperia öncesi yeniler
1243-5780	J108 KEYBOARD SILVER	3	Keyboard Latin silver	2,61	J108I	2010	Xperia öncesi yeniler
1243-6006	SK17 FLASH LED FPC ADH.FOIL	5	Flash LED FPC Adhesive Foil	0,015	SK17I		Xperia
1243-6063	MT15 FRONT RED	1	Cover Front Assy - Red	3,84	MT15I		Xperia
1243-6066	MT15 FRONT SILVER	4	Cover Front Assy - Silver	3,435	MT15I		Xperia
1243-6342	W20 DEC.SHEET WHITE	10	Decoration sheet White	0,255	W20I	2011	Xperia öncesi yeniler
1243-6345	W200 BATTERY COVER WHITE	2	Battery Cover White	1,35			eski modeller
1243-6349	W20 UPPER FRONT WHITE	1	Upper front cover White	1,665	W20I	2011	Xperia öncesi yeniler
1243-7302	CK15 CARD CONN. MICRO SD	5	Card Conn Micro SD	0,195	CK15I		Xperia
1243-8928	SK17 ADHESIVE FOIL HINGE	5	Hinge Assy Adhesive Foil	0,015	SK17I		Xperia
1243-9968	SK17 PROTECTIVE FILM MAIN ANT.	5	Main Antenna Switch Protective Film	0,015	SK17I		Xperia
1244-5174	ST15 MICRO USB CONN.5P	2	Conn USB micro 5p	0,285	ST15I		Xperia
1244-5343	MT27 EARSPEAKER	75	Ear Speaker 12.0 Rectangular	1,155	MT27I		Xperia
1244-6259	WT13 REAR COVER BLACK	3	Rear Cover Assy Black mesh	2,025	WT13I		Xperia
1244-6265	WT13 BATTERY COVER BLACK	3	Battery Cover Assy Black	2,595	WT13I		Xperia
1244-8400	LT15 RF CAP	8	Cap RF	0,09	LT15I		Xperia
1244-9425	ST15 SHIELD CAN LID DBB	5	Shield Can Lid DBB	0,03	ST15I		Xperia
1244-9755	ST15 BATTERY COVER DARK PINK	9	Cover Battery Dark Pink	1,53	ST15I		Xperia
1244-9757	ST15 BATTERY COVER BLACK	1	Cover Battery Black	1,545	ST15I		Xperia
1245-0490	W20 INS.PROTECTION FILM	85	Insulation protection film	0,015	W20I	2011	Xperia öncesi yeniler
1245-2711	LT28 VIBRATOR	9	Vibrator	1,17	LT28I		Xperia
1245-7275	LT26 WATER INDICATOR	49	Water Indicator	0,03	LT26I		Xperia
1245-9262	ST18 SUB PBA BAND 125&18	10	Sub PBA Band125&18	6,225	ST18I		Xperia
1245-9291	ST18 RELAY FPC	8	Relay FPC	1,425	ST18I		Xperia
1245-9312	ST18 SIM FPC	3	SIM FPC Module	4,17	ST18I		Xperia
1246-0258	LT15 ANTENNA MAIN FLEX BAND1,8	3	Ant Main Flex Assy Band 1,8	1,56	LT15I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1246-0289	SK17 MAIN KEYPAD WHITE	2	Main Keypad QWERTY Latin White	3,84	SK17I		Xperia
1246-0292	SK17 BATTERY COVER WHITE	6	Battery Cover Assy White	0,975	SK17I		Xperia
1246-0306	J108 KEYBOAR WHITE	3	Keyboard Latin white	2,76	J108I	2010	Xperia öncesi yeniler
1246-0321	J108 VOLUME KEY WHITE	5	Key Volume Volume key White	0,33	J108I	2010	Xperia öncesi yeniler
1246-0331	SK17 RECEIVER MESH WHITE	5	Receiver Mesh White	0,045	SK17I		Xperia
1246-0348	SK17 RECEIVER DECO WHITE	5	Receiver Deco White	0,255	SK17I		Xperia
1246-0356	SK17 HINGE SLIDE TOP WHITE	3	Hinge Slide Top Assy White	5,685	SK17I		Xperia
1246-0407	SK17 LOWER FRONT WHITE	3	Lower Front Cover Assy White	2,775	SK17I		Xperia
1246-0481	SK17 ONOFF KEY WHITE	5	Power Key White	0,18	SK17I		Xperia
1246-0482	SK17 VOLUME KEY WHITE	5	Volume Key White	0,3	SK17I		Xperia
1246-0483	SK17 CAMERA KEY WHITE	3	Camera Key White	0,21	SK17I		Xperia
1246-0484	SK17 MICRO USB COVER WHITE	5	Micro USB Cover White	0,195	SK17I		Xperia
1246-0870	SK17 SCREW CAP WHITE	10	Screw Cap White	0,015	SK17I		Xperia
1246-1168	MT15 BATTERY COVER COBRAND BLA	4	Battery Cover Assy Co brand Black-Blue	3,075	MT15I		Xperia
1246-1372	MH650 PHF	19	MH650/PHF Stereo/Black/Green He	4,335			eski modeller
1246-1866	J108 FRONT SILVER	2	Front Cover Assy, Silver	4,14	J108I	2010	Xperia öncesi yeniler
1246-4518	SK17 SHIELDING CAN LID RF	5	Shielding Can Lid RF	0,03	SK17I		Xperia
1246-4522	SK17 SHIELDING CAN LID DBB	5	Shielding Can Lid DBB	0,06	SK17I		Xperia
1246-5530	CK13 LCD	4	Display 2.55 inch TFT	12,195	CK13I		Xperia
1246-5652	AN400/EXCHANGE UNIT CAR CHARGE	10	AN400/Exchange Unit/	8,25			eski modeller
1246-7502	SK17 MAIN KEYPAD DOME SHEET	19	Main Keypad Domesheet	0,915	SK17I		Xperia
1247-0255	LT15 FRONT WHITE	14	Cover Front Sub Assembly White	3,84	LT15I		Xperia
1247-0264	LT15 BATTERY COVER WHITE	4	Cover Battery Sub Assembly White	2,055	LT15I		Xperia
1247-2548	ST18 MAIN ANTENNA	10	Flex Main Antenna	1,47	ST18I		Xperia
1247-2564	ST18 GPS NON-CELLULAR ANTENNA	5	GPS Non-Cellular Antenna	0,165	ST18I		Xperia
1247-3025	SK17 BATTERY COVER COBRAND BLC	5	Battery Cover Assy Cobrand Black	0,885	SK17I		Xperia
1247-3029	SK17 BATTERY COVER WHITE COBRA	3	Battery Cover Assy Cobrand White	0,975	SK17I		Xperia
1247-4151	BA-700 BATARYA	22	BA700/Std Battery/ROW/Bag/	22,5			eski modeller
1247-4171	BA-750 BATARYA	71	BA750/Std Battery/ROW/Bag/	22,5			eski modeller
1247-4438	LT26 FPC JACK	2	FPC Jack Assy	2,685	LT26I		Xperia
1247-5962	ST15 GASGET RGB LED	5	Gasket RGB LED	0,12	ST15I		Xperia
1247-6178	ST18 SUB PBA DOME SWITCH	20	Sub PBA Dome Switch	0,135	ST18I		Xperia
1247-6385	MH410 PHF BEYAZ	7	MH410/PHF Stereo/EU4/White/White/Box	7,5			eski modeller
1247-7159	LT26 CAMERA 13,1 MP	3	FICTIVE Camera 13.1 M	28,86	LT26I		Xperia
1247-7524	ST15 EARSPEAKER	17	Earspeaker	0,81	ST15I		Xperia
1247-7736	MT27 VIBRATOR	4	Vibrator	1,17	MT27I		Xperia
1247-8936	LT26 RF CABLE	2	RF Cable	0,405	LT26I		Xperia
1247-9658	CK13 CAMERA 3 MP	5	FICTIVE Camera 3 MPixel CMOS	8,19	CK13I		Xperia
1247-9760	ST18 CARRIER HOLDER RECEIVER S	10	Carrier Holder Receiver Sub Assembly	0,165	ST18I		Xperia
1247-9769	ST18 AUDIO JACK PLATE	10	Audio Jack Plate	0,06	ST18I		Xperia
1247-9773	ST18 REAR COVER	6	Cover Rear Assembly	1,395	ST18I		Xperia
1247-9784	ST18 CABLE COVER INSERT	5	Cable Cover Insert	0,075	ST18I		Xperia
1247-9786	ST18 KEY HOME	3	Key Home	0,66	ST18I		Xperia
1247-9790	ST18 VOLUME KEY BLACK	4	Key Volume Black	0,21	ST18I		Xperia
1247-9792	ST18 ON/OFF KEY	2	Key On/Off	0,18	ST18I		Xperia
1247-9801	ST18 SCREW	30	Screw Len:4.0 Diam:1.4	0,015	ST18I		Xperia
1247-9811	ST18 BATTERY COVER BLACK	6	Cover Battery Black	2,28	ST18I		Xperia
1247-9819	ST18 CAP TP A	4	Cap TP A	0,03	ST18I		Xperia
1247-9822	ST18 CAP TP B	5	Cap TP B	0,045	ST18I		Xperia
1247-9834	ST18 CAP RF	4	Cap RF	0,045	ST18I		Xperia
1248-0165	MT15 GASGET SPEAKER GASGET UPP	10	Gasket Speaker gasket upper	0,06	MT15I		Xperia
1248-1738	ST18 FOIL ADH. DOUBLE SIDE REC	10	Foil Adhesive Double Side Receiver	0,015	ST18I		Xperia
1248-1744	ST18 RF RADIATOR SHEET	10	RF Radiator Sheet	0,405	ST18I		Xperia
1248-1827	ST18 MCOMP SHEET RELAY CON	10	MComp Sheet Relay CON	0,015	ST18I		Xperia
1248-1830	ST18 CUSHION 0,0 MM SUB PBA	10	Cushion 0.0 mmSub PBA	0,06	ST18I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1248-2071	LT16 CUSHION RECEIVER	20	Cushion Receiver	0,03			eski modeller
1248-2091	LT26 SHIELD CAN BB A	8	Shield Can BB A	0,075	LT26I		Xperia
1248-2095	LT26 SHIELD CAN BB B	7	Shield Can BB B	0,075	LT26I		Xperia
1248-2098	LT26 SHIELD CAN RF	10	Shield Can RF	0,105	LT26I		Xperia
1248-2112	LT26 SHIELD CAN NON CELL	10	Shield Can Non Cell	0,03	LT26I		Xperia
1248-2155	LT26 CARRIER HOLDER PROX.SENS.	4	Carrier Holder Proximity Sensor	0,09	LT26I		Xperia
1248-2187	LT26 COVER TRANSPARENT	3	Cover Transparent Assy	9,015	LT26I		Xperia
1248-2245	LT26 REAR FRAME BLACK	10	Rear Frame Assy Black	2,37	LT26I		Xperia
1248-2274	LT26 ONOFF KEY BLACK	5	Key On/Off Black	0,93	LT26I		Xperia
1248-2338	LT26 CAMERA KEY BLACK	5	Key Camera Black	0,87	LT26I		Xperia
1248-2345	LT26 VOLUME KEY BLACK	8	Key Volume Black	1,005	LT26I		Xperia
1248-2355	LT26 SCREW	65	Screw 3.5x1.4	0,015	LT26I		Xperia
1248-2360	LT28 SCREW OTHER LEN3.0Dİ:1.4	44	Screw Other Len:3.0 Diam:1.4	0,03	LT28I		Xperia
1248-2368	LT26 MICRO USB CAP BLACK	9	Cap Micro-USB Black	0,405	LT26I		Xperia
1248-2372	LT26 HDMI CAP BLACK	8	Cap HDMI Black	0,405	LT26I		Xperia
1248-2377	LT26 BOTTOM COVER BLACK	20	Cover Bottom Black	1,725	LT26I		Xperia
1248-2382	LT26 REAR COVER BLACK	8	Cover Rear Assy Black	6,045	LT26I		Xperia
1248-2396	LT26 CORE UNIT LABEL	50	Core Unit Label	0,105	LT26I		Xperia
1248-2400	LT26 SHEET PROT. LCD	9	Sheet Protection LCD	0,24	LT26I		Xperia
1248-2402	LT26 SHEET ACF RELAY	10	Sheet ACF Relay	0,195	LT26I		Xperia
1248-3571	SK17 COND. COPPER FOIL	10	Conductive Copper Foil	0,015	SK17I		Xperia
1248-3777	ST17 INNER FRAME	3	Inner Frame	2,565	ST17I		Xperia
1248-3847	SK17 VGA CAMERA RUBBER CARRIER	10	VGA Camera Rubber Carrier	0,015	SK17I		Xperia
1248-4548	ST15 FRONT WHITE	26	Cover Front assy White	42,3	ST15I		Xperia
1248-4551	ST15 FRONT BLACK	2	Cover Front assy Black	40,695	ST15I		Xperia
1248-6272	ST18 VOLUME KEY GOLD	8	Key Volume Gold	0,21	ST18I		Xperia
1248-6277	ST18 BATTERY COVER GOLD	3	Cover Battery Gold	2,28	ST18I		Xperia
1248-6278	ST18 BATTERY COVER PINK	3	Cover Battery Pink	2,28	ST18I		Xperia
1248-6298	MT15 GASGET LCD DRIVER	10	Gasket LCD Driver	0,015	MT15I		Xperia
1248-6841	ST15 MICROPHONE	10	Microphone	0,555	ST15I		Xperia
1248-9098	CK15 BATTERY COVER WHITE	2	Battery Cover Assy White	1,155	CK15I		Xperia
1248-9224	ST18 VOLUME KEY WHITE	10	Key Volume White	0,21	ST18I		Xperia
1248-9229	ST18 BATTERY COVER WHITE	1	Cover Battery White	2,28	ST18I		Xperia
1249-1368	CK15 MYLAR HINGE FPC	10	Mylar Hinge FPC	0,045	CK15I		Xperia
1249-1372	CK15 CONDUCTIVE TAPE 7,6*43,2	10	Conductive Tape 7.6*43.2mm	0,015	CK15I		Xperia
1249-1378	CK15 CONDUCTIVE TAPE 3,5*17,5	10	Conductive Tape 3.5*17.5mm	0,015	CK15I		Xperia
1249-1387	CK15 CONDUCTIVE TAPE 10*18 MM	10	Conductive Tape 10*18mm	0,075	CK15I		Xperia
1249-1396	CK15 MYLAR HOME KEY LED	10	Mylar Home Key LED	0,015	CK15I		Xperia
1249-3415	MK16 FRONT BLACK	1	Front Cover Assy Black	42,345			eski modeller
1249-3954	ST15 SCREW	50	Screw Torx Len:3.4 Diam:1.6	0,015	ST15I		Xperia
1249-4595	ST15 ADHESIVE COND.5 X 2	10	Adhesive Conductive 5 x 2	0,015	ST15I		Xperia
1249-4929	EP300 STD.CHARGER MOUSE	25	EP300/Std Charger/UK/Box/	8,25			eski modeller
1249-7284	ST17 COVER 1/8 BAT. COVER(IÇ)	4	Cover Battery 1/8	5,535	ST17I		Xperia
1249-7755	LT22 CAMERA 8 MP	8	Camera 8 MPixel CMOS	23,235	LT22I		Xperia
124AFM00000	ST23 FRONT BLACK	5	Cover Front Assy Black	96,33	ST23I		Xperia
124AFM00001	ST23 FRONT WHITE	1	Cover Front Assy White	96,75	ST23I		Xperia
1250-0364	MT15 FRONT WHITE	5	Cover Front Assy - Classic White	3,525	MT15I		Xperia
1250-0367	MT15 BAT. COVER WHITE	8	Battery Cover Assembly Classic White	3,075	MT15I		Xperia
1250-1934	MT27 CAMERA 5 MP	5	Camera 5 Mpixel	14,325	MT27I		Xperia
1250-3743	SK17 CAMERA WINDOW	5	Camera Window	0,345	SK17I		Xperia
1250-3752	SK17 CAMERA RING SILVER	5	Camera Ring Silver	0,255	SK17I		Xperia
1250-4619	WT19 DOME SHEET	9	Dome Sheet	0,015	W19I		Xperia
1250-4681	WT19 BATTERY COVER BLACK	4	Battery Cover Assy Black	1,86	W19I		Xperia
1250-4689	WT19 CAMERA RING	4	Camera Ring	0,285	W19I		Xperia
1250-4691	WT19 SIDE KEY	5	Key Side	0,615	W19I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1250-4702	WT19 CARRIER FRAME	5	Carrier Frame Assy	1,62	W19I		Xperia
1250-4705	WT19 NET RECEIVER	5	Net Receiver	0,03	W19I		Xperia
1250-5005	WT19 CO-BRAND BLACK	4	Co-Brand Black	0,06	W19I		Xperia
1250-5008	ST18 RF CABLE	5	RF Cable	0,615	ST18I		Xperia
1250-5770	WT19 KEY HOME BLACK	2	Key Home Black	0,75	W19I		Xperia
1250-5789	WT19 WINDOW FLASH LED	5	Window Flash LED	0,045	W19I		Xperia
1250-5894	WT19 KEY HOME WHITE	6	Key Home White	0,75	W19I		Xperia
1250-5897	WT19 BATTERY COVER WHITE	5	Battery Cover Assy White	1,98	W19I		Xperia
1250-5899	WT19 COBRAND WHITE	6	Co-Brand White	0,075	W19I		Xperia
1250-6494	ST15 ONOFF KEY WHITE	5	Key On/Off White	0,225	ST15I		Xperia
1250-8399	LT22 LCD	6	Display 4.0 inch LTPS TFT	110,22	LT22I		Xperia
1251-0967	LT22 REAR COVER BLACK	1	Cover Rear Metal Assy Black	19,155	LT22I		Xperia
1251-0969	LT22 CAMERA KEY BLACK	4	Key Camera Black	0,315	LT22I		Xperia
1251-0970	LT22 VOLUME/ONOFF BLACK	4	Key Volume / Power Black	0,555	LT22I		Xperia
1251-1320	ST18 CONN POGO PIN PLUG 5P	5	Conn Pogopin Plug 5p	0,54	ST18I		Xperia
1251-3150	ST18 CUSHION BAT. CONN.	5	Cushion Batt Conn	0,03	ST18I		Xperia
1251-3155	ST18 COVER PANEL BOTTOM	9	Cover Panel Bottom	0,45	ST18I		Xperia
1251-4024	LT22 PBA KEY FLEX	4	PBA Key flex	4,245	LT22I		Xperia
1251-4032	LT22 PBA MICROPHONE FLEX	8	PBA Microphone flex	1,05	LT22I		Xperia
1251-4334	SK17 SCREW	50	Screw Other Len:1.6 Diam:1.4	0,015	SK17I		Xperia
1251-4854	LT22 CARRIER ANTENNA	1	Carrier Antenna Assy	0,72	LT22I		Xperia
1251-4864	LT22 TRANSPARENT BELT	4	Transparent Belt Assembly	9,435	LT22I		Xperia
1251-4873	LT22 CAP METAL SIM BLACK	6	Cap Metal Sim Black	0,69	LT22I		Xperia
1251-7188	LT28 FPC SIDE	6	FPC Side Key	4,215	LT28I		Xperia
1251-7754	LT22 CARRIER LCD	2	Carrier LCD Assembly	7,065	LT22I		Xperia
1251-8844	ST18 SHEET LCD B TO B	5	Sheet LCD B to B	0,015	ST18I		Xperia
1251-9377	ST25 LCD	2	Display 3.5 inch TFT	31,425	ST25I		Xperia
1251-9598	LT28 ANTENNA NFC FLEX	25	Antenna NFC Flex	1,29	LT28I		Xperia
1252-0900	LT22 GASGET EARPHONE	20	Gasket Earspeaker	0,03	LT22I		Xperia
1252-0901	LT22 FOIL BATTERY ADH.	10	Foil Battery Adhesive	0,09	LT22I		Xperia
1252-0944	CK15 CO-BRAND BLACK	9	Co-Branding Black txt pro	0,21	CK15I		Xperia
1252-0949	CK15 CO-BRAND WHITE	7	Co-Branding White txt pro	0,21	CK15I		Xperia
1252-1143	MT27 BATTERY COVER BLACK	4	Cover Battery Black	2,67	MT27I		Xperia
1252-1164	MT27 INNER FRAME	1	Inner Frame	6,48	MT27I		Xperia
1252-1516	ST25 CARRIER WINDOW FRONT	2	Carrier Window Front assy	4,11	ST25I		Xperia
1252-1565	ST25 TRANSPARENT BELT 1,8	4	Transparent Belt Total Assy Band18	11,04	ST25I		Xperia
1252-1572	ST25 ANTENNA MAIN 1,8	5	Antenna Main Band18	0,72	ST25I		Xperia
1252-1579	ST25 BATTERY COVER BLACK	1	Battery Cover Assy Black	3,735	ST25I		Xperia
1252-1584	ST25 ANTENNA CAP WHITE	6	Antenna Cap White	0,885	ST25I		Xperia
1252-1586	ST25 BATTERY COVER WHITE	2	Battery Cover Assy White	3,735	ST25I		Xperia
1252-1670	SK17 FRONT BLACK	1	Touch/Display Front Cover Assy Black	101,76	SK17I		Xperia
1252-1672	SK17 FRONT/LCD/TOUCH WHITE	2	Touch/Display Front Cover Assy White	97,83	SK17I		Xperia
1252-3213	LT22 BATTERY 1265 MAH	1	Battery 1265.0 mAh	8,94	LT22I		Xperia
1252-3510	LT28 CAMERA FICTIVE 13.1M	5	FICTIVE Camera 13.1M	24,405	LT28I		Xperia
1252-4144	LT28 COVER METAL REAR BLACK	1	Cover Metal Rear Sub Assy Black	11,46	LT28I		Xperia
1252-4152	LT28 COVER PLASTIC BOTTOM BLC	9	Cover Plastic Rear Bottom Black	0,96	LT28I		Xperia
1252-4188	LT28 CAP PLASTIC USB HDMI BLAC	6	Cap Plastic USB HDMI Black	1,335	LT28I		Xperia
1252-4442	MT27 LCD SUPPORT	8	LCD support	5,715	MT27I		Xperia
1252-4589	LT22 PBA INTERCONNECT FLEX	2	PBA Interconnect Flex	2,205	LT22I		Xperia
1252-4822	MT27 FPC LED/VIBR/SPEAKER	17	FPC LED/Vibr/Speaker	1,44	MT27I		Xperia
1252-4823	MT27 FPC AV	10	FPC AV	0,645	MT27I		Xperia
1252-5114	LT22 REAR COVER SILVER	3	Cover Rear Metal Assy Silver	19,365	LT22I		Xperia
1252-5118	LT22 CAP METAL SIM SILVER	1	Cap Metal Sim Silver	0,69	LT22I		Xperia
1252-5123	LT22 COVER PLASTIC NFC SLIT	3	Cover Plastic NFC Slit	0,09	LT22I		Xperia
1252-5125	LT22 ANTENNA NFC FLEX	6	Antenna NFC Flex	1,005	LT22I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1252-5126	LT22 CARRIER INTERNAL FRAME	6	Carrier Internal Frame Assembly	2,34	LT22I		Xperia
1252-5127	LT22 VOLUME/ONOFF KEY SILVER	4	Key Volume / Power Silver	0,555	LT22I		Xperia
1252-5128	LT22 CAMERA KEY SILVER	2	Key Camera Silver	0,315	LT22I		Xperia
1252-5155	LT22 FOIL ADH.DOUBLE SIDE LCD	10	Foil Adhesive Double Side LCD Flex	0,03	LT22I		Xperia
1252-5717	ST17 FRONT BLACK	6	Cover Front with display Black	85,92	ST17I		Xperia
1252-5836	LT28 CABLE RF	5	Cable RF	0,48	LT28I		Xperia
1252-6446	ST17 EAR SPEAKER	10	Earspeaker	1,065	ST17I		Xperia
1252-9607	MT27 LCD	3	Display 3.7 inch S	43,695	MT27I		Xperia
1253-0560	MT27 CAP BOTTOM WHITE	1	Cap Bottom White Matte	1,755	MT27I		Xperia
1253-2277	LT22 FOIL ADH.DOUBLE SIDE FLAS	10	Foil Adhesive Double Side Flash Lens	0,03	LT22I		Xperia
1253-2872	MT11 CAMERA 5 MP	11	FICTIVE Camera MT15/Xperia neo 5 Mpixel	12,435	MT11I		Xperia
1253-4690	LT26 SCREW	49	Screw Len:2.6 Diam:1.4 M	0,03	LT26I		Xperia
1253-6653	LT22 FOIL ADH.DOUBLE SIDE CAM.	10	Foil Adhesive Double Side Camera Sealing	0,03	LT22I		Xperia
1253-6675	LT22 FOIL ADH.DOUBLE SIDE FLAS	10	Foil Adhesive Double Side Flash Silicone	0,03	LT22I		Xperia
1253-7477	WT19 FRONT BLACK	12	Front Cover Assy Black	44,115	W19I		Xperia
1253-7696	LT22 SCREW	72	Screw Other Len:2.0 Diam:1.2 M1.2x2.0	0,03	LT22I		Xperia
1253-7817	WT19 FRONT BEYAZ	2	Front Cover Assy White	51,375	W19I		Xperia
1253-8202	MT27 VOLUME/CAMERA SLICONE	10	Silicone Volume/Camera	0,21	MT27I		Xperia
1253-8213	MT27 ON/OFF SILICONE	14	Silicone On/Off	0,105	MT27I		Xperia
1253-9141	MT27 LID BATTERY FLEX	5	Lid Battery Flex	0,135	MT27I		Xperia
1253-9171	LT22 GASGET LOUDSPEAKER BLACK	9	Gasket Loudspeaker Black	0,075	LT22I		Xperia
1253-9172	LT22 GASGET LOUDSPEAKER SILVER	10	Gasket Loudspeaker Silver	0,06	LT22I		Xperia
1254-0058	LT22 CAP COSMETIC CAP BLACK	3	Cap Cosmetic cap assy Black	1,065	LT22I		Xperia
1254-0940	LT22 CUSHION GROUNDING PAD 1	10	Cushion Grounding Pad 1	0,09	LT22I		Xperia
1254-0946	LT22 CUSHION THERMAL INTERFACE	10	Cushion Thermal Interface Pad 2	0,075	LT22I		Xperia
1254-1011	LT22 CARRIER LCD FLEX SUPPORT	9	Carrier LCD Flex Support Assembly	0,255	LT22I		Xperia
1254-1164	LT26 NFC ANTENNA	7	NFC Antenna	3,495	LT26I		Xperia
1254-2975	MT27 LABEL	48	Label Mobile Phone	0,06	MT27I		Xperia
1254-3370	LT26 MAIN ANTENNA	6	Main Antenna	0,42	LT26I		Xperia
1254-3374	LT26 ANTENNA GPS BLACK	6	Ant GPS Black	0,21	LT26I		Xperia
1254-3412	LT22 CAP TOP BLACK	3	Cap Top Assembly Black	0,87	LT22I		Xperia
1254-3749	LT26 PBA BOTTOM	1	PBA Bottom	3,21	LT26I		Xperia
1254-3751	LT26 FPC MAIN	18	FPC Main Assy	19,935	LT26I		Xperia
1254-3969	LT22 COSMETIC SIDE SCREW GREY	15	Cosmetic side screw grey	0,09	LT22I		Xperia
1254-3993	LT22 CUSHION COND.GROUNDING	10	Cushion Conductive Grounding	0,03	LT22I		Xperia
1254-4525	LT26 CUSHION SPEAKER	15	Cushion Speaker	0,045	LT26I		Xperia
1254-4580	LT22 GASGET	10	Gasket	0,03	LT22I		Xperia
1254-4611	LT26 CARRIER VIBRATOR	10	Carrier Vibrator	0,06	LT26I		Xperia
1254-4648	LT26 FOIL ADH. AUDIO JACK	20	Foil Adhesive Audio Jack	0,015	LT26I		Xperia
1254-4654	LT26 FOIL ADH. SPEAKER	20	Foil Adhesive Speaker	0,015	LT26I		Xperia
1254-4665	LT26 SHEET LCD FPC	20	Sheet LCD FPC	0,045	LT26I		Xperia
1254-4672	LT26 CAP RF	10	Cap RF	0,075	LT26I		Xperia
1254-4708	LT22 COMPASS TAPE	10	Compass tape	0,03	LT22I		Xperia
1254-4913	ST27 CAMERA	5	Camera 5 MPixel CMOS	14,61	ST27I		Xperia
1254-5589	MT27 CAP BOTTOM BLACK	6	Cap Bottom Black	1,695	MT27I		Xperia
1254-5591	MT27 BATTERY COVER WHITE	4	Cover Battery White Matte	2,865	MT27I		Xperia
1254-7016	LT26 FOIL ADH.NFC PBA	20	Foil Adhesive NFC PBA	0,015	LT26I		Xperia
1254-7028	LT22 CAP COSMETIC CAP SILVER	6	Cap Cosmetic cap assy Silver	1,08	LT22I		Xperia
1254-7031	LT26 ON OFF KEY WHITE	9	Key On/Off White	0,93	LT26I		Xperia
1254-7035	LT26 CAMERA KEY WHITE	8	Key Camera White	0,87	LT26I		Xperia
1254-7042	LT26 VOLUME KEY WHITE	9	Key Volume White	1,005	LT26I		Xperia
1254-7045	LT26 SHEET NFC	10	Sheet NFC Shield	0,015	LT26I		Xperia
1254-7078	LT26 HDMI CAP WHITE	7	Cap HDMI White	0,405	LT26I		Xperia
1254-7082	LT26 SHEET GPS ANT.	20	Sheet GPS Ant	0,015	LT26I		Xperia
1254-7090	LT26 BOTTOM COVER WHITE	1	Cover Bottom White	1,62	LT26I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1254-7096	LT26 REAR COVER WHITE	2	Cover Rear Assy White	5,835	LT26I		Xperia
1254-7102	LT26 MICRO USB CAP WHITE	10	Cap Micro-USB White	0,405	LT26I		Xperia
1254-8248	LT26 FOIL ADH.GPS ANT.	20	Foil Adhesive GPS Ant	0,03	LT26I		Xperia
1255-1182	LT26 PBA NFC	4	PBA NFC	19,47	LT26I		Xperia
1255-4136	C6603 WATER INDICATOR	10	Water Indicator	0,03	C6603		Xperia
1255-5039	ST27 BACK HAUSING BLACK 1,8	5	Back Housing Assy Band18 Black	12,855	ST27I		Xperia
1255-5117	ST27 BATTERY COVER BLACK	3	Battery Cover Assy Black	5,865	ST27I		Xperia
1255-5221	ST27 MICRO USB CAP BLACK	3	Micro USB Cap Black	1,155	ST27I		Xperia
1255-5227	ST27 AUDIO JACK CAP BLACK	7	Audio Jack Cap Black	1,155	ST27I		Xperia
1255-5243	ST27 SIM READER	26	SIM Drawer	1,425	ST27I		Xperia
1255-5246	ST17 RECEIVER ADHESIVE	50	Receiver Adhesive	0,03	ST17I		Xperia
1255-7685	ST27 VIBRATOR MAIN MİC VOL KEY	4	Vibrator Main Mic Volume key FPC	3,93	ST27I		Xperia
1255-7689	ST27 AUDIO JACK FPC	5	Audio Jack FPC	1,44	ST27I		Xperia
1256-0847	ST27 CONN.AUDIO JACK 6P	4	Conn Audio Jack 6p	0,63	ST27I		Xperia
1256-1440	ST25 ANTENNA CAP PINK	9	Antenna Cap Pink	0,9	ST25I		Xperia
1256-1441	ST25 ANTENNA CAP YELLOW	9	Antenna Cap Yellow	0,9	ST25I		Xperia
1256-2138	LT28 KEY ON/OFF	2	Key On/Off	1,065	LT28I		Xperia
1256-2141	LT28 KEY VOLUME	5	Key Volume	1,14	LT28I		Xperia
1256-2145	LT28 KEY CAMERA	2	Key Camera	1,065	LT28I		Xperia
1256-3303	ST27 SCREW	50	Screw Other Len:2.0 Diam:1.4	0,03	ST27I		Xperia
1256-6730	LT26 SCREW	50	Screw 6.0x1.4	0,015	LT26I		Xperia
1256-9365	MT27 BATTERY COVER RED	3	Cover Battery Red	3,045	MT27I		Xperia
1256-9823	LT22 FRONT GROMMET	11	Front Grommet Assembly	0,15	LT22I		Xperia
1257-1151	LT26 CARRIER HOLDER BOTTOM	5	Carrier Holder Bottom	0,09	LT26I		Xperia
1257-1153	LT26 REAR FRAME WHITE	10	Rear Frame Assy White	2,1	LT26I		Xperia
1257-1357	LT26 SHEET NFC FPC	10	Sheet NFC FPC	0,015	LT26I		Xperia
1257-1394	LT22 SCREW	72	Screw Other Len:0.0 Diam:0.0 Screw Black	0,03	LT22I		Xperia
1257-2754	LT26 CUSHION MAIN CAMERA	20	Cushion Main Camera1	0,03	LT26I		Xperia
1257-3755	LT26 CUSHION SUB PBA	20	Cushion Sub PBA	0,015	LT26I		Xperia
1261-1813	LT22 COSMETIC SIDE SCREW BLACK	5	Cosmetic side screw black	0,63	LT22I		Xperia
1261-3591	ST23 RF CABLE	14	RF Cable	0,12	ST23I		Xperia
1261-3811	LT26 SCREW	16	Screw 3.5x1.4 M	0,015	LT26I		Xperia
1261-6359	LT26 WATER IND.	17	Water Indicator L	0,045	LT26I		Xperia
1261-6773	LT26 SHEET RALAY FPC	20	Sheet Relay FPC	0,015	LT26I		Xperia
1261-7648	ST27 SCREW	48	Screw Other Len:4.2 Diam:1.7 selftap	0,03	ST27I		Xperia
1261-9125	ST25 TOUCH PANEL	2	Touch Panel Glass Window 3.5 with Gasket	34,14	ST25I		Xperia
1261-9201	LT22 VIBRATOR GASGET	10	Gasket Vibrator	0,03	LT22I		Xperia
1261-9301	LT26 FOIL ADH.TRANSPARENT FRON	10	Foil Adhesive Transparent Front	0,075	LT26I		Xperia
1262-0804	ST27 EARSPEAKER	30	Ear Speaker 12.0 Rectangular Waterproof	1,245	ST27I		Xperia
1262-1909	ST27 BACK HOUSING 1,8 WHITE	10	Back Housing Assy Band18 White	12,855	ST27I		Xperia
1262-1940	ST27 MICRO USB CAP WHITE	4	Micro USB Cap White	1,155	ST27I		Xperia
1262-1947	ST27 AUDIO JACK CAP WHITE	3	Audio Jack Cap White	1,155	ST27I		Xperia
1262-1956	ST27 BATTERY COVER WHITE	7	Battery Cover Assy White	6,39	ST27I		Xperia
1262-3081	C6603 EARSPEAKER	34	Ear Speaker 12.0 Rectangular_WR	1,125	C6603		Xperia
1262-3217	MT27 FRONT BLACK	2	Cover Front Black	53,535	MT27I		Xperia
1262-4143	LT26 CUSHION VİB.	20	Cushion Vib	0,015	LT26I		Xperia
1262-5032	BA-600 BATARYA	10	BA600/Std Battery/Global/Bag	22,5			eski modeller
1262-6718	LT22 LCD PRESSURE INSERT	1	LCD Pressure Insert	209,265	LT22I		Xperia
1262-7321	LT22 GASGET COND. LMU SHIELD C	10	Gasket 7x2.2 Conductive LMU Sheild Can	0,03	LT22I		Xperia
1262-9832	LT22 GASGET	10	Gasket 3.4 x 3.4 Conductive HDMI Shield	0,03	LT22I		Xperia
1263-0209	ST23 DECO BLACK	12	Deco Black	2,175	ST23I		Xperia
1263-0211	ST23 BAT.COVER BLACK	7	Cover Battery Assy Black	2,58	ST23I		Xperia
1263-0213	ST23 ON OFF KEY BLACK	12	Key Power Black	0,345	ST23I		Xperia
1263-0214	ST23 VOLUME KEY BLACK	15	Key Volume Black	0,345	ST23I		Xperia
1263-2974	MT27 SCREW	50	Screw Torx 5.0 x 1.4	0,03	MT27I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1263-6090	ST26 SIDE SLIDE MICRO SIM ADAP	5	Side slide type micro-SIM adapter	0,345	ST26I		Xperia
1263-6203	MH750 PHF	21	MH750/Stereo Headset/Exchange Unit/Black	7,5			eski modeller
1263-8998	LT28 SIM TRAY	30	SIM Tray	0,195	LT28I		Xperia
1264-0456	C6603 FPC ASS RELAY FPC	21	FPC Assembly Relay FPC	5,46	C6603		Xperia
1264-1968	ST26 FPC LINK	2	Link FPC	2,04	ST26I		Xperia
1264-1977	ST26 SIM SD SIDE KEY FPC	3	SIM SD Side Key FPC	4,935	ST26I		Xperia
1264-2020	MH410C PHF BLACK	9	MH410C/Exchange Accessory/Blck/Blck	9			eski modeller
1264-2341	C6603 VIBRATOR	3	Vibrator	2,19	C6603		Xperia
1264-3045	C6603 SIM TRAY	168	SIM Tray	0,09	C6603		Xperia
1264-3212	MT27 BATTERY FOIL	95	Foil Battery Protection	0,12	MT27I		Xperia
1264-3311	LT28 LCD SİYAH	2	Cover Front Assy Black	167,7	LT28I		Xperia
1264-3819	ST23 DECO SILVER	14	Deco Silver	2,175	ST23I		Xperia
1264-3866	LT22 TOUCH FLEX SHIELDING	14	Touch Flex Shielding	0,3	LT22I		Xperia
1264-4018	ST27 SCREW	46	Screw Other Len:0.0 Diam:1.4 water proof	0,075	ST27I		Xperia
1264-4353	C6603 MESH RECEIVER	25	Mesh Receiver	0,03	C6603		Xperia
1264-4354	C6603 ADHESİVE RECEİVER	25	Adhesive Receiver	0,03	C6603		Xperia
1264-4357	C6603 ADHESİVE DOUBLE SİDE	25	Adhesive Double Side 0.0 mmWP Speaker	0,03	C6603		Xperia
1264-4366	C6603 MCOMP SHEET THERMAL COND	10	MComp Sheet Thermal Conductive	0,375	C6603		Xperia
1264-4370	C6603 ADHESİVE CONDUCTİVE LCD	25	Adhesive Conductive LCD	0,135	C6603		Xperia
1264-4373	C6603 ADHESİVE CONDUCTİVE LCD2	25	Adhesive Conductive LCD 2	0,06	C6603		Xperia
1264-4375	C6603 ADHESİVE BATTERY 1	10	Adhesive Battery1	0,27	C6603		Xperia
1264-4414	C6603 PLATE SİDE KEY	25	Plate Side Key	0,105	C6603		Xperia
1264-4419	C6603 COVER PANEL TOP BLACK	24	Cover Panel Top Black	1,005	C6603		Xperia
1264-4420	C6603 COVER PANEL BOTTOM BLACK	10	Cover Panel Bottom Black	1,095	C6603		Xperia
1264-4425	C6603 FOİL ADHESİVE BACK PANEL	12	Foil Adhesive Back Panel	1,44	C6603		Xperia
1264-4531	C6603 ADHESİVE WP TEST HOLE	10	Adhesive WP Test Hole	0,03	C6603		Xperia
1264-4532	C6603 SHEET WP TEST HOLE	10	Sheet WP Test Hole	0,3	C6603		Xperia
1264-4535	C6603 COVER WP TEST HOLE	10	Cover WP Test Hole	0,18	C6603		Xperia
1264-5384	ST26 COAXIAL CABLE	4	Coaxial Cable	0,705	ST26I		Xperia
1264-6466	C6603 CAMERA 13 MPİXEL CMOS	17	Camera 13 MPixel CMOS	19,305	C6603		Xperia
1264-7064	C6603 BATARYA	1	Battery 2330.0 mAh	10,785	C6603		Xperia
1264-7408	LT28 FRAME REAR BLACK ROW	6	Frame Rear Assy Black RoW	7,425	LT28I		Xperia
1264-7611	LT28 PBA SUB ANTENNA ROW	5	PBA Sub Antenna Assy RoW	3,165	LT28I		Xperia
1264-7805	C6603 SCREW OTHER LEN2.6 D:1.4	100	Screw Other Len:2.6 Diam:1.4 M	0,03	C6603		Xperia
1264-8162	C6603 CABLE RF COAX CABLE	30	Cable RF Coax Cable, ASSY	0,495	C6603		Xperia
1264-8191	ST27 FRONT BLACK	6	Cover Front Housing Display Assy Black	97,17	ST27I		Xperia
1264-8198	ST27 FRONT COVER BEYAZ	1	Cover Front Housing Display Assy White	97,335	ST27I		Xperia
1264-8553	LT22 SCREW	20	Screw Phillips Len:3.0 Diam:1.2	0,015	LT22I		Xperia
1264-8816	C6603 FOİL ADHESİVE DOUBLE WHI	25	Foil Adhesive Double White	0,06	C6603		Xperia
1264-8926	MT27 SCREW	46	Screw M1.4x2.8	0,03	MT27I		Xperia
1264-8931	MT27 FOIL BAT. FLEX LID	183	Foil Battery Flex Lid	0,03	MT27I		Xperia
1265-1718	MH650C PHF BLACK	36	MH650c/Exchange Accessory/Black	15			eski modeller
1265-1720	MH650C PHF BEYAZ	1	MH650c/Exchange Accessory/White	15			eski modeller
1265-2260	ST23 BAT.COVER WHITE	6	Cover Battery Assy White	3,24	ST23I		Xperia
1265-2291	ST23 ON OFF KEY WHITE	5	Key Power White	0,345	ST23I		Xperia
1265-2295	ST23 VOLUME KEY WHITE	5	Key Volume White	0,345	ST23I		Xperia
1265-3119	ST26 REAR COVER	4	Rear Cover	4,755	ST26I		Xperia
1265-3121	ST26 BAT COVER WHITE	5	Battery Cover White	2,22	ST26I		Xperia
1265-3122	ST26 SIDE KEY	5	Side Key	0,555	ST26I		Xperia
1265-3124	ST26 BAT COVER BLACK	5	Battery Cover Black	2,595	ST26I		Xperia
1266-8150	ST23 REAR COVER	5	Rear Cover Assy Band 18 Black	2,19	ST23I		Xperia
1266-8448	ST23 SCREW (T5) M1.6*L3.8	50	Screw (T5) M1.6*L3.8	0,03	ST23I		Xperia
1266-8451	ST23 SCREW M1.6*L2.6	50	Screw M1.6*L2.6	0,03	ST23I		Xperia
1266-8453	ST23 RUBBER MIC	25	Rubber Mic	0,09	ST23I		Xperia
1266-8455	ST23 RUBBER CAP	25	Rubber Cap	0,135	ST23I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
1266-8458	ST23 RUBBER PROXIMITY SENSOR	25	Rubber Proximity Sensor	0,075	ST23I		Xperia
1267-0214	C6603 FPC ASSEMBLY TOP ROW	6	FPC Assembly Top RoW	3,915	C6603		Xperia
1267-1585	C6603 ADHESIVE BATTERY 2	10	Adhesive Battery 2	0,045	C6603		Xperia
1267-2113	C6603 PBA SUB ROW	6	PBA Sub RoW	1,995	C6603		Xperia
1267-2148	LT28 RUBBER MIC	100	Rubber Mic	0,12	LT28I		Xperia
1267-2522	C6603 SHEET BATTERY FPC	10	Sheet Battery FPC	0,03	C6603		Xperia
1267-2560	C6603 ADHESIVE FPC A	25	Adhesive FPC A	0,03	C6603		Xperia
1267-2567	C6603 ADHESIVE FPC B	25	Adhesive FPC B	0,03	C6603		Xperia
1267-2575	C6603 FPC ADHESIVE	75	Adhesive FPC	0,03	C6603		Xperia
1267-3404	C6603 COVER PANEL TOP WHITE	25	Cover Panel Top White	1,005	C6603		Xperia
1267-3456	C6603 COVER PANEL BOTTOM WHITE	26	Cover Panel Bottom White	1,095	C6603		Xperia
1267-3914	C6603 ANT DIVERSITY FLEX ROW	9	Ant Diversity Flex RoW	0,78	C6603		Xperia
1267-3920	C6603 ANT MAIN FLEX ROW	6	Ant Main Flex RoW	1,44	C6603		Xperia
1267-4894	C6603 FOIL ADHESIVE DOUBLE BLC	25	Foil Adhesive Double Black	0,06	C6603		Xperia
1267-5631	C6603 FOIL ADHESIVE DOUBLESIDE	25	Foil Adhesive Double Side 0.0 mmWP	0,03	C6603		Xperia
1267-5633	C6603 CARRIER HOLDER 1ST MIC	21	Carrier Holder 1st Mic	0,105	C6603		Xperia
1268-1637	EP881/FASTER CHARGER/EU4//BOX	50	EP881/Faster Charger/EU4//Box/	16,5			eski modeller
1268-2281	C6603 MH-EX300AP	6	MH-EX300AP	6,375	C6603		Xperia
1268-9710	C6603 COVER CON VIBRATOR	25	Cover Con Vibrator	0,12	C6603		Xperia
1269-2608	C6603 COVER PANEL TOP PURPLE	15	Cover Panel Top Purple	1,005	C6603		Xperia
1269-2649	C6603 COVER PANEL BOTTOM PURPL	10	Cover Panel Bottom Purple	1,095	C6603		Xperia
1269-3648	C6603 SHEET BTB LCD	25	Sheet BtB LCD	0,03	C6603		Xperia
1270-2876	C6603 CARRIER HOLDER COAX CABL	25	Carrier Holder Coax Cable	0,24	C6603		Xperia
1270-3731	C6603 CUSHION BATTERY BOTTOM	25	Cushion Battery Bottom	0,03	C6603		Xperia
1270-3738	C6603 MCOMP SHEET RELAY FPC	25	MComp Sheet relay FPC	0,03	C6603		Xperia
1270-5858	C6603 FOIL ADH.DOUBLE PURPLE	15	Foil Adhesive Double Purple	0,06	C6603		Xperia
1270-5875	C6603 CUPPER SHEET MCAMA	25	Cupper Sheet McamA	0,225	C6603		Xperia
1270-5884	C6603 CUPPER SHEET MCAMB	25	Cupper Sheet McamB	0,03	C6603		Xperia
1270-6755	ST21 SPEAKER	28	Speaker	0,42	C6603		Xperia
1271-7822	EC802 MUSB	25	EC802/µUSB/Exch Acc/ROW	9			eski modeller
1272-0786	C6603 FRONT BLACK	1	Front Assembly Black RoW	238,26	C6603		Xperia
1272-0789	FRONT WHITE	5	Front Assembly White RoW	238,26			eski modeller
1272-0794	C6603 FRONT ASS. PURPLE	4	Front Assembly Purple RoW	238,26	C6603		Xperia
1272-2162	C6603 BACK PANEL BLACK	1	Back Panel Assy Black C6603	16,56	C6603		Xperia
1272-2206	C6603 BACK PANEL ASS WHITE	2	Back Panel Assy White C6603	53,43	C6603		Xperia
1272-4944	C6603 CAP AUDIO JACK ASS R BLA	10	Cap Audio Jack Assy R Black	1,92	C6603		Xperia
1272-4945	C6603 CAP AUDIO JACK ASSR WHIT	16	Cap Audio Jack Assy R White	1,95	C6603		Xperia
1272-4948	C6603 CAP AUDIO JACK ASS PURPL	14	Cap Audio Jack Assy R Purple	1,92	C6603		Xperia
1272-4956	C6603 CAP USB ASS R BLACK	4	Cap USB Assy R Black	1,875	C6603		Xperia
1272-4958	C6603 USB ASS R WHITE	16	Cap USB Assy R White	1,89	C6603		Xperia
1272-4959	C6603 CAP USB R PURPLE	13	Cap USB Assy R Purple	1,875	C6603		Xperia
1272-4964	C6603 CAP SD BLACK	6	Cap SD Assy R Black	1,92	C6603		Xperia
1272-4965	C6603 CAP SD ASS R WHITE	15	Cap SD Assy R White	1,95	C6603		Xperia
1272-4966	C6603 CAP SD R PURPLE	14	Cap SD Assy R Purple	1,92	C6603		Xperia
1272-4970	C6603 CAP SIM ASS R BLACK	14	Cap SIM Assy R Black	1,965	C6603		Xperia
1272-4973	C6603 CAP SIM ASS R WHITE	17	Cap SIM Assy R White	1,995	C6603		Xperia
1272-4979	C6603 CAP SIM R PURPLE	14	Cap SIM Assy R Purple	1,965	C6603		Xperia
1272-7680	C6603 SHEET TP FPC	25	Sheet TP FPC	0,03	C6603		Xperia
196BE90000A	ST21 BATTERY COVER	4	BATTERY COVER BLACK	2,37	ST21I		Xperia
199BE90003A	ST21 FRAME ANTENNA S-SIM	9	FRAME ANTENNA ASSY S-SIM	1,455	ST21I		Xperia
310AFM1200F	ST23 SUB BOARD ASS BAND 18	2	Sub Board Assy Band 18	4,845	ST23I		Xperia
312AFM24C0F	ST23 FPC LINK	2	FPC Link	1,725	ST23I		Xperia
312AFM26C0D	ST23 SIM FPC	3	FPC SIM SD	3,405	ST23I		Xperia
31TEAU1000B	W205 PCB NAVIGATION	22	PCB Navigation	2,025	W205	2009	Xperia öncesi yeniler
35051002C00	ST21 LCD	4	LCD TFT 3.2Inch	17,895	ST21I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
405-22580-0011	W150 BATTERY COVER BLACK	5	Battery Cover Black	1,995	W150I	2011	Xperia öncesi yeniler
455BE90110A	ST21 RUBBER İNDICATOR	25	Cap Rubber for Indicator	0,075	ST21I		Xperia
468BE900600	ST21 CAMERA LENS	5	CAMERA LENS	0,3	ST21I		Xperia
475GUA0010A	ST21 CAMERA 2MP	9	Camera CMOS 2MPix	6,735	ST21I		Xperia
56BAFM00000	ST23 ADHESIVE SPEAKER	50	Adhesive Speaker	0,045	ST23I		Xperia
56BAFM00006	ST23 ADHESIVE RECEIVER	25	Adhesive Receiver	0,03	ST23I		Xperia
620K00D1005	ST21 AUDIO JACK	9	AUDIO JACK	0,48	ST21I		Xperia
A/303-1000-00293	T303 CHIP FERRITE	5	Chip Ferrite bead array 47 Ohm	0,075			eski modeller
A/303-1000-00350	S312 EMI FILTER	5	EMI Filter	0,21	S312	2009	Xperia öncesi yeniler
A/308-0000-00012	R300 VARISTOR	5	Varistor 9.0V	0,015			eski modeller
A/308-0000-00019	T303 VARISTOR	10	Varistor 5.5V	0,015			eski modeller
A/308-0000-00054	T303 VARISTOR 18V	10	Varistor 18V	0,015			eski modeller
A/308-0000-00055	T250 D101 PROTECTION DIOD	11	TVS Diode 5.0V 45pF	0,06			eski modeller
A/308-0000-00057	T250 D12 PROTECTION DIOD	13	Protection diod	0,045			eski modeller
A/308-0000-00075	S312 VARISTOR	5	Varistor	0,015	S312	2009	Xperia öncesi yeniler
A/308-0000-00078	T303 VARISTOR 14V	5	Varistor 14V	0,015			eski modeller
A/308-0000-00083	R300 TVS DIODE	5	TVS Diode 5.0V 100pF	0,015			eski modeller
A/308-0000-00102	R300 VARISTOR	4	Varistor 5.5V	0,015			eski modeller
A/308-0000-00125	T303 DIODE 5,0 V	5	Diode Protection 5.0V	0,015			eski modeller
A/308-0000-00126	K330/S312 DIODE	10	TVS Diode 24V 50pF	0,06	S312	2009	Xperia öncesi yeniler
A/308-0000-00130	S312 VARISTOR	5	Varistor	0,015	S312	2009	Xperia öncesi yeniler
A/308-0000-00159	S312 VARISTOR	5	Varistor	0,045	S312	2009	Xperia öncesi yeniler
A/309-0000-00129	S312 FLASH LED	5	Flash LED	0,135	S312	2009	Xperia öncesi yeniler
A/309-0000-00133	S312 DIODE	5	Schottky Diode	0,045	S312	2009	Xperia öncesi yeniler
A/311-0000-00019	K220 FM MODULE	1	FM module	1,2			eski modeller
A/311-0000-00348	T250 AUDIO AMPLIFIER	11	Audio Amplifier	0,33			eski modeller
A/311-0000-00402	T250 CHARING PUMP	5	Illumination pump	0,39			eski modeller
A/311-0000-00530	K330 IC	3	IC FM Radio Module	0,975			eski modeller
A/311-0000-00714	S312 FM RADIO	3	FM RADIO	0,96	S312	2009	Xperia öncesi yeniler
A/311-0000-00728	S312 LEVEL SHIFTER	5	Level Shifter	0,285	S312	2009	Xperia öncesi yeniler
A/313-0000-00017	T250 EARPHONE	7	Ear Speaker 10x5.0mm Spring	0,63			eski modeller
A/313-0000-00023	T250 LOUDSPEAKER	8	Loud Speaker	0,75			eski modeller
A/313-0000-00056	K330 LOUDSPEAKER	5	Loudspeaker 16mm Circular	0,525			eski modeller
A/313-0000-00077	R300 LOUDSPEAKER	25	Loudspeaker 18mm Circular	0,645			eski modeller
A/313-0000-00115	S312 EARSPEAKER	4	Ear Speaker	0,675	S312	2009	Xperia öncesi yeniler
A/313-0000-00131	S312 EAR SPAEKAR	10	Ear Speaker	0,675	S312	2009	Xperia öncesi yeniler
A/314-0000-00079	T250 CON BTB LCD	6	FPC Connector Display 33pin	0,585			eski modeller
A/314-0000-00084	S312 BATTERY CON	17	Battery connector	0,345	S312	2009	Xperia öncesi yeniler
A/314-0000-00085	T250 ANTENNA CON	44	Antenna connector (1 pin Pogo)	0,21			eski modeller
A/314-0000-00190	K330 BTB CONN	5	BtB Connector Keyboard 20pin	0,21			eski modeller
A/314-0000-00192	R300 SIM CONN.	12	SIM Connector	0,18			eski modeller
A/314-0000-00196	R300 BATTERY CONN.	2	Battery Connector 5pin	0,225			eski modeller
A/314-0000-00201	K330 SIM CONN.	5	SIM Connector	0,225			eski modeller
A/314-0000-00228	R300 POGOPIN CONN.BT ANTENNA	5	Pogopin Connector Bluetooth Antenna	0,195			eski modeller
A/314-0000-00229	R300 SPRING CONNECTOR ANTENNA	5	Spring Connector Antenna	0,075			eski modeller
A/314-0000-00233	T303 BTB CONNECTOR HINGE FPC	5	BtB Connector Hinge FPC	0,54			eski modeller
A/314-0000-00234	T303 BATTERY CONNECTOR 5 PIN	5	Battery Connector 5pin	0,285			eski modeller
A/314-0000-00248	T303 KEYPAD CONNECTOR	5	Keypad connector	0,225			eski modeller
A/314-0000-00263	R300 SPRING CONN.	5	Spring Connector	0,06			eski modeller
A/314-0000-00267	K330 CAMERA SOCKET	5	Camera Socket 20pin	0,36			eski modeller
A/314-0000-00372	S312 RF CONN	5	RF Connector	0,12	S312	2009	Xperia öncesi yeniler
A/314-0000-00374	S312 BTB CONN	5	BtB Connector	0,225	S312	2009	Xperia öncesi yeniler
A/314-0000-00379	S312 SISTEM CONN	18	System Connector	0,21	S312	2009	Xperia öncesi yeniler
A/314-0000-00443	W100 FPC CONN. 41P	3	Conn FPC 41p	0,33	W100I	2011	Xperia öncesi yeniler
A/314-0000-00447	W100 MICRO USB CONN.	4	Micro USB Connector	0,15	W100I	2011	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
A/314-0000-00453	W10 AUDIO JACK	4	Audio Jack	0,195			eski modeller
A/314-0000-00454	W100 SPEAKER CONN.	5	Speaker Connector	0,045	W100I	2011	Xperia öncesi yeniler
A/314-0000-00484	W100 MICRO SD CARD CONN.	5	Micro SD Card Connector	0,24	W100I	2011	Xperia öncesi yeniler
A/315-0000-00009	R300 SIDE PUSH SWITCH	15	Side Push Switch	0,165			eski modeller
A/315-0000-00047	W150 SIDE KEY SWITCH	25	Side Key Switch	0,165	W150I	2011	Xperia öncesi yeniler
A/320-0000-00030	S312 VIBRATOR	7	Vibrator	0,675	S312	2009	Xperia öncesi yeniler
A/321-0000-00139	R300 FPC PRESET KEY	16	FPC Preset Key	0,36			eski modeller
A/321-0000-00292	W100 HINGE FPC	14	Hinge FPC	0,51	W100I	2011	Xperia öncesi yeniler
A/327-0000-00021	T250 LCD	7	Display 1.7" TFT	9,225			eski modeller
A/327-0000-00061	S312 LCD	9	Display 2,0"	11,955	S312	2009	Xperia öncesi yeniler
A/330-0000-00026	T250 ANTENNA ASS 900 MHZ	10	Antenna Asembly 900 MHz	0,48			eski modeller
A/330-0000-00053	K330 BT ANTENNA	5	Bluetooth Antenna	0,165			eski modeller
A/330-0000-00067	R300 ANTENNA MAIN	7	Antenna Main 900 Assy	3,045			eski modeller
A/330-0000-00068	R300 ANTANNA 850	4	Antenna Main 850 Assy	3,045			eski modeller
A/330-0000-00131	S312 CARRIER BT	4	Carrier BT	0,345	S312	2009	Xperia öncesi yeniler
A/330-0000-00234	CK13 MAIN ANTENNA	10	Main Antenna Assy	0,435	CK13I		Xperia
A/335-0000-00037	R300 CAMERA VGA	1	Camera VGA CMOS	3,615			eski modeller
A/335-0000-00048	K330 CAMERA VGA	2	Camera VGA CMOS	3,315			eski modeller
A/335-0000-00064	S312 CAMERA	3	Camera	6,42	S312	2009	Xperia öncesi yeniler
A/401-22710-0007	W100 UPPER FRONT WHITE SILVER	3	Upper Front Cover Assy White,Silver Logo	2,79	W100I	2011	Xperia öncesi yeniler
A/401-22710-0008	W100 UPPER FRONT BLACK SIL.LOG	5	Upper Front Cover Assy Black,Silver Logo	2,79	W100I	2011	Xperia öncesi yeniler
A/401-22710-0011	W100 UPPER RAR COVER WHITE	2	Upper Rear Cover Assy White	1,515	W100I	2011	Xperia öncesi yeniler
A/401-22710-0012	W100 UPPER REAR COVER BLACK	8	Upper Rear Cover Assy Black	1,515	W100I	2011	Xperia öncesi yeniler
A/401-22830-0001	S312 FRONT COVER BLUE	1	Front Cover Blue	3,51	S312	2009	Xperia öncesi yeniler
A/401-22830-0002	S312 FRONT COVER SILVER	2	Front Cover Silver	3,51	S312	2009	Xperia öncesi yeniler
A/402-22580-0002	W150 REAR COVER BLACK	4	Rear Cover Assy Black, 900	1,89	W150I	2011	Xperia öncesi yeniler
A/402-22710-0001	W100 LOWER REAR COVER WHITE	3	Lower Rear Cover Assy White, 900	1,41	W100I	2011	Xperia öncesi yeniler
A/402-22710-0004	W100 LOWER FRONT FRAME	8	Lower Front Frame	0,345	W100I	2011	Xperia öncesi yeniler
A/402-22710-0006	W100 LOWER REAR COVER BLACK	10	Lower Rear Cover Assy Black, 900	1,29	W100I	2011	Xperia öncesi yeniler
A/402-23290-0001	CK13 REAR COVER BLACK&SILVER	4	Rear Cover Assy Black&Silver	3,12	CK13I		Xperia
A/403-22580-0001	W150 CAMERA WINDOW	4	Camera Window	0,375	W150I	2011	Xperia öncesi yeniler
A/403-22610-0003	T303 CAMERA WINDOW	5	Camera Window	0,54			eski modeller
A/403-22710-0001	W100 CAMERA WINDOW	33	Camera Window	0,24	W100I	2011	Xperia öncesi yeniler
A/403-23290-0002	CK13 CAMERA WINDOW	5	Camera Window	0,195	CK13I		Xperia
A/404-22360-0003	R300 BOOST KEY	10	Boost Key	0,48			eski modeller
A/404-22360-0004	R300 PRESET KEY	14	Preset Key	0,66			eski modeller
A/404-22580-0001	W150 HOME KEY SILVER	2	Home Key Silver	0,45	W150I	2011	Xperia öncesi yeniler
A/404-22580-0002	W150 POWER LOCK KEY BLACK	5	Power/Lock Key Black	0,195	W150I	2011	Xperia öncesi yeniler
A/404-22580-0003	W150 VOLUME KEY BLACK	5	Volume Key Black	0,195	W150I	2011	Xperia öncesi yeniler
A/404-22610-0001	T303 FUNCTION KEYBOARD SILVER	6	Function Keyboard Silver	1,56			eski modeller
A/404-22610-0002	T303 KEYBOARD LATIN SILVER	4	Keyboard Latin Silver	1,185			eski modeller
A/404-22610-0003	T303 KEYBOARD LATIN BLACK	11	Keyboard Latin Black	1,455			eski modeller
A/404-22610-0004	T303 FUNCTION KEYBOARD BLACK	9	Function Keyboard Black	1,92			eski modeller
A/404-22710-0001	W100 MAIN KEYPAD BLACK	7	Main Keypad Latin Black	1,605	W100I	2011	Xperia öncesi yeniler
A/404-22710-0002	W100 VOLUME KEY WHITE	5	Volume key White	0,165	W100I	2011	Xperia öncesi yeniler
A/404-22710-0003	W100 SUB KEYPAD WHITE,BLACK RI	2	Sub Keypad White, Black Ring	1,56	W100I	2011	Xperia öncesi yeniler
A/404-22710-0009	W100 SUB KEYPAD BLACK,SILVER R	13	Sub Keypad Black, Silver Ring	1,56	W100I	2011	Xperia öncesi yeniler
A/404-22710-0010	W100 VOLUME KEY BLACK	4	Volume key Black	0,165	W100I	2011	Xperia öncesi yeniler
A/404-22710-0076	W100 MAIN KEYPAD WHITE	5	Main Keypad Latin White	1,47	W100I	2011	Xperia öncesi yeniler
A/404-22710-0077	W100 SUB KEYPAD WHITE,SILVER R	2	Sub Keypad White, Silver Ring	1,44	W100I	2011	Xperia öncesi yeniler
A/404-22830-0009	S312 VOLUME KEY SILVER	9	Volume Key Silver	0,255	S312	2009	Xperia öncesi yeniler
A/404-22830-0010	S312 CAMERA KEY GREEN	1	Camera Key Green	0,6	S312	2009	Xperia öncesi yeniler
A/404-22830-0019	S312 VOLME KEY GREY	4	Volume Key Grey	0,255	S312	2009	Xperia öncesi yeniler
A/404-22830-0020	S312 CAMERA KEY GOLD	3	Camera Key Gold	0,6	S312	2009	Xperia öncesi yeniler
A/404-22830-0048	S312 KEYBOARD BLUE	9	Keyboard Latin Blue	3,645	S312	2009	Xperia öncesi yeniler

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
A/404-22830-0056	S312 KEYBOARD SILVER	5	Keyboard Latin Silver	3,885	S312	2009	Xperia öncesi yeniler
A/404-23290-0005	CK13 VOLUME KEY BLACK	3	Volume Key Black	0,285	CK13I		Xperia
A/404-23290-0006	CK13 VOLUME KEY WHITE	4	Volume Key White	0,285	CK13I		Xperia
A/404-23290-0053	CK13 KEYPAD BLACK	6	QWERTY Keypad Latin Black	3,39	CK13I		Xperia
A/404-23290-0054	CK13 KEYPAD WHITE	5	QWERTY Keypad Latin White	3,39	CK13I		Xperia
A/405-22610-0001	T303 TOP REAR COVER SILVER	3	Top Rear Cover Silver	0,525			eski modeller
A/405-22610-0004	T303 BATTERY COVER SILVER	4	Battery Cover Silver	1,71			eski modeller
A/405-22610-0005	T303 BATTERY COVER BLACK	4	Battery Cover Black	1,71			eski modeller
A/405-22610-0006	T303 TOP REAR COVER BLACK	4	Top Rear Cover Black	0,57			eski modeller
A/405-22710-0005	W100 BATTERY COVER BLACK	3	Battery Cover Black	0,51	W100I	2011	Xperia öncesi yeniler
A/405-22710-0008	W100 BAT. COVER CO-BRAND BLACK	4	Battery Cover Cobranding Black	1,14	W100I	2011	Xperia öncesi yeniler
A/405-22710-0012	W100 BATTERY COVER WHITE	4	Battery Cover White	0,645	W100I	2011	Xperia öncesi yeniler
A/405-22830-0017	S312 CO BRAND BLUE	31	Co-Brand Blue S312	0,435	S312	2009	Xperia öncesi yeniler
A/405-22830-0018	S312 CO BRAND SILVER	3	Co-Brand Silver S312	0,435	S312	2009	Xperia öncesi yeniler
A/405-23290-0001	CK13 BATTERY COVER BLACK	3	Battery Cover Assy Black	1,26	CK13I		Xperia
A/405-23290-0002	CK13 BATTERY COVER WHITE	2	Battery Cover Assy White	1,26	CK13I		Xperia
A/409-00000-0016	T250 SCREW	16	Screw Torx 6 Len:5 Diam:1.6 Black	0,015			eski modeller
A/409-00000-0050	T303 SCREW PHILIPS 4,5 DIAM 1,	20	Screw Philips Len:4.5 Diam:1.4 Silver	0,015			eski modeller
A/409-00000-0051	T303 SCREW PHILIPS 2,0 DIAM 1,	20	Screw Philips Len:2.0 Diam:1.4 Black	0,015			eski modeller
A/409-00000-0052	R300 SCREW	4	Screw Philips Len:4 Diam: 1.4 Black	0,015			eski modeller
A/409-00000-0080	S312 SCREW T6 BLACK	5	Screw T6 Black	0,015	S312	2009	Xperia öncesi yeniler
A/409-00000-0081	S312 SCREW T5 SILVER	5	Screw T5 Silver	0,015	S312	2009	Xperia öncesi yeniler
A/409-00000-0102	W100 SCREW	50	Screw 1.6mm_4mm	0,015	W100I	2011	Xperia öncesi yeniler
A/409-00000-0103	W100 SCREW	50	Screw 1.4mm_1.5mm	0,015	W100I	2011	Xperia öncesi yeniler
A/409-00000-0104	W100 SCREW 1,4 MM-3,5 MM	40	Screw 1.4mm_3.5mm	0,015	W100I	2011	Xperia öncesi yeniler
A/409-00000-0106	W150 SCREW	20	Screw	0,015	W150I	2011	Xperia öncesi yeniler
A/411-00000-0005	T303 SLIDE HINGE	6	Slide Hinge Assy	3,99			eski modeller
A/415-22310-0005	T250 CO-BRAND COVER ADHESIVE	5	Co brand Cover Adhesive	0,105			eski modeller
A/415-22310-0008	T250 GASKET LOADSPEAKER	5	Load Speaker Gasket	0,09			eski modeller
A/415-22310-0010	T250 GASKET SYSTEM CONNECTOR	5	Gasket System Connector	0,03			eski modeller
A/415-22310-0018	T250 SPONGE EARPHONE	6	Sponge Earphone	0,015			eski modeller
A/415-22310-0043	T250 ISOLATE TAPE	10	Isolate tape	0,015			eski modeller
A/415-22330-0007	K330 SHIELD CAN	3	Shield Can Lid	0,345			eski modeller
A/415-22360-0002	R300 SHIELD CAN	3	Shield Can Lid Main	0,36			eski modeller
A/415-22360-0003	R300 SHIELD CAN	5	Shield Can Lid Bluetooth	0,21			eski modeller
A/415-22360-0006	R300 SPONGE SYSTEM CONN.	5	Sponge System Connector	0,12			eski modeller
A/415-22360-0007	R300 SPONGE SPEAKER	5	Sponge Speaker Chamber Back	0,06			eski modeller
A/415-22360-0008	R300 SPONGE SPEAKER	5	Sponge Speaker Chamber Front	0,195			eski modeller
A/415-22360-0009	R300 SPONGE LCM	5	Sponge LCM BtB	0,045			eski modeller
A/415-22360-0010	R300 DOME SHETT PRESET KEY	4	Dome Sheet Preset Key	0,09			eski modeller
A/415-22360-0016	R300 GASGET CAMERA	2	Camera Gasket	0,045			eski modeller
A/415-22360-0022	R300 ESD METAL	2	ESD Metal	0,165			eski modeller
A/415-22580-0001	W150 HOME KEY DOME SHEET	9	Home Key Domesheet	0,12	W150I	2011	Xperia öncesi yeniler
A/415-22580-0019	W150 EAR SPEAKER SPONGE	10	Ear Speaker Sponge	0,015	W150I	2011	Xperia öncesi yeniler
A/415-22580-0020	W150 SPEAKER SPONGE	10	Speaker Sponge	0,015	W150I	2011	Xperia öncesi yeniler
A/415-22580-0021	W150 SPEAKER MESH BLACK	10	Speaker Mesh Black	0,015	W150I	2011	Xperia öncesi yeniler
A/415-22610-0003	T303 ANTI FRICTION BLOCK	5	Anti-Friction Block	0,075			eski modeller
A/415-22610-0004	T303 BOTTOM COVER U-SHAPE SILV	7	Bottom Cover U-Shape Silver	0,09			eski modeller
A/415-22610-0005	T303 BOTTOM COVER U-SHAPE BLAC	5	Bottom Cover U-Shape Black	0,075			eski modeller
A/415-22610-0006	T303 PLATING CAMERA SHEET SILV	4	Plating Camera Sheet Silver	0,525			eski modeller
A/415-22610-0012	T303 DAMPER STOPPER	12	Damper Stopper	0,165			eski modeller
A/415-22610-0013	T303 SYSTEM CONN. SPONGE	10	System Connector Sponge	0,03			eski modeller
A/415-22610-0016	T303 MICROPHONE SPONGE DUST NE	10	Microphone Sponge Dust Net	0,045			eski modeller
A/415-22610-0017	T303 MYLAR HINGE FPC	10	Mylar Hinge FPC	0,045			eski modeller
A/415-22610-0018	T303 MYLAR HINGE SCREW	20	Mylar Hinge Screw	0,015			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
A/415-22610-0023	T303 DAMPER CAMERA	10	Damper Camera	0,015			eski modeller
A/415-22610-0027	T303 MYLAR BATTERY LABEL	10	Mylar Battery Label	0,075			eski modeller
A/415-22610-0028	T303 PLATING CAMER.SHEET BLACK	10	Plating Camera Sheet Black	0,525			eski modeller
A/415-22610-0029	T303 CAMERA LENS ADHESIVE	10	Camera Lens Adhesive	0,03			eski modeller
A/415-22610-0031	T303 CONDUCTIVE RUBBER	5	Conductive Rubber	0,165			eski modeller
A/415-22610-0059	T303 SHIELD CAN LID BB	5	Shield Can Lid BB	0,165			eski modeller
A/415-22610-0061	T303 SHIELD CAN LID RF	5	Shield Can Lid RF	0,15			eski modeller
A/415-22710-0002	W100 MAIN KEYPAD DOMESHEET	8	Main Keypad Domesheet	0,225	W100I	2011	Xperia öncesi yeniler
A/415-22710-0003	W100 SUB KEYPAD DOMESHEET	23	Sub Keypad Domesheet	0,195	W100I	2011	Xperia öncesi yeniler
A/415-22710-0004	W100 SPEAKER MESH BLACK	58	Speaker Mesh Black	0,03	W100I	2011	Xperia öncesi yeniler
A/415-22710-0005	W100 LCM FPC CONN.MYLAR	37	LCM FPC Connector Mylar	0,015	W100I	2011	Xperia öncesi yeniler
A/415-22710-0009	W100 SPONGE MIC.	40	MIC Sponge	0,06	W100I	2011	Xperia öncesi yeniler
A/415-22710-0010	W100 DECO SHEET WHITE	15	Deco Sheet White	0,615	W100I	2011	Xperia öncesi yeniler
A/415-22710-0011	W100 SPEAKER MESH WHITE	7	Speaker Mesh White	0,03	W100I	2011	Xperia öncesi yeniler
A/415-22710-0013	W100 DECO SHEET BLACK	19	Deco Sheet Black	0,615	W100I	2011	Xperia öncesi yeniler
A/415-22810-0004	S312 GASGET SYS. CONN.	5	Gasket System Connector	0,03	S312	2009	Xperia öncesi yeniler
A/415-22810-0005	S312 GASGET CAMERA	5	Gasket Camera	0,03	S312	2009	Xperia öncesi yeniler
A/415-22810-0015	S312 SHIELD CAN	5	Shield Can Lid RF	0,285	S312	2009	Xperia öncesi yeniler
A/415-22810-0016	S312 SHIELD CAN	5	Shield Can Lid BB	0,285	S312	2009	Xperia öncesi yeniler
A/415-23260-0004	WT13 METAL DOME	5	Metal Dome	0,135	WT13I		Xperia
A/415-23290-0001	CK13 MAIN KEYPAD DOME SHEET	5	Main Keypad Dome Sheet	0,87	CK13I		Xperia
A/471-22580-0002	W150 COBRAND BLACK	10	Cobranding Label Black Walkman Logo	0,315	W150I	2011	Xperia öncesi yeniler
A/471-23260-0003	WT13 CO-BRAND BLACK	1	Co-Branding Black Walkman	0,24	WT13I		Xperia
A/478-221100-003	K200 LIGUIDE INDICATOR	20	Liquid Intrusion Indicator	0,015			eski modeller
A/478-223600-002	R300 KRH LABEL	40	KRH Label	0,045			eski modeller
A/478-225800-001	W150 KRH LABEL	20	Core Unit Label	0,045	W150I	2011	Xperia öncesi yeniler
A/478-226100-007	T303 KRH LABEL	20	KRH label	0,045			eski modeller
A/8BATA337065105	A3618 BATTERY GRAY	1	Battery, Gray	9,555			eski modeller
A/8CS2233RACC11B	K330 REAR COVER GOLD	1	Rear Cover Assy Gold	4,98			eski modeller
A/8CS2233RACG21B	K330 REAR COVER GREEN	1	Rear Cover Assembly (Green)	1,245			eski modeller
A/8CS-22360-0001	R300 FPC KEYBOARD (YENİ)	22	FPC Keyboard Assy	2,985			eski modeller
A/8CS2236FNCB21B	R300 FRONT BLACK	15	Front Cover Assy Black	3,435			eski modeller
A/8CS2236FNCS01B	R300 FRONT SILVER	13	Front Cover Assy Silver	3,435			eski modeller
A/8CS-22580-0001	W150 TOUCH FRONT COVER BLACK	5	Touch Front Cover Assy Black	24,81	W150I	2011	Xperia öncesi yeniler
A/8CS2261ANCB01B	T303 ANTENNA COVER 900 BLACK	7	Antenna Cover 900 Black Assy	1,395			eski modeller
A/8CS2261ANCS01B	T303 ANTENNA COVER 900 SILVER	7	Antenna Cover 900 Silver Assy	1,395			eski modeller
A/8CS2261FNCB01B	T303 FRONT COVER BLACK	10	Front Cover T303 Black Assy	6,75			eski modeller
A/8CS2261FNCS01B	T303 FRONT COVER SILVER	8	Front Cover T303 Silver Assy	6,75			eski modeller
A/8CS2261PCB001B	T303 HINGE FPC	16	Hinge FPC Assy	3,45			eski modeller
A/8CS2261PCB002B	T303 MAIN KEYPAD FPC	8	Main Keypad FPC Assy	3,81			eski modeller
A/8CS2261PCB003B	T303 FUNCTION KEY FPC	18	Function Key FPC Assy	6,24			eski modeller
A/8CS-22710-0004	W100 SUB PCBA ASSY.	17	Sub PCBA Assembly	8,79	W100I	2011	Xperia öncesi yeniler
A/8CS-22830-0001	S312 METAL FRAME WITH KEY FPC	2	Metal Frame with Keypad FPC	4,125	S312	2009	Xperia öncesi yeniler
A/8CS-22830-0004	S312 ANTENNA COVER BLUE (YENİ)	5	Antenna Cover Blue	0,75	S312	2009	Xperia öncesi yeniler
A/8CS-22830-0006	S312 BATTERY COVER BLUE	33	Battery Cover Blue	1,32	S312	2009	Xperia öncesi yeniler
A/8CS-22830-0012	S312 BATTERY COVER SILVER YENİ	5	Battery Cover Silver	1,32	S312	2009	Xperia öncesi yeniler
A/8CS2283ANMB01B	S312 ANTENNA 900	8	Antenna Assembly 900MHz	1,815	S312	2009	Xperia öncesi yeniler
A/8CS-23250-0001	CK15 FRONT BLACK	8	Front Cover Assy Black	19,005	CK15I		Xperia
A/8CS-23250-0002	CK15 FRONT WHITE	3	Front Cover Assy White	19,005	CK15I		Xperia
A/8CS-23250-0003	CK15 FRONT PINK	3	Front Cover Assy Pink	19,005	CK15I		Xperia
A/8CS-23250-0005	CK15 SUB BOARD	7	Sub Board Assy	0,675	CK15I		Xperia
A/8CS-23260-0001	WT13 FRONT BLACK	2	Front Cover Assy Black	21,21	WT13I		Xperia
A/8CS-23260-0002	WT13 FRONT WHITE	5	Front Cover Assy White	26,445	WT13I		Xperia
A/8CS-23290-0001	CK13 FRONT COVER BLACK	8	Front Cover Assy Black	3,885	CK13I		Xperia
A/8CS-23290-0002	CK13 FRONT COVER WHITE	1	Front Cover Assy White	3,885	CK13I		Xperia

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
A/8M01-2233-B001	K330 FRONT GREEN	2	Front Cover Green	2,22			eski modeller
A/8M01-2233-B002	K330 FRONT GOLD	3	Front Cover Gold	2,22			eski modeller
A/8M02-2236-B001	R300 CAMERA COVER BLACK	8	Camera Cover Assy Black	1,92			eski modeller
A/8M02-2236-K001	R300 CAMERA COVER COPPER	7	Camera Cover Assy Copper	1,095			eski modeller
A/8M02-2261-S001	T303 REAR COVER	4	Rear Cover Assy	1,44			eski modeller
A/8M02-2283-S001	S312 PLASTIC FRAME SILVER	5	Plastic Frame Silver	1,815	S312	2009	Xperia öncesi yeniler
A/8M02-2283-S201	S312 PLASTIC FRAME GREY	3	Plastic Frame Grey	1,815	S312	2009	Xperia öncesi yeniler
A/8M03-2236-B001	R300 BATTERY COVER BLACK	11	Battery Cover Black Assy	2,07			eski modeller
A/8M03-2236-K001	R300 BATTERY COVER COPPER	23	Battery Cover Copper Assy	2,07			eski modeller
A/8M03-2283-L001	S312 BATTERY COVER BLUE	5	Battery Cover Blue	1,32	S312	2009	Xperia öncesi yeniler
A/8M07-2283-L001	S312 ANTENNA COVER BLUE	3	Antenna Cover Blue	0,75	S312	2009	Xperia öncesi yeniler
A/8M07-2283-S101	S312 ANTENNA COVER SILVER	10	Antenna Cover Silver	0,75	S312	2009	Xperia öncesi yeniler
A/8M08-2233-N001	K330 KEYBOARD PCB	3	Keyboard PCB Assembly	2,415			eski modeller
A/8M13-2281-0001	S312 METAL FRAME KEYPAD PCB	1	Metal Frame with Keypad FPC	6,39	S312	2009	Xperia öncesi yeniler
BKB1931022/03	YÜKSEK KAP. BATARYA NM 7075	1	NM7075/Battery/Bulk, Ni-Mh	12			eski modeller
BKE90324	K750 VIBRATOR 1001-2339	13	Vibrator	0,51			eski modeller
BKE90337	K610 VIBRATOR	9	Vibrator	0,54			eski modeller
BKE90337/2	K550 VIBRATOR	10	Vibrator	0,54			eski modeller
BKE90340	W880 VİBRATÖR	2	SMD Vibrator	0,645			eski modeller
BML162174/1	CST-61 HBH-PV700 STD CHARGER	943	CST-61 / Std Charger / EU	2,085			eski modeller
DPY901191	ICA-11 T20S TAŞIYICI KILIF	30	EXPRESSCASE,ICA-11	9			eski modeller
DPY901194/3	HCC-13 SİSTEM KABLOSU	3	HCC-13, Systemcablewshellpl	13,5			eski modeller
DPY901200	HCH-37 P900 HOLDER	1	HCH-37/Car Holder/Blister	18			eski modeller
DPY901259/01	HBH-20 BLUETOOTH KULAKLIK	1	HBH-20/Bluetooth# Handsfree/Pin-rack	79,5			eski modeller
DPY901268	MCA-20 CAMERA	1	MCA-20/CommuniCam/Blister	181,5			eski modeller
DPY901328	HCC-30 SİSTEM KABLOSU	7	HCC-30/System Cable/Bag	13,5			eski modeller
DPY901334	MCA-25 COMUNİCAM	1	MCA-25/CommuniCam/Pin-rack	45			eski modeller
DPY901370/3	IST-21 T300 SNAP-ON COVER	27	IST-21/ Snap on cover/ Fashion Purple	9			eski modeller
DPY901402	HCA-20/HCH-33/HCC-20	1	HCA-20/HCH-33/Car Handsfree/Box	123			eski modeller
DPY901415	HCA-20 + HCH-30 + HCC-30 KİT	1	HCA-20/HCH-30/Car Handsfree/Box	118,5			eski modeller
DPY901437	HCH-36 Z600 HOLDER	10	HCH-36/Car Holder/Blister	25,5			eski modeller
DPY901448	ISK-600 STYLE-UP KIT	6	ISK-600/Style-up kit/Blister	10,5			eski modeller
DPY901451	HCA-200 HCH-38 HCC-20 KIT	1	HCA-200/HCH-38/HCC-20/Car Handsfree/Box	100,5			eski modeller
DPY901454	HCH-39 K500-F500 HOLDER	5	HCH-39/Car Holder/Blister	18			eski modeller
DPY901519	CLA-60 ARAÇ ŞARJ CİHAZI	5	CLA-60/Cigarette Lighter Adapter/Blister	13,5			eski modeller
DPY901523	HCH-62 W550 HOLDER	19	HCH-62/Car Holder/Pin rack	15			eski modeller
DPY901530/1	-CST-60 STANDARD CHARGER	35	CST-60/Standard Charger/EU/Blister	15			eski modeller
DPY901544/Z	HBH-DS970 STEREO BT SWAP	1	HBH-DS970/Stereo BT Headset/SwapUnit/Box	60			eski modeller
DPY901581/2Z	MPS-60 PORTABLE BLACK SWAP UNI	6	MPS-60/Portable Speakers/Black/Swap Unit	19,5			eski modeller
DPY901595/1	-CST-75 STANDARD CASCADED CHAR	40	CST-75/Standard Charger/EU/Blister	15			eski modeller
DPY901598	HCH-65 W850 HOLDER	7	HCH-65/Car Holder/Pin rack	18			eski modeller
DPY901619/Z	HBH-DS980 SWAP UNIT	1	HBH-DS980/Stereo BT Headset/Swap/Box	75			eski modeller
DPY901622	MMC-70 MUSIC CABLE	2	MMC-70/Music Cable/Blister	10,5			eski modeller
DPY901661	BST-40 BATARYA	12	BST-40/Battery/Blister	34,5			eski modeller
DPY901672	HCH-71 CAR HOLDER K810	4	HCH-71/Car Holder/Pin Rack	18			eski modeller
DPY90179	DI-28 MOBILE OFFICE	1	DI28	94,5			eski modeller
F/03-85734	K510 BACKUP CAPACITOR 3,3VIV01	4	backup capacitor 3,3V IV01E	0,36			eski modeller
F/04-32270	K510 MOSFET P-CHANNEL 3,9A 20V	24	Mosfet p-channel 3.9A, 20V 1206A	0,15			eski modeller
F/04-34502	K320 TR NPN 100MA/50V WITH	10	TR NPN 100MA/50V WITH BUILT-IN RESISTOR	0,015			eski modeller
F/07-08233	K510 LED WHITE CHARGE PUMP	7	LED White Charge Pump	0,42			eski modeller
F/07-63490	K510 LED SIDE VIEM CHIP RED 66	10	LED SIDE VIEW CHIP RED 660nm 0605	0,06			eski modeller
F/07-85900	W200 CHIP LED REGHT ANGLE ORAN	5	CHIP LED RIGHT ANGLE ORANGE 609NM	0,03			eski modeller
F/07-85914	W200 CHIP LED WIDE 609 NM 0603	5	CHIP LED WIDE ANGLE ORANGE 609NM 0603	0,03			eski modeller
F/10-42853	K510 TJATTE 3	22	TJATTE 3	0,24			eski modeller
F/16-51061	W200 IR TRANCEIVER 115.2 KB/S	5	IR TRANCEIVER 115.2 KB/S 021	0,63			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
F/16-62844	W200 FM RADIO RDS WL-CSP 25	3	FM RADIO RDS WL-CSP 25	1,035			eski modeller
F/16-72905	K510 AUDIO POWER AMP 1,2W FLIP	15	AUDIO POWER AMPLIFIER 1.2W FLIP CHIP 9-P	0,285			eski modeller
F/34-50247	K310 ANTENNA POGO 3 PIN	4	ANTENNA POGO 3-PIN	0,39			eski modeller
F/34-54091	K510 POGO PIN	11	Pogo Pin	0,09			eski modeller
F/34-56180	K510 PCB CONN	20	PCB Connector	0,255			eski modeller
F/34-57540	K510 SIM CONN	23	Sim Connector	0,18			eski modeller
F/34-78443	K510 BATTERY CONN	8	Battery Connector	0,18			eski modeller
F/34-92334	K510 BTB 16 PIN CONN	4	BTB 16 Pin Connetcor	0,27			eski modeller
F/35-25020	K310 CAMERA SOCKET	4	CAMERA MODULE SOCKET 8X8MM	0,33			eski modeller
F/36-80319	K510 SIDE KEY SWITCH	15	SIDE KEY LIGHT TOUCH SWITCH 12 Vdc 50mA	0,105			eski modeller
F/37-80405	K310 LCD MODULE	5	LCD DISPLAY MODULE	8,865			eski modeller
F/40-78820	K510 VİBRATOR	9	Vibrator	0,585			eski modeller
F/42-41032	K510 SPEAKER	15	Speaker	0,57			eski modeller
F/42-60411	K310 RECEIVER 32 OHM 15%	8	RECEIVER 32OHM 15%	0,555			eski modeller
F/43-90506	K510 MICROPHONE	17	Microphone	0,45			eski modeller
F/44-64632	K310 CAMERA MODULE VGA	2	CAMERA MODULE VGA 6X6X4.5MM	6,66			eski modeller
F/51-60834	K510 SCREW BOTTOM	19	Screw Bottom	0,03			eski modeller
F/51-67181	K510 SCREW TOP	20	Screw Top	0,015			eski modeller
F/52-21724	K510 SHIELD BB	8	BB Shield	0,075			eski modeller
F/52-28022	K510 SHEILD BT	10	BT Sheild	0,045			eski modeller
F/52-41968	W200 SPEAKER DUST NET	5	SPEAKER DUST NET	0,165			eski modeller
F/52-95020	W200 METAL FRAME ASS	3	METAL FRAME ASSEMBLY	0,585			eski modeller
F/53-42426	W200 FRAME BLACK 900MHz	2	B-COVER ASSEMBLY BLACK 900MHz	2,535			eski modeller
F/53-44168	K510 KEY POWER	4	Power Key Assy	0,135			eski modeller
F/53-44581	W200 VOLUME KEY BLACK	8	VOLUME KEY BLACK	0,195			eski modeller
F/53-44964	W200 BATTERY COVER PINK	4	BATTERY COVER ASSY PINK	1,425			eski modeller
F/53-44983	W200 BATTERY COVER BLACK	42	BATTERY COVER ASSY BLACK	2,76			eski modeller
F/53-45957	W200 WALKMAN KEY ORANGE	7	WALKMAN KEY ORANGE	0,27			eski modeller
F/53-60307	W200 FRONT COVER BLACK	2	A-COVER ASSY BLACK	3,255			eski modeller
F/53-60335	W200 FRONT COVER PINK	3	A COVER ASSY PINK	2,925			eski modeller
F/53-69077	K310 AUDIO PIPE ASS	3	AUDIO PIPE ASSEMBLY	0,975			eski modeller
F/53-72183	W200 UI MODULE FRAME	4	UI MODULE FRAME	1,83			eski modeller
F/53-76980	K510 DOMEFOIL	9	DOMEFOIL	0,3			eski modeller
F/53-82713	W200 JOYSTICK BUTTON	1	JOYSTICK CAP	0,135			eski modeller
F/54-13160	W200 MEMORY CARD COVER BLACK	6	MEMORY CARD HATCH BLACK	0,36			eski modeller
F/54-13240	W200 JOYSTICK SILICINE	10	JOYSTICK SILICONE	0,09			eski modeller
F/55-28917	K510 IRDA WINDOW	8	IR Window	0,06			eski modeller
F/57-51317	K310 GASKET CAMERA	3	CAMERA GASKET	0,09			eski modeller
F/57-80820	W200 GASKET SPEAKER	10	SPEAKER GASKET	0,09			eski modeller
F/58-35188	K510 LIQUIDEINTRUTION INDICATO	10	Liquide intrusion indicator	0,045			eski modeller
F/65-30530	W200 KEYPAD BLACK	9	KEYPAD ASSY BLACK LATIN	1,275			eski modeller
F/65-30531	W200 KEYPAD PINK	3	KEYPAD ASSY PINK LATIN	1,59			eski modeller
F/75-92053	128MB MEMORY STICK M2	2	MEMORY STICK MICRO (M2) 128MB	10,8			eski modeller
F/80-13720	W200 CO-BRAND OPERATOR BLACK	5	OPERATOR LOGO ASSY WM BLACK	0,285			eski modeller
F/80-13961	W200 CO-BRAND OPERATOR PINK	3	OPERATOR LOGO ASSY WM PINK	0,315			eski modeller
F/80-26119	KRH LABEL K510 K310 K320 W200	100	KRH Lable	0,255			eski modeller
F50001402630	ST21 SCREW	50	SCREW M1.4	0,03	ST211		Xperia
F50002803530	ST21 SCREW	50	SCREW (T5)M1.6	0,03	ST211		Xperia
KDR109171/256	256MB MEMORY STICK MICRO(M2)	94	256MB Memory Stick Micro(M2)	5,685			eski modeller
KDR109171/512	512MB MEMORY STICK MICRO(M2)	10	Memcard 512 Mbyte	6,495			eski modeller
KNC20135/2	S500 CAMERA 2 MEGA	10	Camera (2Mega)	6,27			eski modeller
KRE1011535	S500 ANTENNA BLUETOOTH	8	ANTENNA/BLUETOOTH	0,075			eski modeller
KRE1011536	S500 ANTENNA ELEMENT	3	ASSY/ANTENNA ELEMENT	0,9			eski modeller
KRY1011115	SEPI CABLE	5	SEPI Cable 3V	44,61			eski modeller
KRY1011129	MIS-06 UPDATE SERVICE KIT	1	Update Service Kit MIS-06 Camel	119,13			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
KRY1011939	M2 KART ADAPTOR BLACK	6	Accessory M2 Card reader BLACK	3,78			eski modeller
KRY111093/02	MÜZİK KESME KABLOSU	5	MUSICMUTECABLE,INBLISTER	4,5			eski modeller
LTD260273	FIXTURE	1	Rework fixture	86,685			eski modeller
LTN2141484	SEPI USB/INTERFACE BOX	1	SonyEricsson programming interface-SEPI	66,495			eski modeller
MEKIM31002A	J110 METAL FRAME MYLAR LCM	5	Mylar LCM Metal Frame	0,015			eski modeller
MEKIM36003A	J110 SIM RUBBER	5	Rubber SIM	0,015			eski modeller
MEKIM61026B	J110 SHIELDING COVER PCBA	5	Assy Shielding Cover PCBA	0,105			eski modeller
METEA04001A	W205 MAIN WINDOW	10	Main Window W205	0,75	W205	2009	Xperia öncesi yeniler
METEA07001B	W205 VOLUME KEY SILVER	10	Volume Key, Silver	0,435	W205	2009	Xperia öncesi yeniler
METEA11001A	W205 VIBRATOR	4	Vibrator	0,93	W205	2009	Xperia öncesi yeniler
METEA16001A	W205 DOME SHEET MAIN KEYPAD	6	Dome Sheet Main Keyboard	0,18	W205	2009	Xperia öncesi yeniler
METEA16002A	W205 DOME SHEET NAVIGATION	70	Dome Sheet Navigation Keyboard	0,21	W205	2009	Xperia öncesi yeniler
METEA16003A	W205 DOMESHEET MAIN KEYBOARD	38	Dome Sheet Main Keyboard	0,18	W205	2009	Xperia öncesi yeniler
METEA48002A	W205 CONN. ZIF	10	Connector ZIF 51p	0,51	W205	2009	Xperia öncesi yeniler
METLD07009B	W205 NAVI KEYBOARD BLACK ADET	3	Keyboard Navigation, Black	1,26	W205	2009	Xperia öncesi yeniler
METLD08001A	W205 CAMERA LENS	10	Camera Lens	0,24	W205	2009	Xperia öncesi yeniler
METLD14002A	W205 HALF TO HALF FPC	7	DMG SEMC IRLHalf to Half FPC	3,84	W205	2009	Xperia öncesi yeniler
METLD14002B	W205 HALF TO HALF FPC (YENİ)	6	Half to Half FPC	4,32	W205	2009	Xperia öncesi yeniler
METLD22001A	W205 SPRING CONNECTOR	5	Spring connector	0,165	W205	2009	Xperia öncesi yeniler
METLD23003B	W205 SHIELD CAN	3	Shield Can Lid RF	0,255	W205	2009	Xperia öncesi yeniler
METLD23004B	W205 SHIELD CAN BB	3	Shield Can Lid BB	0,345	W205	2009	Xperia öncesi yeniler
METLD33006A	W205 SPONGE SYSTEM CONN.	10	Sponge System Connector	0,285	W205	2009	Xperia öncesi yeniler
METLD33008A	W205 SPONGE LCD	4	Sponge Display	0,405	W205	2009	Xperia öncesi yeniler
METLD36001B	W205 CAP MS SILVER	14	Cap Memory Stick, Silver	0,12	W205	2009	Xperia öncesi yeniler
METLD36002B	W205 GASGET CAMERA RUBBER	5	Gasket Camera Rubber	0,075	W205	2009	Xperia öncesi yeniler
METLD36003B	W205 GASGET MIC RUBBER	5	Gasket Mic Rubber	0,075	W205	2009	Xperia öncesi yeniler
METLD39005A	W205 GROUNDING CUSHION	5	Grounding cushion 3 mm	0,015	W205	2009	Xperia öncesi yeniler
METLD39009A	W205 GROUNDING CUSHION	5	Grounding cushion 2,5 mm	0,015	W205	2009	Xperia öncesi yeniler
METLD39010A	W205 GASGET	5	Gasket Conductive navig PCB	0,195	W205	2009	Xperia öncesi yeniler
METLD4B001A	W205 MEMORY CARD CONN.	20	Memory card connector	0,54	W205	2009	Xperia öncesi yeniler
METLD52002B	W205 METAL CLIP EAR SPEAKER	2	Metal Clip Ear Speaker	0,15	W205	2009	Xperia öncesi yeniler
METLD61002B	W205 HINGE	18	Hinge	21	W205	2009	Xperia öncesi yeniler
METLD61006B	W205 REAR COVER BLACK	7	Rear Cover, Black	2,64	W205	2009	Xperia öncesi yeniler
METLD61007B	W205 BATTERY COVER BLACK	38	Battery Cover, Black	2,67	W205	2009	Xperia öncesi yeniler
METLD84003A	W205 ADHESIVE CAMERA LENS	5	Adhesive Camera Lens	0,105	W205	2009	Xperia öncesi yeniler
METSA07001B	W205 KEYBOARD LATIN SILVER	7	Keyboard, Latin Silver	0,84	W205	2009	Xperia öncesi yeniler
METUV43001A	W205 SYSTEM CONNECTOR	58	System Connector	0,39	W205	2009	Xperia öncesi yeniler
METUV47001A	W205 SIM CONN.	13	SIM Connector	0,42	W205	2009	Xperia öncesi yeniler
NTM2011273/21	CST-13 STANDART CHARGER/BULK	19	CST-13/Standard Charger/EU/Bulk	13,5			eski modeller
NTZ111068	DOT GAUGE	4	Dot Gauge	6,165			eski modeller
NTZ1121052	BITS (PHILIPS)	4	Bits(JCIS No 0)	3,375			eski modeller
NTZ112288	TORNAVIDA UCU T6 (KISA)	2	Bits (T6)	1,065			eski modeller
NTZ112288/1	T290 BITS/TORX/T6/EXT LENGTH	7	Extended length T6, Torx Bit	1,605			eski modeller
NTZ112478	BİTS TORX T5	1	Torx Bits T5	4,305			eski modeller
NTZ112537	K700 SHIELD FENCE PLIERS	1	Shield Fence Plier	38,34			eski modeller
NTZ112590	TOOL PLECTRUM P1 S500 W580	30	Guitar Pick	0,27			eski modeller
ODM-1203-2186	K770 LCD	7	DISPLAY MODULE PMMA 2.0	22,935			eski modeller
ODM53-39950	K770 VOLUME KEY	2	Volume key assembly	0,45			eski modeller
ODM53-43910	K770 CAP CAMERA PURPLE	2	CAMERA CAP ASSY PURPLE	1,14			eski modeller
ODM53-43968	K770 CAP CAMERA BROWN	9	CAMERA CAP ASSY BROWN	1,005			eski modeller
ODM53-82040	K770 SPEAKER ANTENNA	5	Speaker Antenna box	1,14			eski modeller
ODM53-88350	K770 FRONT COVER BROWN	2	FRONT COVER ASSEMBLY BROWN	2,64			eski modeller
ODM53-88540	K770 FRONT COVER GREY SILVER	10	FRONT COVER ASSEMBLY GREY SILVER	2,985			eski modeller
ODM53-88917	K770 FRAME	3	Frame assembly	3,42			eski modeller
ODM53-89012	K770 BATTERY COVER BROWN	8	BATTERY COVER ASSEMBLY BROWN	7,53			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
ODM53-89018	K770 BATTERY COVER PURPLE	3	BATTERY COVER ASSEMBLY	9,225			eski modeller
ODM53-89025	K770 BATTERY COVER GREY SILVER	2	BATTERY COVER ASSEMBLY GREY SILVER	9,225			eski modeller
ODM55-69000	K770 CAMERA LENS	4	Camera lens assembly	0,465			eski modeller
ODM57-20335	K770 GASKET SYSTEM	5	System connector gasket	0,015			eski modeller
ODM57-94402	K770 GASKET SPEAKER WITH	4	Speaker gasket with dust net	0,06			eski modeller
ODM60-69500	K770 CO-BRAND GREY	4	CO BRAND STICKER GREY SILVER CYBER-SHOT	0,105			eski modeller
ODM65-65100	K770 NUMERIC KEYBOARD BROWN	20	KEYPAD ASSY NUMERIC BROWN LATIN	2,775			eski modeller
ODM65-65101	K770 NUMERIC KEYBOARD SILVER	34	KEYPAD ASSY NUMERIC SILVER LATIN	2,775			eski modeller
ODM65-66810	K770 NAVIGATION BROWN	23	KEYPAD ASSY NAVI BROWN	1,545			eski modeller
ODM65-66900	K770 NAVIGATION GREY SILVER	1	KEYPAD ASSY NAVI GREY SILVER	1,695			eski modeller
ODM65-66911	K770 NAVIGATION PURPLE	2	KEYPAD ASSY NAVI PURPLE	1,545			eski modeller
ODM65-87877	K770 KEYFOİL	9	Keypad support plate	9,48			eski modeller
ODM76-92834	K770 CAMERA DOOR PWBA	25	Camera door PWBA	1,665			eski modeller
ODM80-69100	K770 CO-BRAND BROWN	6	CO BRAND STICKER BROWN CYBER-SHOT	0,105			eski modeller
ODM80-69106	K770 CO-BRAND PURPLE	9	CO BRAND STICKER PURPLE CYBER-SHOT	0,105			eski modeller
ODM80-71075	KRH LABEL K770	30	KRH-label	0,045			eski modeller
PKDAL15004A	J110 LIQUID INTRUSION INDICATO	20	Liquid Intrusion Indicator	0,255			eski modeller
PKJAL15003A	W205 LIQUID INS.LABEL	10	Liquid Intrusion Label	0,015	W205	2009	Xperia öncesi yeniler
REG7041181/1	1.0NH 0402 5% 1000-1462	6	1.0NH 0402 5% WIREWOUND	0,045			eski modeller
REG7041181/18	1.8NH 0402 5% 1001-2239	6	1.8 NH 0402 5% WIREWOUND	0,045			eski modeller
REG7041181/39G	3.9NH 0402 2% WIREWOUND	8	3.9NH 0402 2% WIREWOUND	0,045			eski modeller
REG7044242/56	CAPACITOR 56 NH 1000-1876	5	56nH 5% 0603 0.36A	0,045			eski modeller
REG7049542/15	INDUCTOR	115	15nH 5% 0603 multilayer	0,015			eski modeller
REG70605/15	J105 CAPACITOR 1000-0118	5	120ohm 0603 2A 50mohm Bead	0,015	J105I	2009	Xperia öncesi yeniler
REG70605/20	INDUCTOR 1 KOHM	5	Inductor 1kohm	0,015			eski modeller
REG70605/24	C510 FILTER 1001-1896	5	Filter 220ohm 0603 2A 0.05ohm Bead	0,015	C510	2010	Xperia öncesi yeniler
REG70609/06	TRANSFORMER 1203-0723	5	Transformer	0,015			eski modeller
REG70618/18	FILTER 1000-2617	5	Filter 1.0 GHz 0402	0,015			eski modeller
REG70618/19	EMI FILTER 1000-2618	10	EMI FILTER	0,015			eski modeller
REG70618/2	EMIFILTER 1000-0120	219	75ohm 0402 0.1A 0.8ohm Bead	0,015			eski modeller
REG70618/20	FILTER 0.0 HZ 0402 1200-0317	5	Inductor	0,015			eski modeller
REG70618/37	J105 FERRITE 1001-1223	5	Ferrite B 1.5 kOhm 100.0 mA 0402	0,015	J105I	2009	Xperia öncesi yeniler
REG7245182/18NH	18NH 3% 0201 1001-0372	10	Ind Chip 18, nH K0201	0,015			eski modeller
REG7245372/22	C510 INDUCTOR 1000-0130	5	Inductor Wirewound	0,12	C510	2010	Xperia öncesi yeniler
REG7245542/56J	IND 56 1200-0511	5	Ind WW 56, nH K0402	0,045			eski modeller
REG7245543/12J	W595 INDUCTOR 1001-2140	5	Inductor 120nH 5% 0402 0.11A	0,045	W595	2009	Xperia öncesi yeniler
REG9030049/22	IND CHIP 1200-2028	5	Ind Chip 2,2 uH K2520	0,075			eski modeller
REP621002/47	RESISTOR 47 1000-0232	10	Resistor 47, Ohm 5% 50.0 mW 0201	0,015			eski modeller
REP621005/12	RESISTOR 12 KOHM 1000-0182	10	Resistor 12 kohm	0,015			eski modeller
REP621105/47	47 KOHM 1% RESISTOR 1000-0382	10	47Kohm 1% Resistor	0,015			eski modeller
REP622001/0	RESISTOR 1000-0179	992	Resistor 0.0 Ohm +/-5% NA mW K0402	0,015			eski modeller
REP622455/22	RESISTOR	3	Resistor 22, kOhm +/-5% 63.0 mW K0402	0,015			eski modeller
REV50147/1	FILTER/LC FILTER ARRAY	37	LC Filter Array 0805 22pF	0,075			eski modeller
REV50148/1	W595 LC FILTER 1000-7455	5	LC Filter	0,06	W595	2009	Xperia öncesi yeniler
RJC4633012/33	CAPACITOR CERAMIC 1000-0056	10	Capacitor Ceramic 33,0 pF +/-5% 16,0 V K	0,015			eski modeller
RJC5163026/47	CAPACITOR CERAMIC 1000-0340	67	Capacitor Ceramic 470,0 nF +/-10% 6,3 V	0,015			eski modeller
RJC5163027/1	1.0 UF 10%0402 1000-0051	10	1.0uF 10% 0402 6.3V X5R	0,015			eski modeller
RJC5164038/1	CAPACITOR CERAMIC 1000-0061	20	Capacitor Ceramic 10,0 uF +/-20% 6,3 V K	0,015			eski modeller
RJC5164048/22	CAPACITOR 22 UF 1000-6903	24	Capacitor 22uF	0,03			eski modeller
RJCUA5523201/1	1.0PF 0201 +/- 3PF	10	Capacitor 1.0 pF ##0.1pF 25.0 V K0201	0,015			eski modeller
RJCUA5523201/11	CAPACITOR 0201 1,1 PF +/-0.1	10	Capacitor, 0201, 1.1pF, +/-0.1pF	0,015			eski modeller
RJE3551335/7	K790 BACK-UP BATTERY 1000-0335	9	Capacitor 70.0 mF 3.3 V	0,255			eski modeller
RKZ123904/1	DIODE	41	SWI X2 75V 2X75mA SC75 Pb free	0,015			eski modeller
RKZ123905/1	SCHOTTKY BARRIER 1000-0391	9	Schottky Barrier Diodes 2PIN	0,015			eski modeller
RKZ123905/2	DIODE V SCHOTTY 1000-0087	8	Diode	0,015			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
RKZ123907/1	DIODE 40V 80MA SSM SERIES	16	Diode, 40V, 80mA, SSM series, 150ns	0,015			eski modeller
RKZ123910/1	DIODE	206	Diode	0,015			eski modeller
RKZ123911/1	DIODE	19	DIODE V,EPITAXIAL_SCHOTTKY_DIODE,SOT23C	0,075			eski modeller
RKZ123913/1	DIODE SHOTTKY PBFREE 1002-0000	10	Inductor	0,06			eski modeller
RKZ123929/1	DIODE SHOTTKY BARRIER	15	Diode, Shottky Barrier	0,09			eski modeller
RKZ223905/2	DIODE V ZENER 1000-0272	105	bDiode	0,015			eski modeller
RKZ223906/1	ESD	31	ESD Diode	0,045			eski modeller
RKZ223911/1	ZENERDIODE ESDPROT.1000-0282	25	Diode	0,015			eski modeller
RKZ223911/3	W595 ZENER DIODE 1001-1864	5	ZenerDiode, 5.6V, Pb-free	0,015	W595	2009	Xperia öncesi yeniler
RKZ223914/1	DIODE DUAL ESD PRO. 1000-0399	115	Dual ESD protection diode	0,03			eski modeller
RKZ223914/2	DUAL ESD PROTECTION 1001-0730	10	Dual ESD protection diode 6V	0,045			eski modeller
RKZ223921/1	DIODE ZENNER 15V 1001-0876	10	Zenner Diode, 15V	0,03			eski modeller
RKZ3236025/2	T230 DIODE SMD 30 V	44	Diode Schottky 0,0	0,03			eski modeller
RKZ323907/1	SCHOTTKY DIODE 1000-0294	6	Schotty Diode	0,03			eski modeller
RKZ433664/3	G502 DIODE	5	Diode	0,03	G502	2009	Xperia öncesi yeniler
RKZ433906/1	LED DIODE	41	LED Red	0,03			eski modeller
RKZ433924/1	K700 RED LED ON-OFF 1000-0407	28	LED Red	0,045			eski modeller
RKZ433925/2	DIODE V LED AMBER 1000-7561	18	LED Amber h=0,4	0,015			eski modeller
RKZ433938/1	LIGHT SENSOR 1000-7567	18	Light Sensor	0,15			eski modeller
RKZ433942/1	J110 LED RED 1000-7571	5	LED Red	0,015			eski modeller
RKZ433989/1	DIODE 0.0V 1001-0630	5	Diode 0.0 V 1.8X1.1X0.30	0,045			eski modeller
RKZ923908/3	USB EMI FILTER PB FREE VER OF	126	USB EMI filter	0,135			eski modeller
RKZ923921/1	USB FILTER NETWORK 1000-0368	60	IC	0,09			eski modeller
RKZ923926/1	ESD EMI PROTECTION 1200-0454	4	IC ESD Prot CS-5	0,105			eski modeller
RKZ923929/1	DIODE 6.0 V 1001-0756	4	Diode 6.0 V	0,21			eski modeller
RLC50913/02	Stikon mik	2	Microphone	3,195			eski modeller
RLC509422/2	S500 MICROPHONE	18	MICROPHONE	0,255			eski modeller
RLC509427/3	K790 MICROPHONE	27	Microphone	0,75			eski modeller
RLC509429	Z530 MICROPHONE	39	Microphone	0,3			eski modeller
RLC509429/11	W880 MICROPHONE	8	Mic	0,33			eski modeller
RLE90811	HCB-30 LOUDSPEAKER	1	External Loudspeaker(Car HF Kit)	4,395			eski modeller
RLF50154	HPM-61/STEREO PHF	567	HPM-61/STEREO PHF	2,505			eski modeller
RLF50155	HPB-60 BULK	34	Headset Mono#	2,28			eski modeller
RLF50162	HPM-62 BLACK	1926	HPM-62 Black	2,505			eski modeller
RLF50162/31	HPM-62 SILVER P1	13	HPM-62/STEREO Silver	2,505			eski modeller
RLF90209	HPB-62 MONO PHF	2	HPB-62 Mono PHF	1,77			eski modeller
RMD10116/9	W850 SIDE SWITCH 1001-0060	18	Input Switch	0,09			eski modeller
RMD10148	K610 SWITCH SIDE 1000-7670	74	Side push switch	0,18			eski modeller
RNH942222	S500 LCD	31	2.0 QVGA LCD w/Glass Cover	19,47			eski modeller
RNH94274	Z610 SUB LCD	4	Outer Display OLED 1/1	3,45			eski modeller
RNK87145	W550 SIM READER	129	SIM Reader	0,285			eski modeller
RNK87147/3	K610 MS HOLDER M2 1200-9764	24	Memory card reader	0,435			eski modeller
RNT79925	S500 CONN OTHER 1001-0637	5	Conn Other	0,18			eski modeller
RNV403883/60	Z610 CONNECTOR BTB 2 60 PIN	7	Connector Connector, BtB 2 60 pin	0,42			eski modeller
RNV799011	K610 SOCKET CAMERA MEGA	6	Camera connector	0,405			eski modeller
RNV799016/60	W380 BTB 60 PIN	5	Conn BtB	0,345			eski modeller
RNV799036	K550 CONN.KEYBOARD 1200-5405	102	Con X Keyboard connector	0,21			eski modeller
RNV799041	W302 BTB 24PF 1200-2386	5	Btb 24p F	0,165	W302	2009	Xperia öncesi yeniler
RNV799045/22	K850 CONN BTB 22 1200-2111	3	Conn BtB 22 pin	0,135			eski modeller
RNV799046	K530 LCD CONNECTOR	5	B to B connector, female, 22 pin	0,21			eski modeller
RNV79935	Z520 SYSTEM CON 1002-8847	376	System Connector	0,165			eski modeller
RNV79936	K750 SYSTEM CONNECTOR	1516	System Connector	0,165			eski modeller
RNV79943	Z800 BATTERY CONN.1000-0315	8	Conn Pogopin 5p V800 Battery conn	0,51			eski modeller
RNV79960/1	Z520 RF TEST CONNECTOR	5	RF test connector	0,165			eski modeller
RNV79992	K790 30 PIN BTB MALE (CAMERA)	10	30 Pin BTB, male (Camera)	0,24			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
ROA1281451/3Z	K510 MTT2	12	RF MODULE MINI T-TOP-2, 900 PCBA#s	7,47			eski modeller
ROA1281451/Z	W200 MTT2	9	RF MODULE MINI T-TOP-2, 850 PCBA#s	7,68			eski modeller
ROA1281640/Z	W850 MARLIN GSM RF MODULE	2	Marlin module	12,75			eski modeller
ROA1282082/Z	P1 PRE BUMPED RAY 2.5	2	Pre bumped# Ray 2,5	10,365			eski modeller
ROP1013044/4	PROD ADAPT CIRCUIT ASIC	1	ASIC Wanda BGA181	8,685			eski modeller
ROP1013060/1	CONCORD RF ASIC HVQFN-48PB FRE	15	CONCORD RF ASIC , HVQFN-48 pb free	2,745			eski modeller
ROP1013066/5	ASIC VINCENNE2 A07(PB-FREE PA)	25	ASIC PM Vincenne2 uBGA144	2,205			eski modeller
ROP1013066/6	PROD ADAPT CIRCUIT ASIC	12	Vincenne2	2,205			eski modeller
ROP1013074/1	ASIC TJATTE 3 1000-0198	17	ASIC Tjatte3 CSP20	0,165			eski modeller
ROP1013097/1	W710 IC ACCELEROMETER	2	ACCELEROMETER	1,74			eski modeller
RPM13112	DCU-65 USB CABLE	55	DCU-65/USB CABLE	1,23			eski modeller
RPT79938	Z800 COAX CONNECTOR 1000-8175	5	Connector	0,12			eski modeller
RPT79958	Z310 CONNECTOR	4	RF Connector	0,12			eski modeller
RPT79964	W960 CONN SPRING 5 PINS	4	SPRING CONNECTOR, 5 PINS	0,225			eski modeller
RPV79982/24	W302 BTB 24 P 1001-0632	5	Btb 24p M	0,195	W302	2009	Xperia öncesi yeniler
RTL204905/2	S500 VCTCXO MODULE 3.2*2.5	5	VCTCXO module, 3.2x2.5	0,825			eski modeller
RTN202941/1	FILTER 1200-1865	5	Filter	0,09			eski modeller
RYN1216043/1	6835R-NPN 1000-0400	10	Trans NPN 1.2X1.2X0.5	0,015			eski modeller
RYN121936/1	TRANS NPN	13	Trans NPN	0,015			eski modeller
RYN122673/1	TRANS 1200-1196	5	Trans	0,09			eski modeller
RYN122684/2	TRANS V	24	Trans P-ch FET	0,105			eski modeller
RYN122902/1	TRANSISTOR	5	Transistor	0,15			eski modeller
RYN122910/1	DIOD 1200-0145	8	Transistor	0,12			eski modeller
RYN122911/1	P-CHANNEL MOSFET	5	P-Channel MOSFET	0,15			eski modeller
RYN123645/1	TRANSISTOR	6	Transistor	0,09			eski modeller
RYN123930/1	TRANS N-CH FET 1000-8427	4	Trans N-ch FET	0,06			eski modeller
RYN901905/2	DUAL ANALOG SWITCH DUAL SPDT	103	DUAL Analog Switch DUAL SPDT. NoPb	0,27			eski modeller
RYN901905/3	DUAL ANALOG SWITCH DUAL	5	DUAL Analog Switch DUAL SPDT, 2.0 HighSp	0,3			eski modeller
RYN901918/2	MOSFET COMP N P 20V 1000-0270	10	MOSFET Complementary N P 20 V (D S)	0,075			eski modeller
RYN901920/1	MR SENSOR 1000-8451	4	MR Sensor	0,135			eski modeller
RYN901925/1	MOSFET DUAL P-CHANNEL 20V 4.1A	4	MOSFET, Dual P-Channel, 20V, 4.1A	0,165			eski modeller
RYN901926/1	W302 TRANSİSTOR 1000-0393	5	Trans P-ch FET	0,18	W302	2009	Xperia öncesi yeniler
RYN901936/1	N-CHANNEL MOSFET 1001-0077	1	Transistor	0,12			eski modeller
RYT1017841/1	IC AMP	5	IC Amp	0,255			eski modeller
RYT1017841/2	MIKROKRETS CLASS AB AUDIO	4	MIKROKRETS/Class AB Audio Amplifier	0,24			eski modeller
RYT101947/2	1W OPAMP 1000-0372	19	OPAMP 1W Pb-Free	0,24			eski modeller
RYT101956/1	MR SENSOR MICROCIRCUIT	8	MR SENSOR, MICROCIRCUIT	0,15			eski modeller
RYT109913/1	MICROCIRCUIT 1000-0350	96	MICROCIRCUIT/USB transceiver and UART MU	0,345			eski modeller
RYT109914/1	MICROCIRCUIT 1000-0369	4	1-Bit Level Translator	0,195			eski modeller
RYT109922/2	S700 IC	25	IC	0,465			eski modeller
RYT109932/3	LEVELTRANSLATOR	5	Leveltranslator	0,66			eski modeller
RYT109937/1	FM RAIDO RDS	3	FM-Radio RDS	0,885			eski modeller
RYT1137808/1	LED DRIVER	4	LED Driver	0,36			eski modeller
RYT1137816/3	LDO1,2V 200mA 1200-1852	2	LDO1.2 V, 200mA, low noise, CS	0,225			eski modeller
RYT1137822/1	VOLTAGE REGULATIR 1000-0367	5	IC Voltage Regulator	0,3			eski modeller
RYT1137824/1	VOLTAGE REGULATOR 1000-8818	10	DIODE BRIDGE	0,135			eski modeller
RYT1137838/1	DC/DC CONVERTER 1001-0868	5	DC/DC Converter	0,81			eski modeller
RYT113904/10	2.8V 150mA LINE REGULATOR LEAD	26	ICN Voltage regulator CSP5	0,18			eski modeller
RYT113916/1	STEP-DOWN DC/DC CONVERTER	5	Step-down DC/DC converter	0,57			eski modeller
RYT113923/2	LEADFREEVERSIONOF	10	LeadfreeversionofRYT113923/1	0,48			eski modeller
RYT113929/1	LDO 120 MA LINEAR REGULATOR	5	LDO 120MA Linear regulator	0,195			eski modeller
RYT113955/1	1,8V LOW NOISE 1200-1934	16	1.8V low noise 150mA LDO regulator.	0,135			eski modeller
RYT113955/2	LDO 2.8V 150 MA CS-4 1200-1936	7	LDO. 2.8V. 150mA. CS-4	0,135			eski modeller
RYT113955/7	LDO 3.0V 150MA CS-4 1000-8623	5	LDO, 3.0V, 150mA, CS-4	0,135			eski modeller
RYT113997/4	2CS LDO VOUT1=2.8V 1000-8638	1	IC Voltage Regulator	0,18			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
RYT118968/1	W960 MEM MCP2 GBIT 111.0MHZ	1	Mem MCP 2 Gbit+1 Gbit 111.0 MHz 1.8 V 15	10,785			eski modeller
RYT123927/1	T650 CAMERA ISP	3	Camera ISP	3,54			eski modeller
RYT326908/1	LEVEL SHIFTER	2	Level Shifter	0,135			eski modeller
RYT326916/1	P990 SIGLE GATE 1001-0792	5	Single gate 74LVC1G32 Leadfree	0,135			eski modeller
RYT901960/1	QUAD BAND ANTENNA SWITCH	3	Quad Band Antenna Switch(GSM850/900/1800	1,2			eski modeller
RYT901968/1	S500 FRONT END MODULE	5	Front End Module	1,95			eski modeller
S/188650007	W302 SMD COAX CONN.	5	SMD Coax connector	0,165	W302	2009	Xperia öncesi yeniler
S/189067660	W302 VARISTOR	5	Varistor 0402	0,03	W302	2009	Xperia öncesi yeniler
S/189172304	W302 CAPACITOR	5	Capacitor 33uF	0,075	W302	2009	Xperia öncesi yeniler
S/189380302	W302 EMI ESD FOLTER	5	EMI/ESD Filter	0,255	W302	2009	Xperia öncesi yeniler
S/189627221	W302 BTB 50P F	5	Btb 50p F	0,615	W302	2009	Xperia öncesi yeniler
S/189725712	W302 FERRITE 0402	5	Ferrite 0402	0,015	W302	2009	Xperia öncesi yeniler
S/189753451	W302 BATTERY CONN. 1220-1012	5	Battery connector	0,18	W302	2009	Xperia öncesi yeniler
S/189812820	W302 VARISTOR	5	Varistor 0402	0,075	W302	2009	Xperia öncesi yeniler
S/252993078	W302 SHIELD CAN LID RADIO	5	Shieldcan Lid Radio	0,21	W302	2009	Xperia öncesi yeniler
S/254022723	W302 CAMERA RUBBER	5	Camera Rubber	0,09	W302	2009	Xperia öncesi yeniler
S/254022984	W302 CAMERA SUPPORT	4	Camera support assy	0,255	W302	2009	Xperia öncesi yeniler
S/254046885	W302 MIC. GASGET	5	Mic gasket	0,18	W302	2009	Xperia öncesi yeniler
SOA970240A0	W205 ANTENNA MAIN	20	Antenna Main 900 MHz Assy	3,915	W205	2009	Xperia öncesi yeniler
SOR03F7B010	W205 EAR SPEAKER	13	Ear Speaker	0,72	W205	2009	Xperia öncesi yeniler
SA027WZ10A0	J110 BUFFER AMPLIFIER	5	Buffer amplifier	4,05			eski modeller
SA073028300	J110 LINEAR REGULATOR	14	Linear regulator output IC	0,12			eski modeller
SD2CRS08301	J110 SCHOTTKY DIOD	3	Schottky Diode	0,045			eski modeller
SG012ST50A0	J110 VARISTOR	5	Varistor	0,045			eski modeller
SG0330NP110	W205 TRANS. VOLTAGE SUPP.	5	Transient voltage suppressor	0,015	W205	2009	Xperia öncesi yeniler
SG033ST50A0	J110 ESD PROTECTION 9X3.3	5	ESD Protection 9X3.3	0,045			eski modeller
SG05V0L20A0	W205 PROTECT.DIODE	5	Protection Diode	0,06	W205	2009	Xperia öncesi yeniler
SG0AVL5M040	W205 VARISTOR	5	Varistor	0,015	W205	2009	Xperia öncesi yeniler
SG2501010A0	W205 IC ESD PROTECT	5	IC ESD Protection 25pF 1000	0,075	W205	2009	Xperia öncesi yeniler
SLT19311A00	W205 LCD	24	Display	8,655	W205	2009	Xperia öncesi yeniler
SND10620	K700 BATTERY CONN. 1000-0412	11	battery Connector	0,12			eski modeller
SND10622	K790 BATTERY CONN	7	Conn Leaf Spring Battery	0,12			eski modeller
SND10625	W550 INTERNAL ANTEN CONN	9	Internal Antenna Connector	0,075			eski modeller
SND10630	S700 BATTERY CONN 1200-2387	2	Conn Other	0,15			eski modeller
SND90158	K530 ANTENNA CONN.1001-1227	5	Antenna Pin Connector	0,03			eski modeller
SND90161	K850 ANTENNA CON 1200-2144	17	Conn Leaf Spring	0,045			eski modeller
SR00000452	Z320 RESISTOR , OHM	128	Resistor 0 Ohm	0,015			eski modeller
SR000230251	W205 RESISTOR 2K	100	Resistor 2K, 0201 #}5%	0,015	W205	2009	Xperia öncesi yeniler
SR010030251	W205 RESISTOR 100K	100	Resistor 100K, 0201 #}5%	0,015	W205	2009	Xperia öncesi yeniler
SS04151P250	J110 MOSFET	5	MOSFET	0,075			eski modeller
SVF9301379	S700 LEAD FREE LABEL SHEET OF	20	Lead-free Labels (sheet of 24)	0,015			eski modeller
SVF9302621	KRH LABEL K850	150	LABEL/KRH	0,045			eski modeller
SVF9302657	KRH LABEL K660	20	KRH Label	0,03			eski modeller
SXA1092883	T650 SCREW	48	Screw Torx6, length 6,6 diam 1,6 PTC	0,015			eski modeller
SXA1094884	K700 WATER INDICATOR LABEL	55	Liquid Intrusion Indicator	0,015			eski modeller
SXA1095031	K550 SCREW 4*4 FRAME COVER	28	Screw Other Len:4.0 Diam:1.4	0,015			eski modeller
SXA1095070	W890 SCREW 1,4*3,5 JCIS	10	Screw 1,4x3,5 JCIS	0,015			eski modeller
SXA1095503	W550 SCREW M 1,7	68	Screw Len:0, Diam:0,	0,03			eski modeller
SXA1095648	K600 B TO B CON FOR CAM 20 PIN	5	Conn SIM	0,21			eski modeller
SXA1095884	W995 SCREW 1.7X4.5	58	Screw 1.7 X 4.5	0,015	W995	2010	Xperia öncesi yeniler
SXA1096165	W810 GASKET SYSTEM	20	Dust Gasker I/O Connector	0,03			eski modeller
SXA1096432	K610 SIM READER 1000-9065	11	SIM card reader	0,21			eski modeller
SXA1096654	Z610 SCREW 1,7*5,5 4	37	Screw torx Len 5.5 Diam 1.7	0,015			eski modeller
SXA1096954	HCB-100 CLIP	9	Clip	0,645			eski modeller
SXA1097055/12	K550 SYSTEM CONN	430	12 p System Connector	0,18			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
SXA1097275	S500 RECEIVER GROMMET	11	RECEIVER GROMMET	0,045			eski modeller
SXA1097280	S500 MICROPHONE GASKET	15	MICROPHONE GASKET	0,06			eski modeller
SXA1097321/54	S500 REAR FRAME WHITE	11	REAR FRAME/WHITE	0,765			eski modeller
SXA1097321/55	W580 REAR FRAME WHITE	14	REAR FRAME/White	1,005			eski modeller
SXA1097321/57	W580 REAR FRAME DK BLUE	13	REAR FRAME/DK. BLUE	1,02			eski modeller
SXA1097327	S500 ANTENNA COAX	15	ANTENNA COAX	0,87			eski modeller
SXA1097340/201	S500 NAVIGATION BLACK	15	KEYPAD/NAVIGATION/BLK	1,935			eski modeller
SXA1097340/301	S500 NAVIGATION SORBET YELLOW	3	KEYPAD/NAVIGATION/SORBET YELLOW	1,935			eski modeller
SXA1097341	S500 VOLUME KEY	70	KEY/VOLUME	0,21			eski modeller
SXA1097343	S500 ON-OFF KEY	89	KEY/POWER	0,06			eski modeller
SXA1097352/201	S500 DECOR COVER CHIN BLACK	14	CVR/CHIN/DECOR/BLK CLR COAT	0,27			eski modeller
SXA1097352/301	S500 DECOR COVER CHIN YELLOW	4	CVR/CHIN/DECOR/SORBET YELLOW	0,255			eski modeller
SXA1097355/1	S500 SCREW 1.6X2.7 RED TREAD	54	SCREW/M1.6X2.7/Red Threadlock	0,03			eski modeller
SXA1097355/2	S500 SCREW 1.6X2.7 BLUE THREA	46	SCREW/M1.6X2.7/Blue Threadlock	0,03			eski modeller
SXA1097360/201	S500 BATTERY COVER BLACK SOFT	113	BATTERY DOOR/BLK SOFT TCH	0,39			eski modeller
SXA1097360/301	S500 BATTERY COVER YELLOW	7	BATTERY DOOR/SORBET YELLOW	0,405			eski modeller
SXA1097461	S500 KEYBOARD WEAR STRIP LEFT	42	KYPD WEAR STRIP/LEFT	0,03			eski modeller
SXA1097462	S500 KEYBOARD WEAR STPIP RIGHT	49	KYPD WEAR STRIP/RIGHT	0,03			eski modeller
SXA1097510	S500 GASKET LCD DUST	14	LCD DUST GASKET	0,24			eski modeller
SXA1097559	S500 SHIELD CAN RF	5	SHIELD CAN/RF	0,045			eski modeller
SXA1097560	S500 SHIELD FENCE BBAND	5	SHIELD/FENCE/BBAND	0,12			eski modeller
SXA1097561	S500 SHIELD LID BBAND	1	SHIELD/LID/BBAND	0,06			eski modeller
SXA1097600	K600 WATER INDICATOR	20	Water Indicator	0,015			eski modeller
SXA1097700/1	W580 COVER CHIN WHITE	8	CHIN COVER/SILVER-WHITE	0,27			eski modeller
SXA1097700/102	W580 COVER CHIN WHITE WALKMAN	3	CHIN COVER/SLVR-WHT/WALKMAN	0,465			eski modeller
SXA1097700/2	W580 COVER CHIN GREY	29	COVER/CHIN/DECORATIVE, GREY	0,255			eski modeller
SXA1097700/3	W580 COVER CHIN BLACK	2	CHIN COVER/BLK	0,255			eski modeller
SXA1097700/302	W580 COVER CHIN BLACK WALKMAN	4	CHIN COVER/BLK W/ORG ACCENTS/WALKMAN	0,45			eski modeller
SXA1097700/402	W580 COVER CHIN PINK	6	COVER/CHIN/DECORATIVE (Pink)	0,465			eski modeller
SXA1097705/101	W580 NAVIGATION WHITE ORANGE	4	KEYPAD/NAVIGATN/SLVR-WHT/GENERIC	2,385			eski modeller
SXA1097705/201	W580 NAVIGATION GOLD GRAY	20	KYPD/NAVIGATON/SLVR-WHT	2,385			eski modeller
SXA1097705/401	W580 NAVIGATION PINK	15	KYPD/NAVIGATON/PINK W/ORG TRIM/GENERIC	2,385			eski modeller
SXA1097787/201	S500 NUMERICK KEYBOARD BLACK	38	NUMERIC KEYPAD/GRN KEYS - GRN MAT/LATIN	4,02			eski modeller
SXA1097957/54	S500 DOOR/M2/WHITE	29	DOOR/M2 MEMORY/WHITE	0,075			eski modeller
SXA1097957/57	W580 DOOR/M2/DK BLUE	24	DOOR/M2 MEMORY/DK BLUE	0,06			eski modeller
SXA1097958	S500 TAPE BT ANTENNA KAPTON	10	TAPE/BT ANTENNA/KAPTON	0,015			eski modeller
SXA1097984/101	W580 NUMERICK WHITE ORANGE	3	NUMERIC KEYPAD/ORG KEYS - WHT MAT/LATIN	3,81			eski modeller
SXA1097984/201	W580 NUMERICK GOLD GRAY	32	KYPD/WIDE-NUMERC/GOLD GRAY/LATIN	3,51			eski modeller
SXA1097984/401	W580 NUMERICK PINK	16	NUMERIC KEYPAD/WHT KEYS - SLVR MAT/LATIN	3,51			eski modeller
SXA1098023	S500 GASKET LCD WALKMAN LOGO	17	LCDDUSTGASKETW/WALKMANLOGOCUTOUT	0,24			eski modeller
SXA1098108	PORON PAD COAX RSE GROUND	5	PORON PAD/COAX RSE GROUND	0,015			eski modeller
SXA1098115	S500 GASKET ANTI EASY BOTTOM	42	Anti-easy press bottom gasket	0,015			eski modeller
SXA1098117	S500 GASKET ANTI EASY TOP	48	Anti-easy press top gasket	0,015			eski modeller
SXA1098151	W580 ADHESIVE TAPE	101	ADHESIVE TAPE	0,015			eski modeller
SXA1098287	W580 LCD METAL FRAME	4	LCD Metal Frame (Sharp)	0,405			eski modeller
SXA2148707/8	HBH-PV702 DECO COVER GREY	5	Deco Cover Grey	0,135			eski modeller
SXA2148778/2	HBH-PV710 DECO COV. BROWN	8	Deco Cover Metallic Brown	0,54			eski modeller
SXA2148778/4	HBH-PV710 DECO COVER LIME GREE	5	Deco Cover Metallic Lime Green	0,375			eski modeller
SXK1097388	HBH-IV835 EAR CUSHIONS SET	5	Ear cushions set S/M/L	0,705			eski modeller
SXK1097436	HBH-GV435 BATTERY	2	HBH-GV435 Battery Repair Assembly	4,44			eski modeller
SXK1097453/54	S500 FRONT FRAME WHITE	22	FRONT FRAME CPL/WHITE	1,5			eski modeller
SXK1097453/57	W580 FRONT FRAME CPL DK BLUE	13	FRONT FRAME/ DARK BLUE	1,485			eski modeller
SXK1097454/22	S500 BONZER FLEX	3	Bonzer Flex	11,895			eski modeller
SXK1097466/1	S500 MAIN KEYPAD	40	Main Keypad FPC	3,54			eski modeller
SXK1097468/201	S500 DECOR CAMERA COVER BLACK	23	Assy Decor Camera CVR Black	2,115			eski modeller

Material Number (SAP)	Material Description	quantity	Material Description	unit price(EURO)	MODEL	Son Üretim yılı	GURUP
SXK1097468/301	S500 DECOR CAMERA YELLOW	1	ASSY/DECOR CAM CVR/YELLOW	2,115			eski modeller
SXK1097469/201	S500 REAR COVER BLACK SOFT TCH	19	ASSY/REAR CVR/BLK SOFT TCH	0,825			eski modeller
SXK1097469/301	S500 REAR COVER YELLOW	3	ASSY/REAR CVR/SORBET YELLOW	0,99			eski modeller
SXK1097504/201	S500 FRONT COVER BLACK CLR COA	25	ASSY/FRONT CVR/BLK CLR COAT	1,275			eski modeller
SXK1097504/301	S500 FRONT COVER YELLOW	2	ASSY/FRONT CVR/SORBET YELLOW	1,425			eski modeller
SXK1097681/1	W580 FRONT COVER WHITE	10	ASSY/FRNT CVR/SILVER-WHT	1,71			eski modeller
SXK1097681/2	W580 FRONT COVER GREY	18	ASSY/FRONT COVER/SLV-WHT/GREY KIT	1,62			eski modeller
SXK1097681/3	W580 FRONT COVER BLACK	1	ASSY/FRONT COVER/SLV-BLK	1,635			eski modeller
SXK1097681/4	W580 FRONT COVER PINK	14	FRONT COVER/PINK	1,71			eski modeller
SXK1097682/1	W580 REAR COVER WHITE	12	ASSY/REAR CVR/SILVER-WHT	1,275			eski modeller
SXK1097682/2	W580 REAR COVER GOLD GREY	10	ASSY/REAR COVER/SLVR-WHT/GREY KIT	1,23			eski modeller
SXK1097682/3	W580 REAR COVER BLACK	4	ASSY/REAR COVER/SLVR-BLK	1,215			eski modeller
SXK1097682/4	W580 REAR COVER PINK	15	ASSY/REAR COVER/PINK W/ORANGE TRIM	1,275			eski modeller
SXK1097683/1	W580 BATTERY COVER WHITE	6	ASSY/BATTRY CVR/SILV-WHT	1,08			eski modeller
SXK1097683/2	W580 BATTERY COVER GREY	73	ASSY/BATTERY CVR/SLV-WHT/GREY KIT	1,02			eski modeller
SXK1097683/3	W580 BATTERY COVER BLACK	3	ASSY/BATTERY CVR/SLV-BLK	1,02			eski modeller
SXK1097683/4	W580 BATTERY COVER PINK	31	ASSY/BATTERY CVR/PINK W/ORANGE TRIM	1,08			eski modeller
SXK1097684/1	W580 DECOR CAMERA ORANGE	12	ASSY/CAMERA COVER/ORANGE	2,115			eski modeller
SXK1097684/2	W580 DECOR CAMERA DK BLUE	19	ASSY/CAMERA COVER/DRK BLUE	2,115			eski modeller
SXK1097684/3	W580 DECOR CAMERA PINK	12	ASSY/CAMERA COVER/PINK	2,115			eski modeller
W5301154000	W205 SCREW	51	Screw Torx 5 Len:4.3 Diam:1.4 Black	0,015	W205	2009	Xperia öncesi yeniler
W6501142020	W205 SCREW	4	Screw T5 1.4*2.0	0,015	W205	2009	Xperia öncesi yeniler